Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Billboard BB141

Billboard Bluetooth Wireless Mini Pill Speaker BB141 User Manual

Model: BB141

Introduction

Thank you for purchasing the Billboard Bluetooth Wireless Mini Pill Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker. Please read it thoroughly before use to ensure optimal performance and longevity of the device.

Important Safety Information

- Do not expose the speaker to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the speaker to strong impacts.
- Do not disassemble or attempt to repair the speaker yourself. This will void the warranty.
- Keep the speaker away from water and other liquids.
- Use only the provided charging cable or a certified equivalent.
- Dispose of the speaker and its battery responsibly according to local regulations.

Package Contents

Please check that all items are present:

- Billboard Bluetooth Wireless Mini Pill Speaker (BB141)
- USB Charging Cable
- User Manual

Product Overview

Familiarize yourself with the speaker's components:



Figure 1: Front view of the Billboard Bluetooth Wireless Mini Pill Speaker, showing the speaker grille and Billboard logo.



Figure 2: Packaging of the Billboard Bluetooth Wireless Mini Pill Speaker, illustrating key features such as Bluetooth connectivity, FM tuner, 3.5mm AUX input, and Micro SD card reader.

Note: Specific button layouts and port locations are typically detailed in a diagram. For this manual, assume standard button functions for portable speakers.

- **Power Button:** Turns the speaker on/off.
- **Mode Button:** Switches between Bluetooth, FM Radio, AUX, and Micro SD modes.
- **Play/Pause Button:** Controls audio playback and answers/ends calls.
- **Volume Up/Next Track Button:** Increases volume or skips to the next track.
- **Volume Down/Previous Track Button:** Decreases volume or skips to the previous track.
- **Micro USB Charging Port:** For charging the speaker.
- **AUX Input Port:** For wired audio connection.
- **Micro SD Card Slot:** For playing music directly from a Micro SD card.

Setup

1. Charging the Speaker

1. Connect the small end of the USB charging cable to the Micro USB charging port on the speaker.
2. Connect the large end of the USB charging cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate, typically red, during charging.
4. Once fully charged (approximately 2-3 hours), the indicator light will change color or turn off.

5. A full charge provides up to 4 hours of audio playback.

2. Powering On/Off

- To power on, press and hold the **Power Button** for a few seconds until you hear an audible prompt or see an indicator light.
- To power off, press and hold the **Power Button** again for a few seconds until the speaker turns off.

3. Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth mode. If not, press the **Mode Button** until you hear the Bluetooth pairing prompt.
2. On your mobile device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for available Bluetooth devices. The speaker will appear as "**Billboard BB141**" or similar.
4. Select the speaker from the list to pair. You will hear a confirmation tone once successfully paired.
5. The speaker has a wireless range of up to 33 feet (10 meters).

4. FM Radio Operation

1. Press the **Mode Button** to switch to FM Radio mode.
2. Press the **Play/Pause Button** once to automatically scan and save available FM stations.
3. Use the **Volume Up/Next Track** and **Volume Down/Previous Track** buttons to navigate between saved stations.

5. AUX Input Operation

1. Connect one end of a 3.5mm audio cable (not included) to the AUX input port on the speaker.
2. Connect the other end of the 3.5mm audio cable to the audio output jack of your external device.
3. Press the **Mode Button** to switch to AUX mode.
4. Audio will now play through the speaker from your connected device. Control playback from your external device.

6. Micro SD Card Playback

1. Insert a Micro SD card (not included) with MP3 audio files into the Micro SD card slot on the speaker.
2. Press the **Mode Button** to switch to Micro SD card mode.
3. The speaker will automatically begin playing audio files from the card.

Operating the Speaker

Basic Controls

- **Play/Pause:** Press the **Play/Pause Button** once to play or pause audio.
- **Volume Up:** Press and hold the **Volume Up/Next Track Button** to increase volume.
- **Volume Down:** Press and hold the **Volume Down/Previous Track Button** to decrease volume.
- **Next Track:** Press the **Volume Up/Next Track Button** once to skip to the next track (in Bluetooth or Micro SD mode).
- **Previous Track:** Press the **Volume Down/Previous Track Button** once to go to the previous track (in Bluetooth or Micro SD mode).

Answering/Ending Calls (Bluetooth Mode)

- When a call comes in while connected via Bluetooth, the speaker will ring.
- To answer the call, press the **Play/Pause Button** once.
- To end the call, press the **Play/Pause Button** once again.
- To reject an incoming call, press and hold the **Play/Pause Button** for approximately 2 seconds.

Maintenance

Cleaning

- Wipe the speaker's exterior with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents, as these may damage the finish.
- Avoid getting moisture into any openings.

Storage

- When not in use for extended periods, store the speaker in a cool, dry place.
- It is recommended to fully charge the speaker every 3-6 months to maintain battery health.

Troubleshooting

Problem	Possible Solution
Speaker does not turn on.	Ensure the speaker is charged. Connect it to a power source using the USB cable.
No sound.	Increase the volume on both the speaker and your connected device. Ensure the speaker is in the correct mode (Bluetooth, AUX, FM, Micro SD). If using Bluetooth, ensure it is paired correctly. If using AUX, ensure the cable is fully inserted and functional.
Bluetooth pairing fails.	Ensure the speaker is in Bluetooth pairing mode. Disable and re-enable Bluetooth on your device. Move the speaker closer to your device. Forget the speaker from your device's Bluetooth list and try pairing again. Ensure no other devices are currently connected to the speaker.
Poor FM radio reception.	Relocate the speaker to an area with better signal. Perform an automatic station scan again.

Specifications

Model Number	BB141
Connectivity	Bluetooth, 3.5mm AUX
Wireless Range	Up to 33 feet (10 meters)
Battery Life	Up to 4 hours (audio playback)
Power Output	5 Watts
Dimensions (L x W x H)	4.25" x 2.25" x 3.5" (10.8 cm x 5.7 cm x 8.9 cm)
Weight	163 g (0.36 lbs)
Material	Plastic
Additional Features	FM Radio, Micro SD Card Reader

Warranty and Support

For warranty information and technical support, please refer to the warranty card included with your product or visit the official Billboard website. Keep your proof of purchase for any warranty claims.
For further assistance, please contact Billboard customer service.

© 2023 Billboard. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0844BH6T5

More documents and user manuals: **https://manuals.plus/**