Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Billboard BB1846

Billboard Wireless Bluetooth Speaker User Manual

Model: BB1846

Introduction

Thank you for purchasing the Billboard Wireless Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. Please read this manual thoroughly before using the device.

Package Contents

Verify that all items are present in the package:

- 1 x Billboard Wireless Bluetooth Speaker
- 1 x Charging Cable (typically included, but may vary)
- 1 x User Manual (this document)

Product Overview

Familiarize yourself with the various parts and controls of your Billboard Wireless Bluetooth Speaker.



Figure 1: Front view of the Billboard Wireless Bluetooth Speaker, showcasing its cylindrical shape and black mesh fabric.



Figure 2: Angled front view of the speaker, highlighting its textured surface.



Figure 3: Rear view of the speaker, showing the rubber flap covering the AUX, TF/USB, and DC5V ports.



Figure 4: Bottom view of the speaker, displaying the product label with model number BB1846, audio output power, and manufacturer information.



Figure 5: Side view of the speaker, showing its compact and portable design.



Figure 6: Top view of the speaker, featuring the control panel with Play/Pause, Volume Down/Previous, Volume Up/Next, and Mode/Power buttons.

Setup

Charging the Speaker

1. Locate the DC5V charging port on the rear of the speaker, typically under a rubber flap.
2. Connect the provided charging cable to the speaker's DC5V port.
3. Connect the other end of the charging cable to a compatible USB power adapter (not included) or a computer's USB port.
4. The charging indicator light (if present) will illuminate during charging and turn off when fully charged.
5. Allow approximately 2-3 hours for a full charge before first use.

Powering On/Off

- **To Power On:** Press and hold the **M/Power** button on the top panel for a few seconds until you hear an audible prompt or see an indicator light.
- **To Power Off:** Press and hold the **M/Power** button again for a few seconds until the speaker powers down.

Operating Instructions

Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth mode. If not, press the **M** (Mode) button to switch to Bluetooth mode. The speaker will enter pairing mode, indicated by a flashing LED light.
2. On your mobile device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for available Bluetooth devices. You should see "Billboard Wireless Bluetooth Speaker" or a similar name in the list.
4. Select the speaker from the list to initiate pairing.
5. Once successfully paired, the speaker will provide an audible confirmation, and the LED light will stop flashing and remain solid.
6. You can now play audio from your device through the speaker.

Controlling Playback

- **Play/Pause:** Press the **Play/Pause** button (often indicated by a triangle/two vertical bars icon) on the top panel to play or pause audio.
- **Volume Up:** Press the **+** button to increase the volume.
- **Volume Down:** Press the **-** button to decrease the volume.
- **Next Track:** Press and hold the **+** button to skip to the next track.
- **Previous Track:** Press and hold the **-** button to go to the previous track.

Using AUX Input

For devices without Bluetooth, you can use the AUX input:

1. Connect one end of a 3.5mm audio cable (not included) to the AUX port on the speaker.
2. Connect the other end of the audio cable to the headphone jack or audio output of your device.
3. Press the **M** (Mode) button on the speaker to switch to AUX mode.
4. Audio will now play through the speaker via the wired connection.

Using USB/TF Card Input

The speaker supports playback from USB drives and TF (microSD) cards:

1. Insert a USB drive or TF card containing MP3 audio files into the respective port on the speaker.
2. The speaker should automatically switch to USB or TF card mode and begin playing. If not, press the **M** (Mode) button to cycle through modes until the correct input is selected.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the speaker. Do not use abrasive cleaners, waxes, or solvents.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in constant use.
- **Water Resistance:** The product is listed as "Water Resistant" but not "Waterproof". Avoid submerging the speaker in water or exposing it to heavy rain. Ensure port covers are securely closed to maintain water resistance.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is depleted.	Charge the speaker fully.
No sound from speaker.	Volume is too low or muted. Device not paired correctly. Incorrect input mode.	Increase volume on speaker and connected device. Re-pair Bluetooth. Press 'M' button to select correct input mode (Bluetooth, AUX, USB/TF).
Bluetooth device cannot find speaker.	Speaker is not in pairing mode. Speaker is already connected to another device. Device is out of range.	Ensure speaker is in Bluetooth pairing mode (flashing LED). Disconnect from other devices. Move device closer to speaker (within 33 feet/10 meters).
Poor audio quality.	Interference. Low battery. Source audio quality.	Move speaker away from other electronic devices. Charge the speaker. Try a different audio source or file.

Specifications

Feature	Detail
Model Name	Billboard Wireless Bluetooth Speaker (BB1846)
Connectivity Technology	Bluetooth
Speaker Type	Multimedia
Audio Output Mode	Stereo
Power Source	Battery Powered
Control Method	Touch
Product Dimensions	6 x 8 x 2 inches
Item Weight	13.5 ounces

Feature	Detail
Color	Black
Water Resistance Level	Water Resistant
Manufacturer	ESI Cases & Accessories

Warranty and Support

This product comes with a Limited Warranty. For specific warranty terms and conditions, please refer to the documentation included with your purchase or contact the manufacturer directly.
For technical support or customer service inquiries, please contact ESI Cases & Accessories, the manufacturer of this Billboard product. Contact information may be available on their official website or through your retailer.
Note: Proposition 65 Warning applies to this product. For more information, please refer to the warning label on the product packaging.

Important Safety Information

- Do not expose the speaker to extreme temperatures, direct sunlight, or high humidity.
- Do not disassemble, repair, or modify the speaker yourself. This may void the warranty and pose safety risks.
- Keep the speaker away from children and pets.
- Use only the specified charging cable and power adapter.
- Avoid dropping or subjecting the speaker to strong impacts.
- Dispose of the product and its battery responsibly according to local regulations.

© 2024 Billboard. All rights reserved.
Manufactured by ESI Cases & Accessories

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0844HV1J3

More documents and user manuals: **https://manuals.plus/**