Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Geepas GLED3202SEHD

Geepas 32 Inch LED Standard TV (Model GLED3202SEHD) User Manual

Your Guide to Setup, Operation, and Maintenance

1. Introduction and Important Safety Information

Thank you for purchasing the Geepas 32 Inch LED Standard TV, Model GLED3202SEHD. This manual provides essential instructions for the safe and efficient use of your television. Please read this manual thoroughly before operating the device and retain it for future reference.

Important Safety Instructions:

- Read all instructions before operating the TV.
- Keep the TV away from water or moisture.
- Clean only with a dry cloth. Do not use liquid cleaners.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

2. Product Overview

The Geepas 32 Inch LED Standard TV offers a clear viewing experience with its HD resolution and integrated smart features. Below is an overview of the product and its components.

Included Components:

- Geepas 32 Inch LED Standard TV
- Remote Control

- TV Stand (2 pieces)
- Power Cord
- User Manual (this document)

Key Features:

- 32-inch LED Display
- HD Resolution (1366x768)
- Integrated Wi-Fi Connectivity
- Pre-installed Netflix Application
- Multiple Connectivity Ports (HDMI, USB)



This image displays the front view of the Geepas 32 Inch LED Standard TV. The screen shows a colorful image of hot air balloons against a blue sky with clouds, reflected in water below. The television features a slim black bezel and two black stand feet at the bottom.

3. Setup

Follow these steps to set up your new Geepas TV.

3.1 Unpacking

- Carefully remove the TV and all accessories from the packaging.
- Place the TV face down on a soft, flat surface (e.g., a blanket or foam) to prevent screen damage during stand assembly.

3.2 Stand Assembly

- Locate the two stand pieces and the necessary screws (usually found in a separate bag).

- Align each stand piece with the corresponding slots on the bottom of the TV.
- Secure the stands using the provided screws. Ensure they are tightened firmly but do not overtighten.

3.3 Connecting Power

- Connect the power cord to the power input port on the back of the TV.
- Plug the other end of the power cord into a wall outlet.

3.4 Connecting External Devices

Your TV is equipped with various ports for connecting external devices:

- **HDMI Ports:** For high-definition devices like Blu-ray players, game consoles, or set-top boxes. Use an HDMI cable to connect the device to an HDMI port on the TV.
- **USB Ports:** For connecting USB storage devices to play media files.
- **Antenna/Cable Input:** Connect your coaxial cable from an antenna or cable service provider for broadcast channels.
- **Ethernet Port (LAN):** For a wired internet connection. Alternatively, use Wi-Fi for wireless connectivity.

4. Operating Your TV

This section covers basic operation and smart TV features.

4.1 Remote Control Functions

Insert two AAA batteries into the remote control, observing polarity. The remote control allows you to access all TV functions.

- **Power Button:** Turns the TV on or off.
- **Volume (+/-):** Adjusts the sound level.
- **Channel (CH +/-):** Changes TV channels.
- **Input/Source:** Selects the input source (HDMI 1, HDMI 2, TV, USB, etc.).
- **Navigation Buttons (Up/Down/Left/Right/OK):** Navigate menus and confirm selections.
- **Back/Exit:** Returns to the previous menu or exits the current menu.
- **Netflix Button:** Direct access to the Netflix application.

4.2 Initial Setup Wizard

Upon first power-on, the TV will guide you through an initial setup process:

1. **Language Selection:** Choose your preferred language.
2. **Country/Region:** Select your country for correct channel tuning.
3. **Network Setup:** Connect to your Wi-Fi network by selecting your network name and entering the password.
4. **Channel Scan:** The TV will scan for available broadcast channels.

4.3 Smart TV Features

With built-in Wi-Fi, your Geepas TV allows access to online content.

- **Wi-Fi Connection:** Ensure your TV is connected to a stable internet connection via Wi-Fi (or Ethernet). You can

manage this in the TV's network settings.

- **Netflix:** Press the dedicated Netflix button on your remote or navigate to the Smart TV menu to launch the application. Log in with your Netflix account credentials to start streaming.

5. Maintenance

Proper care and maintenance will extend the life of your TV.

5.1 Cleaning the TV

- Always unplug the TV from the power outlet before cleaning.
- **Screen:** Use a soft, lint-free cloth (e.g., microfiber) to gently wipe the screen. For stubborn marks, lightly dampen the cloth with water or a specialized screen cleaner, then wipe dry immediately. Never spray liquid directly onto the screen.
- **Body:** Wipe the TV casing with a soft, dry cloth. Avoid using abrasive cleaners, waxes, or solvents as they can damage the finish.

5.2 General Care

- Avoid exposing the TV to direct sunlight, extreme temperatures, or high humidity.
- Do not place heavy objects on top of the TV.
- Ensure adequate ventilation around the TV to prevent overheating.

6. Troubleshooting

If you encounter issues with your TV, refer to the following common problems and solutions.

Problem	Possible Solution
No power	Check if the power cord is securely plugged into both the TV and the wall outlet. Test the outlet with another device.
No picture or sound	Ensure the correct input source is selected (e.g., HDMI 1, TV). Check all cable connections. Increase the volume.
Remote control not working	Replace the batteries. Ensure there are no obstructions between the remote and the TV's IR sensor.
Cannot connect to Wi-Fi	Check if your Wi-Fi router is on and functioning. Re-enter the Wi-Fi password in the TV's network settings. Try restarting both the TV and the router.
Netflix not loading	Ensure a stable internet connection. Try restarting the TV. Check for any available software updates for the TV.

7. Specifications

Detailed technical specifications for the Geepas 32 Inch LED Standard TV.

- **Brand:** Geepas

- **Model Name:** GLED3202SEHD
- **Item Model Number:** geepas 32 led
- **Screen Size:** 32 Inches
- **Display Type:** LED
- **Display Resolution:** 1366x768 (HD)
- **HD Type:** HD
- **Connectivity Technology:** Wi-Fi
- **Supported Internet Services:** Netflix
- **Aspect Ratio:** 16:9
- **Special Features:** Flat Screen
- **Included Components:** Remote Control, Stand, TV
- **External Product ID Type:** EAN-13
- **External Product ID:** 6294015509175
- **Date First Available:** 21 November 2019

8. Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Geepas website. You may also contact Geepas customer service directly for assistance with product inquiries, technical support, or service requests.

© 2023 Geepas. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0847NMSK5

More documents and user manuals: **https://manuals.plus/**