**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**LEXiBOOK RL977FZ**

# LEXIBOOK Projector Clock RL977FZ Disney Frozen 2 User Manual

Model: RL977FZ

## Introduction

This manual provides instructions for the LEXIBOOK Projector Clock, model RL977FZ. This device features a digital alarm clock, a night light with a projection function, and a snooze feature. Please read this manual thoroughly before use to ensure proper operation and to maintain the product's longevity.




Image: The LEXIBOOK Projector Clock, model RL977FZ, displaying the time 13:45. The clock features Disney Frozen 2 characters

Anna and Elsa on its face. A blue projection is visible emanating from the top of the clock.

## Important Safety Information

- This product is not a toy. Adult supervision is recommended for young users.
- Do not expose the device to direct sunlight, extreme temperatures, or high humidity.
- Avoid dropping the device or subjecting it to strong impacts.
- Do not attempt to disassemble or modify the device. This will void the warranty.
- Dispose of batteries responsibly according to local regulations.

## Package Contents

The package contains:

- 1 x LEXIBOOK Projector Clock RL977FZ

*Note: 3 x AAA batteries are required for operation and are not included in the package.*

## Setup

### 1. Battery Installation

1. Locate the battery compartment on the underside of the clock.
2. Open the battery compartment cover.
3. Insert 3 new AAA (LR03) batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

### 2. Initial Power-On

Once batteries are installed, the LCD screen will illuminate, and the clock will be ready for time setting.




Image: A detailed view of the control buttons on the front of the LEXIBOOK Projector Clock, including 'Time', 'Alarm', 'Hour', 'Min', and 'On/Off' for the night light/projection.

## Operating Instructions

### 1. Setting the Time

1. Press the **TIME** button. The hour display will flash.
2. Use the **HOUR** button to adjust the hour.
3. Use the **MIN** button to adjust the minutes.
4. Press the **TIME** button again to confirm and exit time setting mode.

*Note: The clock supports 12-hour and 24-hour formats. Repeatedly pressing the HOUR button will cycle through AM/PM for 12-hour format or switch to 24-hour format.*

### 2. Setting the Alarm

1. Press the **ALARM** button. The alarm hour display will flash.

2. Use the **HOUR** button to set the desired alarm hour.
3. Use the **MIN** button to set the desired alarm minutes.
4. Press the **ALARM** button again to confirm and activate the alarm. An alarm icon will appear on the display.

*To deactivate the alarm, press the **ALARM** button until the alarm icon disappears from the display.*

## 3. Using the Snooze Function

When the alarm sounds, press any button (except the 'On/Off' button for the night light) to activate the snooze function. The alarm will temporarily stop and sound again after approximately 9 minutes.
To completely turn off the alarm, press the **ALARM** button.




Image: A child waking up and stretching in bed, with the LEXIBOOK Projector Clock visible on a wooden bedside table. The clock is projecting an image onto the ceiling, illustrating its alarm and projection features.

## 4. Night Light and Projection Function

The clock features a night light with a projection of Olaf, which can display in three different colors.

1. Press the **On/Off** button (with the light bulb icon) to activate the night light and projection.
2. Each press of the **On/Off** button will cycle through the projection colors (e.g., blue, red, orange) or turn the projection off.

3. The night light has integrated timers (5, 10, or 15 minutes) for automatic shut-off. To set the timer, press and hold the **On**/**Off** button. The display will show the current timer setting. Continue pressing to cycle through 5, 10, 15 minutes, or continuous mode. Release the button to select.




Image: The LEXIBOOK Projector Clock actively projecting a blue image of Olaf onto a surface above it, demonstrating its night light and projection capability.

## Maintenance

### Cleaning

Wipe the clock with a soft, dry cloth. Do not use abrasive cleaners or solvents, as these may damage the surface.

### Battery Replacement

When the display dims or the functions become erratic, it is time to replace the batteries. Follow the battery installation steps in the "Setup" section.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Clock does not turn on. | Batteries are not installed or are depleted. Incorrect battery polarity. | Ensure 3 new AAA batteries are installed correctly with the correct polarity. |
| Projection is dim or not visible. | Low batteries. Room is too bright. | Replace batteries. Ensure the room is dark for optimal projection visibility. |
| Alarm does not sound. | Alarm is not set or is deactivated. | Verify the alarm time is set and the alarm icon is visible on the display. |
| Buttons are unresponsive. | Low batteries. Temporary electronic glitch. | Replace batteries. Remove batteries for a few minutes and reinsert them to reset the device. |

## Specifications

**Model:** RL977FZ

**Brand:** LEXiBOOK

**Display Type:** Digital LCD

**Power Source:** 3 x AAA (LR03) batteries (not included)

**Special Features:** Alarm, Snooze, Night Light, Projection (Olaf in 3 colors), Timer (5/10/15 min)

**Product Dimensions:** Approximately 13"W x 3.58"H

**Item Weight:** Approximately 4.96 ounces

**Material:** Plastic, Acrylonitrile Butadiene Styrene

**Recommended Age:** 3 years and up

## Warranty Information

This product comes with a limited warranty. For specific details regarding warranty coverage and duration, please refer to the warranty card included with your purchase or contact LEXiBOOK customer support.

## Customer Support

For further assistance, technical support, or inquiries regarding your LEXIBOOK Projector Clock RL977FZ, please visit the official LEXiBOOK website or contact their customer service department. Contact information can typically be found on the product packaging or the brand's official website.

*Please have your model number (RL977FZ) ready when contacting support.*

© 2025 LEXiBOOK. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the

question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B084L974W8**

More documents and user manuals: **https://manuals.plus/**