Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire FCRE3052AS

Frigidaire 30 in. 5 Burner Element Freestanding Electric Range

Model: FCRE3052AS

User Instruction Manual

1. Introduction

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your new Frigidaire 30-inch 5 Burner Element Freestanding Electric Range. Please read all instructions thoroughly before using the appliance to ensure proper function and to prevent injury or damage. Keep this manual for future reference.

2. Safety Information

Your safety and the safety of others are very important. We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages.

- **WARNING:** To reduce the risk of fire, electric shock, or injury to persons, read the IMPORTANT SAFETY INSTRUCTIONS before operating this appliance.
- Do not store flammable materials in or near the range.
- Never use the appliance for warming or heating the room.
- Always use dry pot holders. Moist or damp pot holders on hot surfaces may result in burns from steam.
- Do not touch heating elements or interior surfaces of oven.
- Always ensure proper ventilation when using the range.

3. Product Overview

The Frigidaire 30-inch 5 Burner Element Freestanding Electric Range is designed for versatile cooking, featuring a smooth glass cooktop with multiple heating elements and a spacious oven with a convenient storage drawer.



Figure 3.1: Front view of the Frigidaire Electric Range, showcasing the stainless steel finish, black glass cooktop, and oven door with

handle.



Figure 3.2: Top-down view of the smooth black glass cooktop, showing five electric heating elements, including a 'Quick Boil' element and a 'Warm Zone'.



Figure 3.3: Close-up of the stainless steel control panel with digital display showing the time (6:04) and various cooking options such as Bake, Start, Broil, Cancel Off, Self Clean, Oven Light, Cook Time, and Delay Time.



Figure 3.4: The oven interior with the door open, revealing multiple rack positions for flexible cooking and a baking sheet on one of the racks.



Figure 3.5: Side view of the range with key dimensions labeled: 18.16 inches (cooktop to top of control panel), 10.04 inches (storage drawer height), and 11.65 inches (storage drawer depth).

4. Setup

Proper installation is crucial for the safe and efficient operation of your electric range. It is recommended that installation be performed by a qualified installer.

1. **Unpacking:** Carefully remove all packaging materials, tape, and protective film from the range. Retain packaging for potential future transport.
2. **Location:** Place the range in a suitable location, ensuring adequate clearance from combustible materials and proper ventilation.
3. **Electrical Connection:** Ensure the range is connected to a properly grounded electrical outlet with the correct voltage

and amperage as specified in the electrical requirements section of the full installation guide (not included in this manual). A power cord is typically not included and must be purchased separately.

4. **Leveling:** Adjust the leveling legs at the bottom of the range to ensure it is stable and level.
5. **Anti-Tip Bracket:** Install the anti-tip bracket according to the instructions provided with the bracket. This is a critical safety feature to prevent the range from tipping over.

5. Operating Instructions

5.1. Cooktop Operation

The smooth glass cooktop features multiple radiant heating elements controlled by knobs on the control panel.

- **Turning On Elements:** Turn the corresponding control knob to the desired heat setting (Low, Medium, High). The element will begin to heat up.
- **Hot Surface Indicator:** A 'Hot Surface' indicator light will illuminate when any cooktop element is hot, even after it has been turned off. This light will remain on until the surface has cooled to a safe temperature.
- **Warm Zone:** Use the dedicated 'Warm Zone' element to keep cooked foods warm.

5.2. Oven Operation

The oven offers various cooking modes and features for precise temperature control.

- **Bake:** Press the 'Bake' button, then use the '+' or '-' buttons to set the desired temperature. Press 'Start' to begin preheating.
- **Broil:** Press the 'Broil' button, select 'Hi' or 'Lo' broil, then press 'Start'.
- **Timer:** Press 'Timer On/Off' and use the '+' or '-' buttons to set the desired countdown time.
- **Set Clock:** Press 'Set Clock' and use the '+' or '-' buttons to adjust the time.
- **Oven Light:** Press 'Oven Light' to turn the interior oven light on or off.
- **Cook Time:** Use this feature to set a specific cooking duration. The oven will turn off automatically after the set time.
- **Delay Time (Automatic Oven):** This feature allows you to set a future time for the oven to start cooking. Place food in the oven, set the desired cook time and temperature, then set the delay start time. The oven will automatically begin cooking at the programmed time.

6. Maintenance

Regular cleaning and maintenance will help ensure the longevity and optimal performance of your range.

- **Cooktop Cleaning:** For the glass cooktop, use a ceramic cooktop cleaner and a non-abrasive pad. Wipe spills immediately after the surface cools to prevent staining.
- **Oven Cleaning:** The oven features a 'Self Clean' option. Follow the instructions in the full manual for proper use of this cycle. For light cleaning, wipe the interior with a damp cloth and mild detergent once the oven has cooled.
- **Stainless Steel Surfaces:** Clean stainless steel surfaces with a soft cloth and a stainless steel cleaner. Always wipe in the direction of the grain.
- **Storage Drawer:** The bottom drawer can be used for storing pans and cookie sheets. Keep it clean and free of debris.

7. Troubleshooting

If you encounter issues with your range, refer to the following common troubleshooting tips. For more complex problems, consult a qualified service technician.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Range does not operate	Power outage; circuit breaker tripped; range not properly plugged in.	Check household fuses/circuit breakers. Ensure range is securely plugged into the outlet.
Cooktop element not heating	Control knob not set correctly; element malfunction.	Ensure knob is turned to a heat setting. If issue persists, contact service.
Oven not heating	Oven controls not set correctly; 'Delay Time' activated.	Verify bake/broil settings and 'Start' button pressed. Check if 'Delay Time' is active.
Oven light not working	Bulb needs replacement.	Replace the oven light bulb (refer to full manual for bulb type and replacement instructions).

8. Specifications

Key specifications for the Frigidaire 30 in. 5 Burner Element Freestanding Electric Range:

- **Product Dimensions:** 25.75 x 29.88 x 46.56 inches
- **Item Model Number:** 310575855
- **Weight:** 148 Pounds
- **Manufacturer:** Frigidaire
- **Material:** Stainless Steel
- **Finish Type:** Brushed
- **Drawer Type:** Storage
- **Included Components:** Range

9. Warranty and Support

For detailed warranty information and customer support, please refer to the warranty card included with your appliance or visit the official Frigidaire website. You may also contact Frigidaire customer service directly for assistance with product registration, service requests, or technical inquiries.
Online Support: www.frigidaire.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B085LNPRS6

More documents and user manuals: **https://manuals.plus/**