Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Campingaz 3000005968

User Manual for CAMPINGAZ Master 3 LX Gas Plancha

Model: 3000005968

Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your CAMPINGAZ Master 3 LX Gas Plancha. Please read this manual thoroughly before assembly and use, and retain it for future reference.
The CAMPINGAZ Master 3 LX Gas Plancha is designed for outdoor cooking, featuring advanced Blue Flame technology for optimal heat distribution and an Instastart ignition system for ease of use. Its enameled cast iron cooking surface ensures excellent cooking results.

Important Safety Information

Always follow basic safety precautions when using gas appliances. Failure to do so may result in serious injury or property damage.

- For outdoor use only. Do not operate indoors.
- Ensure adequate ventilation.
- Keep children and pets away from the appliance during operation.
- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- Always check for gas leaks before each use.
- Use only the type of gas and gas cylinder specified by the manufacturer.
- Do not obstruct the flow of combustion and ventilation air.
- Wear protective gloves when handling hot surfaces.

Product Components

The CAMPINGAZ Master 3 LX Gas Plancha includes the following main components:

- Enameled Cast Iron Cooking Plate (73 x 40 cm)
- Stainless Steel Frame and Lid with Hinges
- Three Blue Flame Burners (9 kW total power)

- InstaStart Ignition System (integrated into control knobs, requires 1 AA battery)
- Adjustable Feet
- Integrated Handles for Transport
- Side Grease Collection Tray



Image: Front view of the CAMPINGAZ Master 3 LX Gas Plancha with its stainless steel lid open, revealing the enameled cast iron cooking plate and control knobs.



Image: The CAMPINGAZ Master 3 LX Gas Plancha in use, with various foods such as fish, shrimp, and vegetables cooking on its large enameled cast iron surface.

Setup and Assembly

The CAMPINGAZ Master 3 LX Gas Plancha requires minimal assembly. Follow these steps for initial setup:

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for potential future transport or storage.
2. **Placement:** Place the plancha on a stable, non-combustible, level surface outdoors. Ensure adequate clearance from combustible materials.
3. **Adjusting Height:** Use the adjustable feet to level the plancha and achieve a comfortable cooking height. The cooking surface can be tilted slightly to facilitate grease drainage into the side collection tray.
4. **Gas Connection:** Connect the gas regulator to the gas cylinder and then to the plancha's gas inlet. Ensure all connections are tight. Perform a leak test before first use and after every gas cylinder change.
5. **Battery Installation:** Install one AA battery into the Instastart ignition system compartment, typically located near the control knobs.



Image: Close-up view of the control panel of the CAMPINGAZ Master 3 LX Gas Plancha, showing the three control knobs with integrated Instastart ignition.

Operating Instructions

Pre-Use Check

- Ensure the gas cylinder is connected securely and the gas supply is open.
- Verify that the grease collection tray is correctly positioned.
- Perform a leak test if the gas cylinder has been changed or if connections have been disturbed.

Ignition (InstaStart System)

1. Open the gas supply valve on the gas cylinder.
2. Push in and turn one of the control knobs counter-clockwise to the high flame position.
3. The Instastart system will automatically generate a spark to ignite the burner.
4. Once ignited, release the knob. If the burner does not ignite within 5 seconds, turn the knob to the OFF position, wait 5 minutes, and repeat the ignition process.
5. Repeat for other burners as needed. The backlit knobs indicate when gas is flowing.

Cooking

- Allow the plancha to preheat for 5-10 minutes to reach desired cooking temperature. The Blue Flame technology ensures rapid and even heat distribution.
- Adjust the control knobs to regulate the heat for different cooking zones.
- Place food directly on the enameled cast iron cooking surface.
- The inclined cooking surface helps drain excess grease and juices into the collection tray, promoting healthier

cooking.

Shutting Down

1. Turn all control knobs to the OFF position.
2. Close the gas supply valve on the gas cylinder.
3. Allow the plancha to cool completely before cleaning or covering.



Image: Top-down view of the three Blue Flame burners of the CAMPINGAZ Master 3 LX Gas Plancha, showing the micro-flame ramps for even heat distribution.

Care and Maintenance

Regular cleaning and maintenance will extend the life of your plancha and ensure optimal performance.

After Each Use

- **Cleaning the Cooking Plate:** Once the plate has cooled slightly but is still warm, scrape off any food residue using a suitable scraper. The enameled surface is easy to clean. Wipe with a damp cloth and mild detergent if necessary. Avoid abrasive cleaners.
- **Emptying Grease Tray:** Remove and empty the side grease collection tray. Clean it with warm, soapy water.
- **Exterior Cleaning:** Wipe down the stainless steel frame and lid with a damp cloth.

Periodic Maintenance

- **Burner Inspection:** Periodically inspect the burners for blockages or damage. Clean any debris from the burner ports.
- **Gas Hose and Regulator:** Check the gas hose and regulator for cracks, cuts, or excessive wear. Replace if damaged.
- **Storage:** When not in use, especially for extended periods, store the plancha in a dry, protected area. The stainless steel lid provides protection for the cooking surface.

Troubleshooting

Problem	Possible Cause	Solution
Burner does not ignite.	No gas flow, clogged burner, faulty ignition, empty battery.	Check gas cylinder and connections. Clean burner ports. Replace AA battery. Try manual ignition with a long lighter.
Uneven heating.	Clogged burner ports, low gas pressure.	Clean burner ports. Ensure gas cylinder is not low.
Excessive flare-ups.	Excess grease buildup, high heat setting.	Clean cooking surface and grease tray regularly. Reduce heat.
Gas smell.	Gas leak.	Immediately turn off gas supply. Perform a leak test with soapy water. Do not use until leak is resolved. Contact qualified service personnel if unable to resolve.

Technical Specifications

Feature	Specification
Model Number	3000005968
Brand	Campingaz
Cooking Surface Material	Double Enameled Cast Iron
Cooking Surface Area	3600 cm^2 (73 x 40 cm)
Burners	3 Blue Flame Burners
Total Power	9 kW
Gas Consumption	660 g/h
Ignition System	InstaStart (integrated, requires 1 AA battery)
Lid Material	Stainless Steel
Dimensions (L x D x H)	79 x 49 x 22 cm
Weight	32 kg

Warranty Information

The CAMPINGAZ Master 3 LX Gas Plancha comes with a 10-year warranty, as indicated in the product title. Please refer to the specific warranty terms and conditions provided at the time of purchase or on the official Campingaz website for full details regarding coverage and claims.
This warranty typically covers defects in materials and workmanship under normal use and service. It does not cover damage resulting from misuse, abuse, accidents, unauthorized repairs, or lack of proper maintenance.

Customer Support

For technical assistance, spare parts, or warranty claims, please contact Campingaz customer service. You can find contact information on the official Campingaz website or through your local retailer.

When contacting support, please have your product model number (3000005968) and purchase date readily available.
Website: www.campingaz.com

© 2025 Campingaz. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B085N47WVK

More documents and user manuals: **https://manuals.plus/**