Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Geepas GCR6059

Geepas GCR6059 60x60 Freestanding Gas Cooker - User Manual

Model: GCR6059 | Brand: Geepas

1. Important Safety Information

Please read this manual carefully before using your Geepas GCR6059 gas cooker. Keep it for future reference. Incorrect installation, adjustment, alteration, service, or maintenance can cause injury or property damage. Consult a qualified installer, service agency, or the gas supplier for assistance.

- Ensure proper ventilation when operating the appliance.
- Do not store flammable materials near the cooker.
- Keep children away from the appliance during operation.
- Always use oven mitts when handling hot items.
- Do not use water on grease fires; smother the fire or use a dry chemical or foam-type extinguisher.
- Ensure the gas supply is turned off if the appliance is not in use for an extended period.

2. Setup and Installation

The Geepas GCR6059 is a freestanding gas cooker designed for household use. Professional installation is highly recommended for gas appliances to ensure safety and proper function.

2.1 Unpacking

Carefully remove all packaging materials. Check the appliance for any damage incurred during transit. Report any damage immediately to your retailer.

2.2 Positioning

Place the cooker on a flat, stable surface. Ensure adequate clearance from adjacent walls and cabinets as specified by local regulations. The dimensions of the unit are approximately 60 x 60 x 85 cm (Width x Depth x Height).



Image: Side view of the Geepas GCR6059 gas cooker, showing its freestanding design.

2.3 Gas Connection

Gas connection must be performed by a qualified and authorized technician in accordance with all local and national gas safety regulations. Ensure the correct type of gas is used for your appliance.

2.4 Electrical Connection

If your model includes an electric ignition or oven light, connect the appliance to a properly grounded electrical outlet. Refer to the rating label for voltage and frequency requirements.

3. Operating the Cooktop

The cooktop features four gas burners with heavy-duty cast iron grates, providing a strong and flexible cooking surface.

3.1 Ignition

1. Place your cookware on the burner grate.
2. Push and turn the corresponding control knob counter-clockwise to the maximum flame setting.
3. Simultaneously press the ignition button (if applicable) or use a match/lighter to ignite the burner.
4. Once the flame is lit, hold the knob for a few seconds before releasing to ensure the flame remains stable.
5. Adjust the flame size by turning the knob between the maximum and minimum settings.



Image: A hand demonstrating how to adjust a control knob on the gas cooker's front panel.

3.2 Using Cookware

Use cookware appropriate for the burner size. The heavy-duty cast iron grates allow for easy movement of pots and pans across the cooktop without lifting.



Image: A pot placed on one of the gas burners, illustrating cooktop usage.

4. Operating the Oven

The large capacity oven is suitable for baking, roasting, and grilling, featuring a double glass oven door for improved insulation.

4.1 Oven Functions

- **Baking/Roasting:** Use the main oven function for general cooking. Turn the oven control knob to the desired temperature.
- **Grill Function:** The appliance includes a grill function, allowing you to grill chicken, lamb, and other items in the lower part of the oven. Select the grill setting on the control knob.



Image: The oven door of the Geepas GCR6059 gas cooker is open, revealing food cooking inside.

4.2 Mechanical Timer

The mechanical timer allows you to set a cooking duration. Manually set the desired time, and the oven will automatically stop operation when the set time is reached. This helps prevent overcooking and saves energy.

5. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your gas cooker.

5.1 General Cleaning

- Always ensure the appliance is cool and disconnected from the power and gas supply before cleaning.
- The modern stainless steel surface is easy to clean. Use a soft cloth with mild detergent and warm water. Avoid abrasive cleaners or scouring pads that can scratch the surface.
- Clean the cast iron grates and burner caps regularly. They can often be washed with warm soapy water.

5.2 Oven Cleaning

For oven interiors, use specialized oven cleaners following the product instructions. Ensure all cleaner residue is removed before using the oven again.

5.3 Glass Lid

After use, you can lower the glass lid to protect the cooktop and keep it clean. Clean the glass lid with a glass cleaner or warm soapy water.

6. Troubleshooting

If you encounter issues with your Geepas GCR6059, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Burner does not ignite	No gas supply, clogged burner, faulty igniter	Check gas valve. Clean burner ports. Contact service technician.
Oven not heating	Gas supply issue, faulty igniter/element, incorrect setting	Verify gas supply. Ensure oven knob is set correctly. Contact service technician.
Uneven cooking in oven	Improper rack placement, oven not preheated, faulty thermostat	Use recommended rack positions. Allow full preheat. Contact service technician.
Gas odor	Gas leak	Immediately turn off gas supply, open windows, do not operate electrical switches, evacuate and call gas company/emergency services.

For issues not listed here or if solutions do not resolve the problem, please contact Geepas customer support or a qualified service technician.

7. Specifications

Key technical details for the Geepas GCR6059 Freestanding Gas Cooker:

- **Brand:** Geepas
- **Model:** GCR6059
- **Product Dimensions (W x D x H):** 60 x 60 x 85 cm
- **Item Weight:** 40 kg
- **Installation Type:** Freestanding
- **Hob Type:** Gas, 4 Burners
- **Oven Capacity:** Large
- **Oven Features:** Grill Function, Mechanical Timer, Double Glass Door
- **Control Type:** Metal Knobs
- **Material:** Stainless Steel (housing), Glass (lid, oven door), Cast Iron (grates)
- **Color:** Silver, Black
- **Included Components:** Warranty Card, User Manual

8. Warranty and Support

This Geepas GCR6059 gas cooker comes with a **1-year manufacturer warranty**. Please refer to the included warranty card for detailed terms and conditions.

For technical support, service requests, or to inquire about spare parts, please contact Geepas customer service. Contact details can typically be found on the warranty card or the official Geepas website.

Always provide your model number (GCR6059) and purchase date when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0861B6633

More documents and user manuals: **https://manuals.plus/**