Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lexus LS 460/LS 460L

2016 Lexus LS 460/LS 460L Owner's Manual

Your comprehensive guide to operating and maintaining your Lexus vehicle.

Introduction

This owner's manual contains detailed information about the operation, features, and maintenance of your 2016 Lexus LS 460 or LS 460L. To ensure safe and proper use of your vehicle, please read this manual thoroughly and keep it in your vehicle for future reference. All information in this manual is current at the time of printing.

Safety Information

Always prioritize safety when operating your vehicle. Familiarize yourself with all safety features and warnings. Failure to follow safety instructions can result in serious injury or death.

Important Safety Precautions:

- Always wear your seatbelt and ensure all passengers are properly restrained.
- Never drive under the influence of alcohol or drugs.
- Observe all traffic laws and speed limits.
- Maintain a safe distance from other vehicles.
- Regularly check tire pressure and fluid levels.

Getting Started

Before driving your Lexus LS 460/LS 460L, take time to understand its basic controls and features.

Vehicle Entry and Ignition:

1. **Unlocking Doors:** Use the smart key system or remote control to unlock the doors.
2. **Adjusting Seating Position:** Adjust the driver's seat, steering wheel, and mirrors for optimal driving posture and

visibility.

3. **Starting the Engine:** With your foot on the brake pedal, press the ENGINE START/STOP button.

Dashboard Overview:

Familiarize yourself with the instrument cluster, warning lights, and infotainment system. Consult the detailed diagrams in your physical manual for specific locations of each indicator.

Operating the Vehicle

This section covers the primary functions and driving characteristics of your Lexus.

Driving Controls:

- **Transmission:** The LS 460/LS 460L features an automatic transmission. Select 'P' for Park, 'R' for Reverse, 'N' for Neutral, and 'D' for Drive.
- **Braking System:** The vehicle is equipped with an anti-lock braking system (ABS) and electronic brake-force distribution (EBD).
- **Steering:** Power-assisted steering provides precise control.

Infotainment System:

Your vehicle includes a sophisticated infotainment system. Refer to the dedicated multimedia manual for detailed instructions on navigation, audio, and connectivity features.

Climate Control:

The automatic climate control system allows you to set and maintain desired cabin temperatures. Adjust fan speed, temperature, and air distribution using the controls on the center console.

Maintenance

Regular maintenance is crucial for the longevity, performance, and safety of your Lexus LS 460/LS 460L.

Scheduled Maintenance:

Follow the maintenance schedule outlined in your Warranty and Services Guide. This typically includes:

- Oil and filter changes
- Tire rotation and inspection
- Brake system inspection
- Fluid level checks (coolant, brake fluid, power steering fluid, windshield washer fluid)
- Air filter replacement

Owner Checks:

Perform these checks regularly:

- Check tire pressure weekly.
- Inspect exterior lights for proper operation.
- Monitor warning lights on the dashboard.

Troubleshooting

This section addresses common issues you might encounter and provides basic solutions.

Engine Will Not Start:

- **Check Battery:** Ensure battery terminals are clean and tight. If the battery is dead, jump-start the vehicle according to instructions in your manual.
- **Check Fuel Level:** Confirm there is sufficient fuel in the tank.
- **Immobilizer System:** Ensure you are using the correct key.

Warning Light Illuminated:

- **Check Engine Light:** If this light illuminates, it indicates a potential issue with the engine or emissions system. It is recommended to have the vehicle inspected by a qualified technician.
- **Tire Pressure Warning:** Check and adjust tire pressures to the recommended levels.
- **Brake System Warning:** If this light comes on, safely pull over and contact Lexus Roadside Assistance or a service center immediately.

For more complex issues, consult a certified Lexus service technician.

Specifications

Key technical specifications for the 2016 Lexus LS 460 and LS 460L.

Feature	LS 460	LS 460L
Engine Type	4.6L V8	4.6L V8
Horsepower	386 hp	386 hp
Transmission	8-speed automatic	8-speed automatic
Fuel Tank Capacity	22.2 gal (approx.)	22.2 gal (approx.)
Seating Capacity	5	4 or 5

Note: Specific figures may vary based on trim level and optional equipment. Refer to your vehicle's documentation for precise details.

© 2016 Lexus. All rights reserved. This manual is for informational purposes only.
For further assistance, please contact your authorized Lexus dealer or visit the official Lexus website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B086D2J7M1

More documents and user manuals: **https://manuals.plus/**