Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Café CTD90FP2NS1

Cafe CTD90FP2NS1 30" Professional French Door Smart Double Wall Oven User Manual

Model: CTD90FP2NS1

Introduction

This manual provides essential instructions for the safe and efficient operation, installation, and maintenance of your Cafe CTD90FP2NS1 30" Professional French Door Smart Double Wall Oven. Please read all instructions thoroughly before using the appliance.

Important Safety Information

Always follow basic safety precautions when using this appliance to reduce the risk of fire, electric shock, or injury.

- Ensure proper installation by a qualified technician.
- Do not store flammable materials in or near the oven.
- Keep children away from the appliance during operation.
- Use oven mitts when handling hot items.
- Disconnect power before servicing.

Setup and Installation

Unpacking

Carefully remove all packaging materials, tape, and protective film from the oven. Retain packaging for future transport if needed.

Electrical Requirements

This electric double wall oven requires a dedicated, properly grounded electrical circuit. Consult a qualified electrician for installation to ensure compliance with local codes and safety standards.

Wall Mount Installation

The oven is designed for wall-mount installation. Refer to the separate installation guide for detailed instructions on cabinet cutout dimensions, securing the oven, and electrical connections.



Figure 1: Angled view of the Cafe CTD90FP2NS1 double wall oven, showcasing its stainless steel finish and French door design.

Initial Cleaning

Before first use, wipe the interior and exterior surfaces with a damp cloth and mild detergent. Remove any protective coatings or stickers.

Wi-Fi Connect Setup

To utilize smart features, connect your oven to your home Wi-Fi network.

1. Download the Cafe Appliances app on your smartphone or tablet.
2. Follow the in-app instructions to add your new oven.
3. The oven's display will guide you through the connection process.



Figure 2: Close-up of the oven's smart display, showing the "Precision Cooking" menu with options for various food types. This interface is used for Wi-Fi setup and smart cooking functions.

Operating Instructions

Basic Oven Functions

Your oven offers various cooking modes accessible via the touch display.

- **Bake:** For general baking of cakes, cookies, and casseroles.
- **Broil:** For searing, toasting, or quick browning.
- **Convection Bake/Roast:** Uses a fan to circulate hot air for even cooking and faster results.
- **Hot Air Frying:** A specialized convection mode for crisping foods with minimal oil.



Figure 3: The interior of the oven with food on baking trays, demonstrating the "Hot Air Frying" function selected on the display.

French Door Operation

The upper oven features French doors. To open, pull either handle. Both doors will open simultaneously. To close, push both doors until they latch securely.

Smart Features and Precision Cooking

Through the Wi-Fi Connect app and the oven's display, you can access advanced features like Precision Cooking, which automatically adjusts time and temperature for optimal results based on food type. You can also monitor and control the oven remotely.

Sabbath Mode

Sabbath Mode allows the oven to operate for an extended period with specific settings to comply with religious observances. Refer to the full manual for detailed instructions on activating and using Sabbath Mode.

Timer Function

The oven includes a programmable timer for cooking duration and a kitchen timer for general use. Access these functions via the touch display.

Maintenance and Cleaning

Self-Cleaning Cycle

The oven features a self-cleaning function. Remove all racks and large food debris before starting a self-clean cycle. Follow the prompts on the display to initiate. The oven will lock during the cycle and unlock automatically when complete and cooled.

General Cleaning

- **Exterior Surfaces:** Use a soft cloth and mild soap or a stainless steel cleaner. Avoid abrasive cleaners.
- **Interior (non-self-clean areas):** Wipe with a damp cloth and mild detergent.
- **Oven Racks:** Clean with warm, soapy water. For heavily soiled racks, a non-abrasive scouring pad may be used.

Door Care

Do not use harsh abrasives or sharp metal scrapers to clean the oven door glass as they can scratch the surface, which may result in shattering.

Troubleshooting

Before contacting service, review the following common issues and solutions.

Problem	Possible Cause	Solution
Oven not heating	Power supply issue; incorrect mode selected.	Check circuit breaker. Ensure oven is plugged in. Verify cooking mode.
Display not responding	Temporary software glitch; power interruption.	Turn off power at the circuit breaker for 5 minutes, then restore.
Wi-Fi connection issues	Router issues; incorrect password; oven too far from router.	Restart router. Re-enter Wi-Fi password in app. Ensure strong signal.
Self-clean cycle not starting	Oven door not fully closed; racks not removed.	Ensure door is latched. Remove all racks and accessories.

For issues not listed or if problems persist, contact Cafe customer support.

Specifications

Feature	Detail
Brand	Café
Model Name	CTD90FP2NS1
Size	30 inches
Capacity	10 cubic feet (Total)
Heating Method	Convection
Fuel Type	Electric
Installation Type	Wall Mount
Finish Type	Stainless Steel
Door Orientation	French Door (Upper Oven), Drop-Down (Lower Oven)
Additional Features	Self-cleaning, Wi-Fi, Smart Features, Sabbath Mode, Timer Function
Item Dimensions (D x W x H)	26.75"D x 53"H (Width is typically 30" for a 30" oven, but not explicitly stated in D x W x H, only size)

Feature	Detail
UPC	084691842187

Warranty and Support

Warranty Information

Your Cafe CTD90FP2NS1 oven comes with a limited warranty. Please refer to the warranty card included with your appliance or visit the official Cafe Appliances website for detailed terms and conditions. Keep your proof of purchase for warranty claims.

Customer Support

For technical assistance, service scheduling, or to order parts, please contact Cafe customer support.

- **Website:** www.cafeappliances.com/support
- **Phone:** Refer to the contact information provided in your appliance documentation.

© 2023 Cafe Appliances. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B086H1GZC2

More documents and user manuals: **https://manuals.plus/**