Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun MQ5237

Braun MultiQuick 5 MQ 5237 BK Immersion Blender

Model: MQ5237 | 1000W Power

Introduction

Thank you for choosing the Braun MultiQuick 5 MQ 5237 BK Immersion Blender. This versatile kitchen appliance is designed to simplify your food preparation tasks with its powerful 1000W motor and a range of useful attachments. This manual provides essential information for safe operation, assembly, use, and maintenance of your new appliance. Please read these instructions carefully before first use and keep them for future reference.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- To protect against electric shock, do not place the motor unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or is dropped or damaged in any manner.
- The use of attachments not recommended or sold by Braun may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter.
- Do not let cord contact hot surfaces, including the stove.
- Blades are sharp. Handle carefully.
- Always ensure the appliance is properly assembled before use.
- Do not process extremely hot liquids without allowing them to cool slightly.

Product Components

The Braun MultiQuick 5 MQ 5237 BK comes with several components designed for various kitchen tasks:



Figure 1: All components of the Braun MultiQuick 5 MQ 5237 BK Immersion Blender, including the motor unit, blending shaft, whisk, 500ml chopper, and 600ml beaker.

- **Motor Unit:** The main body containing the 1000W motor, speed selector (21 speeds), and turbo button.
- **Blending Shaft (PowerBell Plus):** Stainless steel shaft with unique bell shape and extended cutting area for efficient blending and splash control.
- **Whisk Attachment:** For whipping cream, beating eggs, and mixing light batters.
- **500 ml Chopper:** For chopping herbs, nuts, cheese, and small quantities of meat.
- **Masher Attachment:** Specifically designed for mashing cooked vegetables like potatoes for smooth purees.
- **600 ml Beaker:** A BPA-free plastic measuring cup with ml and floz markings, suitable for blending and measuring.

Assembly and Setup

The Braun MultiQuick 5 features the EasyClick system for quick and easy attachment changes.



Figure 2: Demonstrates how to attach the blending shaft to the motor unit by aligning and twisting until it clicks into place.

1. **Attaching the Blending Shaft:** Align the blending shaft with the motor unit and twist clockwise until it clicks securely into place. To detach, twist counter-clockwise and pull apart.
2. **Attaching the Whisk:** Insert the whisk into the whisk gear box, then attach the gear box to the motor unit using the EasyClick system as described above.
3. **Assembling the Chopper:** Place the chopper blade onto the center pin of the chopper bowl. Place the chopper lid onto the bowl, ensuring it locks securely. Then, attach the motor unit to the chopper lid, twisting until it clicks.
4. **Attaching the Masher:** Insert the masher shaft into the masher gear box, then attach the gear box to the motor unit using the EasyClick system.

Before first use, clean all parts that will come into contact with food as described in the 'Cleaning and Maintenance' section.

Operating Instructions

The MultiQuick 5 features a 21-speed selector and a turbo function for optimal control.



Figure 3: Proper grip on the motor unit, showing the ergonomic design and button placement for easy control.

General Operation:

- Plug the appliance into a power outlet.
- Select the desired speed using the 21-speed selector wheel on top of the motor unit. Start with lower speeds for delicate tasks and increase as needed.
- Press and hold the power button to operate. For maximum power, press the turbo button.
- Release the button to stop the appliance.

Using the Immersion Blender:



Figure 4: The immersion blender in action, smoothly blending ingredients directly in a cooking pot, demonstrating its versatility for soups and sauces.



Figure 5: The immersion blender being used with the included beaker to prepare a fruit smoothie, highlighting its effectiveness for beverages.

- Attach the blending shaft to the motor unit.
- Immerse the blending shaft into the ingredients. The unique PowerBell Plus design and SplashControl technology minimize splashing.
- Move the blender up and down gently to ensure all ingredients are processed evenly.
- Ideal for soups, sauces, purees, and smoothies.

Using the Whisk:

- Attach the whisk to the motor unit.
- Use for whipping cream, beating egg whites, or mixing light batters.
- Start at a low speed and gradually increase to avoid splashing.

Using the Chopper (500 ml):

- Assemble the chopper blade in the bowl and attach the motor unit.
- Suitable for chopping herbs, onions, garlic, nuts, hard cheese, and small amounts of meat.
- Use short pulses for coarse chopping, or continuous operation for finer results. Do not overload.

Using the Masher Attachment:

- Attach the masher to the motor unit.
- Use for mashing cooked vegetables such as potatoes, carrots, or sweet potatoes.
- Ensure vegetables are soft and cooked through for best results.

Cleaning and Maintenance

Proper cleaning ensures the longevity and hygiene of your appliance.

- **Motor Unit:** Wipe with a damp cloth only. Do not immerse in water or any other liquid.
- **Blending Shaft, Whisk, Chopper Bowl, Chopper Lid, Masher, Beaker:** These parts are dishwasher safe. Alternatively, they can be washed by hand in hot soapy water.
- **Chopper Blade:** Handle with extreme care as the blades are very sharp. Wash by hand.
- Always unplug the appliance before cleaning.
- Store the appliance and its accessories in a dry place.

Troubleshooting

If you encounter issues with your Braun MultiQuick 5, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet faulty; attachment not correctly assembled.	Check power connection; try another outlet; ensure attachment is clicked securely into place.
Motor stops during operation.	Overload protection activated; ingredients too tough.	Unplug, reduce quantity of ingredients, allow motor to cool for a few minutes before restarting.
Poor blending/chopping results.	Too little liquid; ingredients too large; incorrect speed setting.	Add more liquid; cut ingredients into smaller pieces; adjust speed or use turbo function.
Excessive vibration or noise.	Attachment not properly secured; damaged part.	Re-attach component securely; if problem persists, contact customer support.

Specifications

Detailed technical specifications for the Braun MultiQuick 5 MQ 5237 BK Immersion Blender:



Figure 6: Illustrates the approximate dimensions of the Braun MultiQuick 5 Immersion Blender, showing a height of 40 cm for the main unit and blending shaft.

- **Brand:** Braun
- **Model Number:** MQ5237
- **Color:** Black
- **Power:** 1000 Watts
- **Voltage:** 240 Volts
- **Number of Speeds:** 21 (variable speed control) + Turbo function
- **Product Dimensions (L x W x H):** Approximately 18.8 x 36.6 x 26.2 cm
- **Item Weight:** Approximately 2 Kilograms
- **Material:** Plastic (motor unit), Stainless Steel (blending shaft, blades)
- **Noise Level:** 44 dB
- **Special Feature:** Automatic stop

- **Included Components:** Motor unit, blending shaft, whisk, 500 ml chopper, 600 ml beaker, masher attachment.

Warranty and Support

Braun products are manufactured to high-quality standards. For specific warranty information, please refer to the warranty card included with your purchase or contact Braun customer service in your region. Spare parts for this model are generally available for up to 2 years from the date of purchase.
For technical support, service, or to order spare parts, please visit the official Braun website or contact their authorized service centers. Always provide the model number (MQ5237) when seeking support.

© 2023 Braun. All rights reserved. MultiQuick is a registered trademark of Braun GmbH.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B086HY8QM2

More documents and user manuals: **https://manuals.plus/**