Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BRAUN FP3132BK

Braun PureEase Food Processor FP3132BK

User Instruction Manual

1. Introduction

This manual provides essential information for the safe and efficient operation of your Braun PureEase Food Processor FP3132BK. Please read all instructions carefully before first use and retain this manual for future reference. This appliance is designed for household use only.
The Braun PureEase Food Processor is a versatile kitchen appliance with an 800-watt motor, designed to simplify food preparation tasks such as chopping, blending, kneading, and grinding.

2. Important Safety Instructions

- Read all instructions before using the appliance.
- Always ensure the appliance is unplugged from the power outlet before assembling, disassembling, or cleaning.
- Keep hands and utensils away from moving blades or discs while processing food to prevent injury. Use a spatula only when the appliance is not running.
- Do not process hot liquids in the blender or food processor bowl, as this may cause pressure buildup and result in scalding.
- Ensure all parts are correctly assembled and the safety lock is engaged before operating the appliance.
- Do not immerse the motor unit in water or any other liquid. Clean with a damp cloth only.
- This appliance is not intended for use by children or persons with reduced physical, sensory, or mental capabilities unless supervised or instructed by a responsible adult.
- Do not use attachments not recommended or sold by the manufacturer, as this may cause fire, electric shock, or injury.
- Avoid contact with moving parts.
- Never leave the appliance unattended while it is operating.

3. Parts and Features

Your Braun PureEase Food Processor FP3132BK comes with several components designed for various food preparation tasks.



Image Description: The Braun PureEase Food Processor system, showcasing the main food processor unit with a bowl filled with chopped vegetables, a blender jug with ingredients, and various accessories including blades, discs, and a spatula.

- **Motor Unit:** The base of the appliance containing the 800-watt motor and control panel.
- **Food Processor Bowl (2.1 Liters):** For chopping, slicing, shredding, and kneading.
- **Blender Jug (1.2 Liters):** For blending liquids, smoothies, and purees.
- **Lid with Feeder Tube and Pusher:** For adding ingredients safely during operation.
- **Chopping Blade:** For general chopping tasks.
- **Dough/Kneading Tool:** For mixing and kneading dough.
- **Whipping/Blending Tool:** For whipping cream or blending light mixtures.
- **Slicing/Shredding Disc:** Reversible disc for slicing and shredding vegetables.
- **Multi Mill:** A smaller attachment for grinding spices, coffee beans, or chopping small quantities.
- **Spatula:** For scraping ingredients from the bowl.



Image Description: An overhead view of all the Braun PureEase Food Processor components, including the motor base, food processor bowl, blender jug, various blades, discs, and the spatula, arranged neatly on a surface.

4. Setup and Assembly

Follow these steps to assemble your food processor for use:

1. **Place the Motor Unit:** Position the motor unit on a clean, stable, and dry surface. Ensure it is unplugged.
2. **Attach the Bowl/Jug:**
    - For the food processor: Place the food processor bowl onto the motor unit, aligning the handle with the safety lock mechanism. Turn clockwise until it locks securely.
    - For the blender: Place the blender jug onto the motor unit, aligning it correctly and turning clockwise until it locks.
3. **Insert the Blade/Accessory:** Place the desired blade (chopping, kneading, whipping) or disc (slicing/shredding) onto the central shaft inside the bowl/jug. Ensure it is seated properly.



Image Description: The main food processor unit of the Braun PureEase, showing the motor base, the clear processing bowl, and the lid with the feeder tube. This illustrates the primary setup for food processing tasks.

4. **Secure the Lid:** Place the lid onto the bowl/jug, aligning the tab on the lid with the handle. Turn clockwise until it locks into place. The appliance will not operate unless the lid is correctly locked.
5. **Insert Pusher:** Place the pusher into the feeder tube of the lid.
6. **Multi Mill Assembly:** For the multi mill, attach the blade unit to the mill cup, then invert and place onto the motor unit, twisting to lock.

5. Operating Instructions

The Braun PureEase Food Processor features 2 speeds and a pulse function for precise control.

5.1. Food Processor Functions (Chopping, Slicing, Shredding, Kneading)

1. Assemble the food processor bowl with the desired blade or disc as described in Section 4.
2. Add ingredients to the bowl. For chopping, cut large ingredients into smaller, uniform pieces. For slicing/shredding, feed ingredients through the feeder tube.
3. Secure the lid and pusher.
4. Plug in the appliance.
5. Select the desired speed (1 or 2) or use the pulse function (P) for short bursts.
6. Process until the desired consistency is achieved. Do not over-process.
7. Unplug the appliance before disassembling and removing processed food.



Image Description: The Braun PureEase Food Processor with its bowl containing freshly chopped tomatoes, cucumbers, and herbs, demonstrating its chopping capability. A multi-mill attachment is visible next to it.



Image Description: A woman is shown using the Braun PureEase Food Processor to grate carrots, feeding them through the chute into the processing bowl. Various fresh vegetables are on the counter nearby.

5.2. Blender Functions

1. Assemble the blender jug onto the motor unit.
2. Add ingredients to the blender jug. Do not exceed the maximum fill line.
3. Secure the lid.
4. Plug in the appliance.
5. Select the desired speed (1 or 2) or use the pulse function (P) for short bursts.
6. Blend until smooth.
7. Unplug the appliance before disassembling and pouring out contents.



Image Description: The Braun PureEase Blender unit, showing the motor base with the clear blender jug attached, ready for blending tasks.

5.3. Multi Mill Functions (Grinding, Small Chopping)

1. Assemble the multi mill with its blade unit.
2. Add small quantities of ingredients (e.g., coffee beans, spices, nuts) to the mill cup.
3. Invert the assembled multi mill and place it onto the motor unit, twisting to lock.
4. Plug in the appliance.
5. Use the pulse function (P) or speed 1 for short bursts until desired consistency is reached.
6. Unplug the appliance before carefully removing the multi mill.



Image Description: The Braun PureEase Food Processor with the multi-mill attachment in place on the motor base, ready for grinding or small chopping tasks.



Image Description: A woman is observing the Braun PureEase Food Processor with the multi-mill attachment, which appears to be processing dry ingredients like nuts or spices.

6. Maintenance and Cleaning

Proper cleaning ensures the longevity and hygiene of your appliance.

1. **Always Unplug:** Before cleaning, ensure the appliance is unplugged from the power outlet.
2. **Disassemble:** Carefully disassemble all removable parts (bowls, jugs, lids, blades, discs, multi mill).
3. **Clean Removable Parts:** Wash all removable parts in warm, soapy water. Rinse thoroughly and dry immediately. Most removable parts are dishwasher safe (refer to specific instructions for temperature limits if available). Handle blades with extreme care as they are very sharp.
4. **Clean Motor Unit:** Wipe the motor unit with a damp cloth. Do not immerse the motor unit in water or any other liquid. Do not use abrasive cleaners or scouring pads.
5. **Storage:** Store the cleaned and dried appliance and its accessories in a safe, dry place.

7. Troubleshooting

Problem	Possible Cause	Solution
Appliance does not start.	Not plugged in; bowl/lid not correctly assembled; safety lock not engaged.	Ensure power cord is securely plugged in. Check that the bowl/jug and lid are correctly locked into position.
Motor stops during operation.	Overload protection activated; ingredients too large/hard.	Unplug, remove some ingredients, or cut them into smaller pieces. Allow the motor to cool down for 15-20 minutes before restarting.
Food is not processed evenly.	Too many ingredients; ingredients not cut uniformly.	Process smaller batches. Cut ingredients into similar sizes. Use the pulse function for better control.
Leakage from bowl/jug.	Lid not properly sealed; overfilling.	Ensure the lid is securely locked. Do not exceed the maximum fill line.

8. Specifications

- **Brand:** BRAUN
- **Model Number:** FP3132BK
- **Power / Wattage:** 800 Watts
- **Voltage:** 220 Volts
- **Food Processor Bowl Capacity:** 2.1 Liters
- **Blender Jug Capacity:** 1.2 Liters
- **Number of Speeds:** 2 + Pulse
- **Material (components):** Stainless Steel (blades/discs)
- **Special Features:** Safety Lock
- **Product Dimensions:** 19D x 23W x 38H centimeters
- **Item Weight:** 3 Kilograms



Image Description: A diagram showing the dimensions of the Braun PureEase Food Processor, indicating a height of 38cm, width of 23cm, and depth of 19cm.

9. Warranty and Support

Your Braun PureEase Food Processor FP3132BK comes with an international warranty. Please refer to the warranty card included in your packaging for specific terms and conditions, including the warranty period and coverage details. For technical support, service, or to inquire about replacement parts, please contact your local Braun service center or the retailer from whom you purchased the product. Keep your proof of purchase for warranty claims.
Extended warranty options may be available from third-party providers. For example, 1-Year and 2-Year Extended Warranties by Salama Care are offered for this product.

© 2025 BRAUN. All rights reserved.
Product Model: FP3132BK

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B086Q435F4

More documents and user manuals: **https://manuals.plus/**