Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ROCKPOINT 58inch Barn Door TV Stand

ROCKPOINT 58-inch Barn Door TV Stand Entertainment Media Console - Grey Wash User Manual

Brand: ROCKPOINT | Model: 58inch Barn Door TV Stand

1. Product Overview

The ROCKPOINT 58-inch Barn Door TV Stand is a versatile entertainment media console designed with an industrial and farmhouse aesthetic. Measuring 58 inches in length, 15.4 inches in width, and 25 inches in height, this unit provides ample storage and display space for your living area. Its grey wash finish complements various interior designs.

Key Features:

- **Industrial & Farmhouse Design:** Features traditional barn door sliding cabinet fronts with X-shaped accents, creating an elegant and rustic ambiance.
- **Sliding Barn Doors with Cable Holes:** Two barn doors slide smoothly on a metal rail, allowing flexible access to storage or display. Integrated cable management cutouts in the back help maintain a clutter-free space.
- **Ample Storage:** A spacious tabletop accommodates up to a 65-inch TV. Each cabinet includes an adjustable shelf, ideal for storing cable boxes, DVDs, game consoles, and other audio-visual equipment.
- **Durable Structure:** Constructed from high-grade MDF and durable laminate, ensuring longevity and stability. Can be used as a TV stand, buffet, or storage console.
- **Easy Assembly:** Designed for straightforward assembly, recommended for two people.

2. Safety Information

WARNING: This product requires proper assembly to ensure stability and safety. Keep away from children to prevent injury from small parts or sharp edges. Do not overload shelves to prevent tip-over. Always follow the manufacturer's instructions for safe use and maintenance.

- Always place the TV stand on a flat, level surface.
- Do not exceed the maximum weight capacity for the top surface or shelves.
- Ensure all screws and fasteners are securely tightened during assembly and periodically check for

looseness.
- Keep small parts and assembly tools out of reach of children.

3. Package Contents

Before beginning assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, please contact customer support.

- All necessary wood panels (top, bottom, sides, shelves, doors, back panel).
- Hardware pack (screws, dowels, cam locks, hinges, handles, sliding rail components).
- Assembly instructions manual.

4. Assembly Instructions

Please read all instructions carefully before assembly. Two people are recommended for easier and safer assembly.

1. **Prepare the Area:** Clear a spacious, clean, and level area for assembly. Lay out all components and hardware.
2. **Assemble Side Panels:** Attach the bottom panel to the side panels using the provided dowels and cam locks. Ensure they are securely fastened.
3. **Install Center Supports:** Insert the vertical center support panels into the pre-drilled holes on the bottom panel and secure them.
4. **Attach Shelves:** Place the adjustable shelves into the desired positions within the open compartments.
5. **Install Top Panel:** Carefully align and attach the top panel to the assembled structure using dowels and cam locks.
6. **Assemble Barn Doors:** Attach the handles to the barn doors. Install the sliding rail mechanism to the top of the unit and hang the barn doors according to the specific hardware instructions.
7. **Attach Back Panel:** Secure the back panel to the unit using small nails or screws. Ensure cable management holes are aligned.
8. **Final Check:** Verify all connections are tight and the unit is stable.



Figure 1: Assembled ROCKPOINT 58-inch Barn Door TV Stand.



Figure 2: TV Stand with barn doors open, showcasing interior storage.

5. Operating Instructions

Using the Barn Doors:

The barn doors are designed to slide smoothly along the top rail. Gently grasp the handle and slide the door left or right to reveal or conceal the central shelving compartments or the side cabinets. Avoid forcing the doors if they encounter resistance.



Figure 3: Close-up of a barn door handle.

Adjusting Shelves:

The interior shelves in the side cabinets are adjustable. To change the shelf height, remove any items from the shelf, lift the shelf, and reposition the shelf pins into the desired holes. Ensure all four pins are securely in place before placing items back on the shelf.

Cable Management:

Utilize the pre-drilled cable management cutouts on the back panel to route and organize power cords and audio/video cables. This helps keep wires tidy and out of sight, contributing to a cleaner aesthetic.

▶ **Watch video online**
Rockpoint - 58 inch Barn Door TV Stand / Media Console

Video 1: Official product video demonstrating the ROCKPOINT 58-inch Barn Door TV Stand, highlighting its features and design.

6. Maintenance

Care and Cleaning:

To maintain the appearance and longevity of your TV stand, wipe it with a dry cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the laminate finish. For stubborn spots, a slightly damp cloth followed by a dry cloth can be used. Ensure no moisture is left on the surface.

7. Troubleshooting

Common Issues and Solutions:

- **Wobbly Stand:** Ensure all cam locks and screws are fully tightened. Check that the stand is on a level surface. Adjust furniture levelers if applicable.
- **Doors Not Sliding Smoothly:** Inspect the sliding rail for any obstructions or debris. Ensure the doors are properly seated on the rail. Lubricate the rail lightly if necessary.
- **Damaged or Missing Parts:** If you encounter damaged or missing parts during assembly, do not proceed. Contact ROCKPOINT customer support immediately for assistance.
- **Surface Scratches:** Minor scratches can sometimes be touched up with a furniture repair marker that matches the grey wash finish.

8. Specifications

Attribute	Value
Brand	ROCKPOINT
Model	58inch Barn Door TV Stand
Color	Grey Wash
Item Dimensions (L x W x H)	58 x 15.4 x 25 inches
Item Weight	74 Pounds
Material Type	Engineered Wood
Shape	Rectangular
Required Assembly	Yes
Product Care Instructions	Wipe with Dry Cloth
Manufacturer	HONGXING
UPC	680270761285



Figure 4: Product Dimensions.

9. Warranty and Customer Support

For warranty information, missing parts, or any product-related inquiries, please contact ROCKPOINT customer support directly. Refer to the packaging or the official ROCKPOINT website for contact details.

Always retain your proof of purchase for warranty claims.

© 2023 ROCKPOINT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B086X11SZQ

More documents and user manuals: **https://manuals.plus/**