Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEXiBOOK RL800NI

LEXiBOOK Super Mario Nightlight Alarm Clock RL800NI

Instruction Manual

Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your LEXiBOOK Super Mario Nightlight Alarm Clock, Model RL800NI. This device combines timekeeping, alarm functions, a nightlight, and interactive Super Mario sound effects to enhance your daily routine.



Figure 1: Front view of the Super Mario Nightlight Alarm Clock.

Safety Information

- **Recommended Age:** This product is suitable for users aged 3 years and up.
- **Battery Safety:** Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Insert batteries with correct polarity. Remove exhausted batteries promptly.
- **Placement:** Place the alarm clock on a stable, flat surface away from direct sunlight, heat sources, and moisture.
- **Cleaning:** Use a soft, dry cloth for cleaning. Do not use abrasive cleaners or immerse the unit in water.

Setup

1. Battery Installation

1. Locate the battery compartment on the underside of the alarm clock.
2. Using a small screwdriver, open the battery compartment cover.
3. Insert 3 x AA / LR6 batteries (not included), ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery compartment cover and secure it with the screw.

A low battery indicator will appear on the LCD screen when batteries need replacement.



Figure 2: Rear view with battery compartment and control buttons.

Operating Instructions

1. Setting the Time

- Press and hold the **TIME SET** button (often marked with a clock icon) located on the back of the unit until the hour digits flash.
- Use the **+** and **-** buttons on the front to adjust the hour.
- Press the **TIME SET** button again to switch to minute adjustment.
- Use the **+** and **-** buttons to adjust the minutes.
- Press the **TIME SET** button once more to confirm and exit time setting mode.

2. Setting the Alarm

- Press and hold the **ALARM SET** button (often marked with a bell icon) located on the back of the unit until the alarm hour digits flash.
- Use the **+** and **-** buttons to adjust the alarm hour.
- Press the **ALARM SET** button again to switch to alarm minute adjustment.
- Use the **+** and **-** buttons to adjust the alarm minutes.
- Press the **ALARM SET** button once more to confirm and exit alarm setting mode.
- To activate or deactivate the alarm, briefly press the **ALARM SET** button. An alarm icon will appear/disappear on the display.

3. Adjusting Alarm Volume and Ringtones

- While in alarm setting mode (after setting the time), you may be able to cycle through available Super Mario inspired ringtones using the **+** or **-** buttons.
- The alarm volume is adjustable. Refer to the specific button on your unit, often combined with the **+** or **-** buttons during alarm setup, or a dedicated volume button.

4. Snooze Function and Stopping the Alarm

- When the alarm sounds, press the top of the clock (Mario character) to activate the snooze function. The alarm will temporarily stop and sound again after a few minutes.
- To completely stop the alarm, press the top of the clock (Mario character) again or press the **ALARM SET** button.

5. Nightlight and Backlit Screen

- The LCD screen is backlit for easy readability in low light conditions.
- The clock features a luminous nightlight function. This may be activated by pressing the top of the clock (Mario character) or a dedicated button.



Figure 3: Nightlight feature in a dark environment.

6. Super Mario Sound Effects

- Press the button marked with a question mark block (often on the front left) to play various Super Mario sound effects, such as jumps and coin sounds.

Maintenance

Cleaning

To clean the alarm clock, use a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the unit. Ensure the unit is off and batteries are removed before cleaning.

Battery Replacement

Replace the batteries when the low battery indicator appears on the LCD screen or when the display becomes dim or functions become erratic. Follow the battery installation steps outlined in the Setup section.

Troubleshooting

- **Clock not turning on / Display blank:** Check if batteries are inserted correctly with proper polarity. Replace with fresh AA/LR6 batteries.
- **Alarm not sounding:** Ensure the alarm is activated (alarm icon visible on display). Check the alarm time setting. Verify battery level.
- **Sound effects not playing:** Check battery level. Ensure the sound effects button is pressed firmly.
- **Incorrect time display:** Reset the time following the instructions in the Operating section.

Specifications

Feature	Detail
Brand	LEXiBOOK
Model Number	RL800NI
Display Type	Digital LCD
Power Source	3 x AA / LR6 Batteries (not included)
Dimensions (H x W x D)	18.2 cm x 13.5 cm x 9 cm (approx. 7.17" x 5.31" x 3.54")
Weight	250 Grams (approx. 8.8 ounces)
Material	Acrylonitrile Butadiene Styrene (Plastic)
Special Features	Alarm, LCD Backlit Screen, Snooze Function, Super Mario Sound Effects, Adjustable Alarm Volume
Recommended Age	3 years and up

Warranty and Support

No specific warranty information or direct support contact details are provided within this manual. For warranty claims or technical assistance, please refer to the product packaging or contact the retailer where the product was purchased. You may also visit the official LEXiBOOK website for further information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B087V742Y5

More documents and user manuals: **https://manuals.plus/**