Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Geepas GSB44073N

Geepas Portable Rechargeable Juicer

Model: GSB44073N

Introduction

Welcome to the user manual for your Geepas Portable Rechargeable Juicer, Model GSB44073N. This guide provides essential information for the safe and efficient operation, maintenance, and care of your new juicer. Please read these instructions thoroughly before first use and retain them for future reference.

Safety Instructions

To ensure safe operation and prevent damage, please observe the following safety precautions:

- Always ensure the blending cup is securely attached and the safety lock is engaged before starting the juicer. The juicer will not operate if the safety lock is not correctly positioned.
- Do not immerse the motor base in water or any other liquid. Clean the motor base with a damp cloth only.
- Keep the appliance out of reach of children.
- Do not overfill the blending cup. The maximum capacity is 300ml.
- Avoid blending extremely hot liquids, as this can create pressure and cause injury.
- Do not operate the juicer when empty.
- Use only the provided charging cable.
- Do not attempt to disassemble or repair the juicer yourself. Contact qualified service personnel for assistance.

Product Overview

Your Geepas Portable Rechargeable Juicer consists of the following main components:

- **Motor Base:** Contains the powerful 50W copper motor and rechargeable battery.
- **Blending Cup:** 300ml capacity cup for ingredients.
- **Lid with Safety Lock:** Features integrated stainless steel blades and a safety mechanism.
- **Power Button:** Located on the lid for operation.
- **Charging Port:** For recharging the internal battery.



Figure 1: Disassembled view of the juicer, showing the lid and blending cup.

Setup

Before using your juicer for the first time, follow these steps:

1. Unpack all components from the packaging.
2. Wash the blending cup and lid (including the blades) thoroughly with warm, soapy water. Rinse well and dry. The motor base should only be wiped with a damp cloth.
3. Ensure the juicer's battery is fully charged. Connect the charging cable to the charging port on the motor base and plug it into a suitable power source. The indicator light will show charging status.



Figure 2: The juicer ready for use with fresh ingredients.

Operating Instructions

Follow these steps to prepare your juice or smoothie:

1. **Prepare Ingredients:** Cut fruits and vegetables into small pieces (approximately 1-2 cm). Place the prepared ingredients into the blending cup.
2. **Add Liquid:** Add water, milk, or other liquids. Ensure the total volume of ingredients and liquid does not exceed the 300ml maximum fill line on the cup.
3. **Assemble the Juicer:** Invert the motor base and securely attach the blending cup by twisting it clockwise until it locks into place. Ensure the safety lock mechanism is fully engaged.
4. **Start Blending:** Place the assembled juicer upright. Double-click the power button on the lid to start the blending cycle. The blades will begin to rotate.
5. **Optimize Blending:** For best results, gently shake the juicer during operation to ensure all ingredients come into contact with the blades.

6. **Automatic Stop:** The juicer will automatically stop after approximately 40 seconds.
7. **Re-blend (if needed):** If the desired consistency is not achieved after one cycle, you can double-click the power button again to initiate another blending cycle.
8. **Enjoy:** Once blending is complete, open the lid and pour your fresh juice or smoothie.



Figure 3: Double-clicking the power button to start blending.



Figure 4: Blended smoothie in the juicer cup.

Cleaning and Maintenance

Regular cleaning ensures hygiene and extends the life of your juicer:

1. **Quick Clean:** After use, pour clean water into the blending cup, filling it approximately halfway.
2. **Add Soap:** Add a small amount of dish soap to the water.
3. **Blend for Cleaning:** Secure the lid with the safety lock engaged. Double-click the power button to run the blender for a few seconds (or one full 40-second cycle). This will clean the inside of the cup and blades.
4. **Rinse:** Pour out the soapy water and rinse the blending cup and lid thoroughly with clean warm water.
5. **Dry:** Allow all parts to air dry completely before reassembling or storing.

Important Notes:

- While the portable blender is designed to be waterproof, it is **not recommended** to wash it in a dishwasher. Hand washing is preferred to maintain its integrity.

- Do not use abrasive cleaners or scouring pads, as these can scratch the surfaces.
- Always ensure the charging port is dry before connecting the charging cable.

Troubleshooting

If you encounter any issues with your juicer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Juicer does not start.	Safety lock not engaged. Battery is low or depleted.	Ensure the blending cup is securely twisted onto the motor base and the safety lock is correctly aligned. Charge the juicer fully.
Poor blending results or ingredients are stuck.	Ingredients are too large. Insufficient liquid. Overfilling the cup.	Cut ingredients into smaller pieces. Add more liquid. Do not exceed the 300ml fill line. Gently shake the juicer during operation.
Juicer stops unexpectedly.	Normal 40-second cycle completion. Overload protection activated.	This is normal operation. Double-click to restart if further blending is needed. Reduce ingredient load and ensure sufficient liquid.

Specifications

Key technical specifications for the Geepas Portable Rechargeable Juicer GSB44073N:

- **Brand:** Geepas
- **Model Number:** GSB44073N
- **Capacity:** 300 ml
- **Power:** 50 Watts
- **Voltage:** 240 Volts
- **Material:** Stainless Steel (blades), other parts (cup, lid) are durable plastic.
- **Dimensions (Product):** Approximately 11 cm (Depth) x 11 cm (Width) x 20.5 cm (Height)
- **Weight:** Approximately 2.8 Kilograms
- **Special Features:** Portable, Rechargeable, Safety Lock, Automatic 40-second stop.
- **Number of Speeds:** 1
- **Power Source:** Battery Powered
- **Included Components:** Warranty Card, User Manual

Warranty and Support

Your Geepas Portable Rechargeable Juicer GSB44073N comes with a manufacturer's warranty.

- **Warranty Period:** Two (2) years from the date of purchase.
- Please retain your proof of purchase for warranty claims.
- For warranty service or technical support, please refer to the contact information provided on your warranty card or visit the official Geepas website.

© 2024 Geepas. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B088CLHZ2K

More documents and user manuals: **https://manuals.plus/**