Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GTMEDIA i8S Plus

GTMEDIA i8S Plus 2.4G Mini Wireless Keyboard with Touchpad Backlight Instruction Manual

Model: i8S Plus

1. Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your GTMEDIA i8S Plus 2.4G Mini Wireless Keyboard with Touchpad Backlight. This compact device combines a QWERTY keyboard, a multi-touch touchpad, and multimedia control keys, designed for use with various devices such as PCs, laptops, smart TVs, Android TV boxes, and projectors.

2. Package Contents

Please check the package for the following items:

- 1x GTMEDIA i8S Plus 2.4G Wireless Keyboard
- 1x USB Wireless Receiver
- 1x Lithium Battery (BL-5C 380mAh, removable)
- 1x USB Charging Cable
- 1x User Manual



Image: Contents of the GTMEDIA i8S Plus package, including the keyboard, USB receiver, battery, charging cable, and user manual.

3. Product Overview

The GTMEDIA i8S Plus features a full QWERTY keyboard and a high-sensitive touchpad. Familiarize yourself with the layout and functions of the keys and indicators.



Image: Labeled diagram of the GTMEDIA i8S Plus keyboard, highlighting the power switch, home page, return, navigation, left mouse click, keyboard, touchpad, media controls, mute, browse, and menu buttons.

Key Features:

- **2.4GHz Wireless Connectivity:** Provides a stable connection up to 10 meters.
- **77-Key QWERTY Keyboard:** Full keyboard layout for efficient typing.
- **High-Sensitive Touchpad:** Supports multi-touch gestures and adjustable DPI.
- **RGB Backlight:** Three selectable backlight colors for use in low-light conditions.
- **Multimedia Control Keys:** Dedicated keys for media playback and system functions.
- **Rechargeable Battery:** Built-in BL-5C 380mAh lithium battery.
- **Automatic Sleep/Wake:** Power-saving feature to extend battery life.

4. Setup Instructions

Follow these steps to set up your GTMEDIA i8S Plus keyboard:

1. **Charge the Keyboard:** Before first use, fully charge the keyboard using the provided USB charging cable. Connect the cable to the keyboard's charging port and a USB power source (e.g., computer USB port, USB wall adapter). The charging indicator will light up.
2. **Locate the USB Receiver:** The USB wireless receiver is stored inside the battery compartment of the keyboard.

Open the battery cover on the back of the keyboard to retrieve it.

3. **Insert the USB Receiver:** Plug the USB receiver into an available USB port on your device (PC, laptop, smart TV, etc.).
4. **Power On the Keyboard:** Slide the power switch on the side of the keyboard to the "ON" position.
5. **Automatic Connection:** The keyboard should automatically connect to your device. No additional drivers are typically required.



Image: Visual guide for initial setup, showing the USB receiver being removed from the battery compartment, plugged into a laptop, and the keyboard being switched on.

▶ **Watch video online**

Basic operation of i8+ wireless keyboard

Video: This video demonstrates the basic operation of the GTMEDIA i8+ wireless keyboard, including unboxing, connecting the USB receiver, and using the keyboard and touchpad functions. While the video shows the i8+ model, the basic setup and operation principles are similar for the i8S Plus.

5. Operating Instructions

5.1. Touchpad Gestures

The touchpad supports various gestures for easy navigation:

- **Single Finger Tap:** Left mouse click.
- **Two Fingers Drag:** Scroll screen (up/down).
- **Three Fingers Click:** Right mouse click.



Image: Illustration of touchpad gestures: one finger for left click, two fingers for scrolling, and three fingers for right click.

5.2. Combination Keys (i8S Plus Specific)

Use the **Fn** key in combination with other keys for special functions:

- **Fn + '**: Open/Close Backlight.

- **Fn + RGB**: Switch backlight colors (Red, Green, Blue).
- **Fn + Sliding touchpad**: Customize backlight color (slide finger across the bottom edge of the touchpad).
- **Fn + Space**: Adjust mouse movement speed (DPI).
- **Fn + Alt**: Open/Close Touchpad function.
- **Fn + RF**: Activation key (for initial pairing or re-pairing if connection is lost).



Image: The GTMEDIA i8S Plus keyboard displaying its three primary backlight colors: green, blue, and red.

5.3. Compatibility

The keyboard is compatible with a wide range of operating systems and devices:

- **Operating Systems:** Windows 2000, XP, Vista, Windows CE, Windows 7, Android, Linux (Debian-3.1, Redhat-9.0, Ubuntu-8.10, Fedora-7.0 tested), Mac OS X, Android 3.0 and above.
- **Compatible Devices:** HD player, Set-top box, Android TV box, Netbook, PC, Smart Mobile Phone, Projector, Laptop, Smart TV.



Image: The GTMEDIA i8S Plus keyboard shown with various compatible devices, including computers, Android TV boxes, smart TVs, laptops, and HTPCs, illustrating its "One For All" plug-and-play functionality.

6. Specifications

Feature	Detail
Model	i8S Plus
Connectivity Technology	2.4GHz Radio Frequency (RF)
Operating Voltage	3.7V
Charge Voltage	4.4V ~ 5.25V
TX Power	Less than +5dBm
Reception Range	Up to 10 meters (MAX)

Keyboard Layout	77-key QWERTY
Special Features	Backlight (RGB 3 colors), Touchpad (DPI adjustable, multi-touch), Hotkeys, Media keys
Battery Type	Built-in BL-5C 380mAh Lithium Battery (rechargeable, removable)
Product Dimensions	5.98 x 4.02 x 0.51 inches (152mm x 102mm x 13mm)
Item Weight	5.6 ounces



Image: The GTMEDIA i8S Plus keyboard with its dimensions clearly marked in both millimeters and inches.

7. Troubleshooting

If you encounter issues with your GTMEDIA i8S Plus keyboard, refer to the following common solutions:

- **Keyboard not responding:**
  - Ensure the keyboard is powered on.
  - Check if the battery is charged. Connect the charging cable and try again.

- Verify the USB receiver is securely plugged into your device.
- Try plugging the USB receiver into a different USB port.
- Re-pair the keyboard by pressing **Fn + RF**.

- **Touchpad not working:**
  - Ensure the touchpad is not disabled. Press **Fn + Alt** to toggle the touchpad function.
  - Clean the touchpad surface if it's dirty.
- **Backlight not working or changing colors:**
  - Press **Fn + "** to turn the backlight on/off.
  - Press **Fn + RGB** to cycle through colors.
  - For custom colors, use **Fn + Sliding touchpad** (slide finger across the bottom edge).
- **Short battery life:**
  - Ensure the keyboard is fully charged.
  - The keyboard has an automatic sleep function. If it's not sleeping, ensure no keys are being pressed inadvertently.
  - Reduce backlight brightness or turn it off when not needed to conserve battery.
- **Poor wireless range:**
  - Ensure there are no large metallic objects or other 2.4GHz wireless devices interfering with the signal between the keyboard and the USB receiver.
  - Try moving the USB receiver to a more open location or closer to the keyboard. The maximum reception range is 10 meters.

8. Maintenance

To ensure the longevity and optimal performance of your keyboard:

- Keep the device dry. Avoid exposure to moisture or liquids.
- Do not expose the device to extreme temperatures.
- Clean the keyboard and touchpad regularly with a soft, dry cloth. Avoid harsh chemicals.
- Store the USB receiver inside the battery compartment when not in use to prevent loss.
- Charge the battery regularly, even if not in frequent use, to maintain battery health.

9. Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official GTMEDIA website. Keep your proof of purchase for warranty claims.

GTMEDIA i8S Plus User Manual © 2024. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why do the keys on my GTMEDIA i8S Plus keyboard not correspond to what is indicated on the keycaps?

If the keys on your GTMEDIA i8S Plus do not match what is being typed on your screen, it is usually due to a mismatch between the keyboard's physical layout and the input language...

Read full answer

Open the live page

https://manuals.plus/asin/B088R1D8BM

More documents and user manuals: **https://manuals.plus/**