Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MINISO IK633 (White and Pink)

MINISO Wireless Keyboard and Mouse Combo User Manual

Model: IK633 (White and Pink)

Brand: MINISO

1. Introduction

This manual provides comprehensive instructions for the MINISO Wireless Keyboard and Mouse Combo, Model IK633. Please read this manual carefully before using the product to ensure proper operation and to maximize its lifespan. This combo offers a comfortable and efficient input solution for various computing needs.

Key Features:

- **Ergonomic and Slim Design:** The keyboard features an ergonomic tilt angle for comfortable typing, while the contoured wireless mouse provides hours of comfortable use with a sweat-resistant, skin-friendly finish.
- **Quiet Operation:** Noise-reduction keys on the keyboard and silent clicks on the mouse minimize disturbance to your surroundings.
- **Quick Wireless Connection:** Simple plug-and-play setup with a single USB receiver for both the keyboard and mouse, requiring no software installation.
- **Adjustable DPI Mouse:** The optical mouse offers three adjustable DPI levels (800/1200/1600) for fast and precise cursor control on various surfaces.
- **Power Saving Features:** Both the keyboard and mouse include automatic sleep mode and on/off switches to conserve battery life.

2. Package Contents

Upon opening the package, please verify that all items listed below are present and in good condition:

- 1 x MINISO Wireless Keyboard (White and Pink)
- 1 x MINISO Wireless Mouse (White and Pink)
- 1 x USB Nano Receiver (stored inside the mouse battery compartment)
- 1 x User Manual (this document)



Image: The MINISO Wireless Keyboard and Mouse Combo, showing the white keyboard with pink keys and the matching white and pink mouse.



Image: The retail packaging for the MINISO Wireless Keyboard and Mouse Set, indicating the product is a combo.

3. Setup Guide

Follow these steps to set up your MINISO Wireless Keyboard and Mouse Combo:

1. **Install Batteries:**
    - For the mouse: Open the battery compartment cover on the underside of the mouse. Insert the required battery (typically 1x AA, not included) ensuring correct polarity (+/-). Close the cover.
    - For the keyboard: Open the battery compartment cover on the underside of the keyboard. Insert the required batteries (typically 2x AAA, not included) ensuring correct polarity (+/-). Close the cover.



Image: The bottom view of the MINISO wireless mouse, showing the battery compartment and the slot for the USB nano receiver.

2. **Locate the USB Nano Receiver:** The USB nano receiver is typically stored inside the mouse's battery compartment for safekeeping during transport. Carefully remove it.
3. **Connect the Receiver:** Plug the USB nano receiver into an available USB port on your computer (desktop, laptop, etc.).
4. **Power On:**
    - For the mouse: Locate the ON/OFF switch on the underside of the mouse and slide it to the "ON" position.
    - For the keyboard: Locate the ON/OFF switch on the underside of the keyboard and slide it to the "ON" position.
5. **Automatic Connection:** The keyboard and mouse should automatically connect to your computer within a few seconds. No additional drivers or software installation are required for most operating systems (Windows, macOS, Linux, Chrome OS).

4. Operating Instructions

4.1 Keyboard Usage

The MINISO Wireless Keyboard functions like a standard QWERTY keyboard. It includes multimedia function keys (F1-F12) that can be accessed by pressing the **Fn** key in combination with the desired function key.



Image: A close-up view of the MINISO wireless keyboard, highlighting the layout and key design.

Multimedia Functions (Fn + F-keys):

Key Combination	Function
Fn + F1	Media Player
Fn + F2	Volume Down
Fn + F3	Volume Up
Fn + F4	Mute
Fn + F5	Previous Track

Key Combination	Function
Fn + F6	Next Track
Fn + F7	Play/Pause
Fn + F8	Stop
Fn + F9	Home Page
Fn + F10	Email
Fn + F11	My Computer
Fn + F12	Calculator

4.2 Mouse Usage and DPI Adjustment

The MINISO Wireless Mouse provides smooth and precise tracking. It features adjustable DPI (Dots Per Inch) settings, allowing you to change the cursor sensitivity to suit your preference.



Image: Two MINISO wireless mice, showcasing their ergonomic shape and silent click design.

Adjusting DPI:

To change the DPI setting, press the DPI button located on the top of the mouse, usually behind the scroll wheel. Each press will cycle through the available DPI levels:

- **800 DPI:** Slower cursor movement, ideal for precise tasks like graphic design.
- **1200 DPI:** Standard cursor movement, suitable for general use.
- **1600 DPI:** Faster cursor movement, ideal for quick navigation or gaming.

The mouse will remember your last selected DPI setting even after being turned off.

5. Maintenance and Care

Proper maintenance ensures the longevity and optimal performance of your MINISO Wireless Keyboard and Mouse Combo.

5.1 Cleaning

- Use a soft, dry, lint-free cloth to wipe down the surfaces of the keyboard and mouse.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaning solution. Avoid excessive moisture.
- Do not spray cleaners directly onto the devices.
- Avoid using harsh chemicals, solvents, or abrasive cleaners, as they may damage the finish.

5.2 Battery Replacement

When the keyboard or mouse performance degrades (e.g., delayed response, erratic cursor movement), it may be time to replace the batteries.

- Refer to Section 3.1 "Install Batteries" for instructions on how to open the battery compartments and replace the batteries.
- Always use new batteries of the specified type (AA for mouse, AAA for keyboard).
- Dispose of old batteries responsibly according to local regulations.

5.3 Storage

If you plan not to use the combo for an extended period, it is recommended to:

- Turn off both the keyboard and mouse using their respective ON/OFF switches.
- Remove the batteries to prevent leakage, which can damage the devices.
- Store the USB nano receiver inside the mouse's battery compartment.
- Store the devices in a cool, dry place away from direct sunlight and extreme temperatures.

6. Troubleshooting

If you encounter issues with your MINISO Wireless Keyboard and Mouse Combo, please refer to the following common solutions:

Problem	Possible Cause	Solution
Keyboard/Mouse not responding	Low or dead batteries.	Replace batteries in both the keyboard and mouse.
	Devices are turned off.	Ensure the ON/OFF switches on both devices are in the "ON" position.
	USB receiver not properly connected.	Unplug the USB receiver and plug it back into a different USB port on your computer.
	Interference from other wireless devices.	Move the keyboard and mouse closer to the USB receiver. Avoid placing the receiver near large metal objects.
Erratic mouse cursor movement	Dirty optical sensor.	Clean the optical sensor on the underside of the mouse with a soft, dry cloth.
	Using the mouse on an unsuitable surface.	Use the mouse on a clean, non-reflective, opaque surface or a mouse pad.
Keyboard keys are sticky or unresponsive	Dirt or debris under the keys.	Gently clean around and under the keys using compressed air or a soft brush.

If the problem persists after trying these solutions, please refer to the Warranty and Support section for further assistance.

7. Product Specifications

Feature	Detail
Brand	MINISO
Model	IK633
Color	White and Pink
Connectivity Technology	USB Wireless (2.4GHz)
Power Source	Batteries (AA for mouse, AAA for keyboard)
Compatible Operating Systems	Windows 7/10, Linux, Chrome OS, Mac OS X (above V10.4)
Special Features	Ergonomic, Portable, Quiet Click, Adjustable DPI
Mouse DPI Levels	800 / 1200 / 1600 DPI
Package Dimensions	38.7 x 14.5 x 4.9 cm (15.2 x 5.7 x 1.9 inches)
Item Weight	610 g (1.34 lbs)

8. Warranty and Support

8.1 Satisfaction Guarantee

MINISO offers a satisfaction guarantee for this product. If you are not 100% satisfied with your purchase, you may be eligible for a full refund. Please refer to your point of purchase or the MINISO official website for detailed return and refund policies.

8.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact MINISO customer support through their official website or the retailer from whom you purchased the product. Please have your product model number (IK633) and purchase details ready when contacting support.

You can visit the official MINISO store on Amazon for more information:MINISO Official Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B089GJHM2L

More documents and user manuals: **https://manuals.plus/**