Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MAXSO B089GLJK9N

MAXSO Vacuum Insulated Food Jar Instruction Manual

Models: 24 oz & 17 oz (Grey)

Introduction Package Contents Product Features Setup Operating Instructions Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for choosing the MAXSO Vacuum Insulated Food Jar. This manual provides essential information for the safe and effective use of your new thermal food containers. Designed for convenience and durability, these food jars keep your meals hot or cold for extended periods, making them ideal for work, school, travel, and outdoor activities.

2. Package Contents

Your MAXSO 2-Pack Soup Thermo set includes the following items:

- One (1) 24 oz Vacuum Insulated Food Jar (Grey)
- One (1) 17 oz Vacuum Insulated Food Jar (Grey)
- One (1) Foldable Soup Spoon
- One (1) User Manual (this document)



Image: The MAXSO 2-pack insulated food jars, showing both sizes and included accessories.

3. Product Features

3.1 Vacuum Insulation Technology

The MAXSO food jars utilize advanced vacuum insulation technology to maintain food temperature. Hot foods stay warm for up to 12 hours, and cold foods remain chilled for up to 24 hours.



Image: Visual representation of the insulation capabilities and material quality.

3.2 Leak-Proof Design with Air Pressure Release

Each food jar features a secure, leak-proof seal to prevent spills and messes in your bag. An integrated air pressure release button simplifies opening, especially after storing hot contents.



Image: Demonstrates the air pressure release button and other design features.

Video: An official seller video demonstrating the features of the MAXSO food jars, including the leak-proof design and ease of use.

3.3 Food-Grade Stainless Steel Construction

Constructed from 18/8 food-grade stainless steel for both interior and exterior, ensuring durability and safety. All plastic and silicone components are BPA-free.



Image: Exploded view highlighting the stainless steel construction and various parts.

3.4 Integrated Foldable Spoon

A convenient foldable soup spoon is included and stores neatly within the lid, eliminating the need to carry separate utensils.

Video: An official seller video showcasing the MAXSO thermos, specifically highlighting the included folding utensils.

3.5 User-Friendly Design Elements

Features include a flexible handle for easy carrying, a scratch-resistant non-slip base for stability, and a wide mouth opening (2.8 inches) for easy filling, eating, and cleaning. The outer lid can also be used as a serving bowl.



Image: Illustrates the wide mouth opening and size comparison of the two food jars.

4. Setup

4.1 Initial Cleaning

Before first use, wash all parts of the food jar and spoon with warm, soapy water. Rinse thoroughly and dry. The food jars are dishwasher safe, but hand washing is recommended for optimal longevity of the seals.

4.2 Pre-Heating for Hot Foods

For best heat retention, pre-heat the food jar by filling it with hot water (not boiling) for 5-10 minutes. Empty the hot water before adding your food.

4.3 Pre-Cooling for Cold Foods

For best cold retention, pre-cool the food jar by filling it with cold water or ice for 5-10 minutes. Empty the cold water/ice before adding your food.

5. Operating Instructions

5.1 Filling with Food

After pre-heating or pre-cooling, fill the food jar with your desired hot or cold food. Ensure not to overfill, leaving enough space for the inner sealing lid.

5.2 Sealing the Jar

1. Place the inner leak-proof sealing lid securely onto the jar, twisting until tight.
2. Attach the outer lid (which doubles as a bowl) by twisting it clockwise until fully sealed.

5.3 Using the Foldable Spoon

To use the foldable spoon, gently pull it out from its storage slot in the inner lid. Unfold it until it locks into place. After use, fold it back and return it to the storage slot.

5.4 Using the Outer Lid as a Bowl

The outer lid is designed to function as a convenient serving bowl. Simply remove it and pour or scoop your food into it.

5.5 Releasing Air Pressure

If the lid is difficult to open, especially after storing hot food, press the small air pressure release button on the inner lid to equalize the pressure before twisting it open.

Video: An official seller video demonstrating the practical use of the food jars for various meals.

6. Maintenance

6.1 Cleaning

The MAXSO food jars are dishwasher safe. However, for optimal care and to prolong the life of the product, hand washing is recommended. Use a soft sponge or brush with warm, soapy water. Ensure all parts, especially the silicone seals, are thoroughly cleaned and dried before reassembly and storage.

6.2 Storage

Store the food jars with lids removed to allow for air circulation and prevent odors. Keep in a dry place.

7. Troubleshooting

7.1 Lid is Difficult to Open

If the lid is too tight, press the air pressure release button on the inner lid to release any vacuum pressure. This should make it easier to twist open.

7.2 Food Not Staying Hot/Cold

- Ensure the jar was properly pre-heated with hot water or pre-cooled with ice/cold water for 5-10 minutes before adding food.
- Verify that both the inner and outer lids are twisted on tightly to create an airtight seal.
- Check the silicone seals for any damage or improper placement.

7.3 Leakage

Check all silicone seals (on the inner lid and around the threads) to ensure they are clean, undamaged, and correctly seated. Make sure both lids are securely tightened.

8. Specifications

Attribute	Detail
Brand	MAXSO
Capacity	17 oz & 24 oz (2-pack)
Color	Grey
Material	18/8 Stainless Steel (Food Grade)
Insulation	Vacuum Insulated (Double Wall)
Hot Retention	Up to 12 Hours
Cold Retention	Up to 24 Hours
Special Features	Leakproof, Sweatproof, Rust Resistant, Scratch-Resistant, Lightweight, Air Pressure Release, Foldable Spoon, Lid Doubles as Bowl
Product Dimensions	9.64"W x 7.87"H (for the set)
Item Weight	2.12 Pounds (for the set)
Care Instructions	Dishwasher Safe, Hand Wash Only

9. Warranty & Support

9.1 Lifetime Warranty

MAXSO is proud to offer a Lifetime Warranty on our Thermo Food Jars. This warranty covers manufacturing defects and ensures your satisfaction with the product. Please retain your proof of purchase.

9.2 Customer Support

For any questions, concerns, or warranty claims, please contact MAXSO customer support through the retailer's platform or visit the official MAXSO website for contact information.

© 2026 MAXSO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B089GLJK9N

More documents and user manuals: **https://manuals.plus/**