**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



### Geepas GWMF71200LCJ

# GEEPAS GWMF71200LCJ Front Loading Washing Machine User Manual

Model: GWMF71200LCJ | Capacity: 7 kg

## 1. Introduction

This manual provides essential information for the safe and efficient operation of your GEEPAS GWMF71200LCJ Front Loading Washing Machine. Please read these instructions carefully before installation, use, and maintenance. Keep this manual for future reference.

## 2. Safety Instructions

To reduce the risk of fire, electric shock, or injury when using your appliance, follow these basic precautions:

- Ensure the appliance is properly grounded.
- Do not operate any appliance with a damaged cord or plug.
- Keep flammable materials away from the appliance.
- Supervise children when the appliance is in use. The child lock feature should be activated to prevent accidental operation.
- Do not wash items that are soiled with cooking oils, gasoline, or other flammable substances.
- Always unplug the appliance before cleaning or performing any maintenance.
- Ensure all transit bolts are removed before first use to prevent excessive vibration.

## 3. Product Overview

The GEEPAS GWMF71200LCJ is a 7 kg front-loading washing machine designed for efficient and thorough cleaning. It features a durable stainless steel drum, an intuitive LED display, and 15 wash programs to suit various fabric types and cleaning needs.




Figure 1: Front view of the GEEPAS GWMF71200LCJ Washing Machine.




Figure 2: GEEPAS 7 KG Fully Automatic Front-Load Washing Machine highlighting its capacity.




Figure 3: The washing machine featuring its front-load design, Baby Care function, and Child Lock capability.




Figure 4: Key specifications of the washing machine including 7kg capacity, 1400 RPM spin speed, 15 programs, and LED display.




Figure 5: Detailed view of the front loading design with the control console and LED display.




Figure 6: The durable stainless steel drum, designed for hygiene and longevity, with the door open.




Figure 7: Illustrates the process of adding detergent and the option to select water temperature for various wash cycles.




Figure 8: The washing machine with its wide-opening door, facilitating easy loading and unloading of laundry.




Figure 9: Summary of product features including energy rating, capacity, spin speed, and number of programs.

## 4. Setup and Installation

Proper installation is crucial for the performance and longevity of your washing machine. It is recommended to have a qualified technician perform the installation.

### 4.1 Unpacking

- Remove all packaging materials.
- **Important:** Locate and remove the four large transit bolts from the rear of the machine. Failure to remove these bolts will cause excessive vibration and potential damage during operation.

### 4.2 Positioning

- Place the washing machine on a firm, level surface.
- Adjust the leveling feet to ensure the machine is stable and does not rock.

### 4.3 Water and Drain Connection

- Connect the water inlet hose to a cold water tap. Ensure connections are tight to prevent leaks.
- Position the drain hose into a standpipe or over the edge of a sink, ensuring it is securely fixed to prevent dislodgement during draining.

### 4.4 Electrical Connection

- Plug the power cord into a grounded electrical outlet (240 Volts).
- Do not use extension cords or adapters.

## 5. Operating Instructions

Follow these steps for a typical wash cycle:

1. **Load Laundry:** Open the door and place clothes loosely into the drum. Do not overload the machine beyond its 7 kg capacity.
2. **Add Detergent:** Pull out the detergent dispenser drawer and add the appropriate amount of detergent and fabric softener to their respective compartments.
3. **Close Door:** Ensure the door is securely closed.
4. **Select Program:** Turn the program selector knob to choose one of the 15 available wash programs. The LED display will show the selected program and estimated time.
5. **Adjust Settings (Optional):** Use the touch control panel to adjust spin speed, temperature, or activate special functions like delay start or Baby Care, if desired.
6. **Start Cycle:** Press the "Pause/Start" button to begin the wash cycle.
7. **Child Lock:** To activate the Child Lock, press and hold the "Temp" and "Program" buttons together for 3 seconds. The control panel will then be locked to prevent accidental changes. Repeat the action to deactivate.
8. **End of Cycle:** The machine will signal when the cycle is complete. Open the door and remove your laundry.

## 6. Washing Programs

The GEEPAS GWMF71200LCJ offers 15 standard wash programs, including:

- **Quick Wash:** For lightly soiled items requiring a fast cycle.
- **Rinse & Spin:** For rinsing and spinning items separately.
- **Delicate:** Gentle wash for sensitive fabrics.

- **Baby Care:** Special program for baby clothes, often with higher temperatures for hygiene.
- **Cotton:** Standard wash for cotton garments.
- **Jeans:** Optimized for denim.
- **Mix:** For mixed loads of different fabric types.
- **Spin Only:** For extracting excess water from clothes.
- **Drain:** To drain water from the drum.
- **Temperature Selection:** Allows adjustment of wash water temperature (e.g., Cold, 20°C, 40°C, 60°C, 90°C).
- **Spin Speed Selection:** Allows adjustment of spin speed up to 1400 RPM.
- **Delay Function:** To postpone the start of a wash cycle.

Refer to the control panel markings for specific program details and recommended usage.

## 7. Maintenance and Cleaning

Regular maintenance ensures optimal performance and extends the lifespan of your washing machine.

### 7.1 Exterior Cleaning

- Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents.

### 7.2 Detergent Dispenser

- Periodically remove and clean the detergent dispenser drawer to prevent residue buildup. Rinse thoroughly under running water.

### 7.3 Drum Cleaning

- Run a hot wash cycle with an empty drum and a washing machine cleaner or a cup of white vinegar to remove odors and residue.

### 7.4 Drain Filter

- Regularly check and clean the drain filter, usually located at the bottom front of the machine, to prevent blockages.

## 8. Troubleshooting

Before contacting customer service, refer to the following common issues and solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| Machine does not start | Power cord unplugged; door not closed properly; child lock activated. | Check power connection; ensure door is latched; deactivate child lock (hold "Temp" and "Program" for 3 seconds). |
| Excessive vibration/noise | Transit bolts not removed; machine not level; uneven load. | **Ensure transit bolts are removed (refer to Setup section);** adjust leveling feet; redistribute laundry inside the drum. |
| Water not draining | Drain hose kinked or blocked; drain filter clogged. | Check drain hose for obstructions; clean the drain filter. |

| Problem | Possible Cause | Solution |
|---|---|---|
| Detergent residue in dispenser | Low water pressure; dispenser clogged. | Check water supply; clean the detergent dispenser. |

## 9. Specifications

| Feature | Detail |
|---|---|
| Brand | Geepas |
| Model Info | GWMF71200LCJ |
| Product Dimensions | 65 x 53 x 85 cm |
| Capacity | 7 Kilograms |
| Max Spin Speed | 1400 RPM |
| Special Features | Child Lock, High Efficiency |
| Color | White |
| Control Console | Touch |
| Standard Cycles | 15 |
| Access Location | Front Load |
| Voltage | 240 Volts |
| Certification | Energy Star |
| Material Type | Stainless Steel (Drum) |
| Item Weight | 63 Kilograms |

## 10. Warranty and Support

Your GEEPAS GWMF71200LCJ Front Loading Washing Machine comes with a **1-year manufacturer warranty**. Please retain your proof of purchase and the included warranty card for any warranty claims.
For technical support, service, or warranty inquiries, please refer to the contact information provided on your warranty card or visit the official Geepas website.
**Included Components:** User Manual, Warranty Card

© 2023 Geepas. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

**Answered questions about this manual**

**How do I fix the 'RF' error symbol on my Geepas GWMF71200LCJ washing machine?**

While the standard manual for the Geepas GWMF71200LCJ does not explicitly list an "RF" error code in its basic troubleshooting table, error codes starting with "F" or containing "R" in similar front-loading machines typically...

**Read full answer**

---

**Open the live page**

**https://manuals.plus/asin/B08CNH5X3W**

More documents and user manuals: **https://manuals.plus/**