Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bushnell Wingman GPS Speaker

Bushnell Wingman GPS Speaker Instruction Manual

Introduction

The Bushnell Wingman GPS Speaker is an innovative device that combines high-quality audio with the convenience of audible GPS distances, specifically designed for golfers. It features BITE magnetic technology for easy attachment to a golf cart and integrates seamlessly with the Bushnell Golf App for enhanced course information.

Key Features:

- High-quality audio output for music and clear audible GPS distances.
- BITE magnetic technology for secure and convenient mounting to golf cart bars.
- Long-lasting rechargeable battery, providing up to 10 hours of operation on a single charge.
- Seamless integration with the Bushnell Golf App, offering full-color aerial views and flyovers of golf course layouts with precise distances.



Figure 1: Front view of the Bushnell Wingman GPS Speaker.

Setup

1. Charging the Device

Before initial use, ensure your Wingman GPS Speaker is fully charged. Connect the device to a power source using the provided charging cable. The integrated rechargeable Lithium-Ion battery offers up to 10 hours of usage.

2. Powering On/Off

To power the device on or off, press and hold the power button ( ) located on the front panel.



Figure 2: The power button and other controls on the Bushnell Wingman.

3. Bluetooth Pairing

To connect your Wingman to a smartphone or other Bluetooth-enabled device:

1. Ensure the Wingman is powered on.
2. Activate Bluetooth on your smartphone.
3. Select "Bushnell Wingman" from the list of available Bluetooth devices.
4. A confirmation sound will indicate successful pairing.

4. Bushnell Golf App Installation

Download the official Bushnell Golf App from your smartphone's app store. This application is essential for accessing full-color aerial views, flyovers of hole layouts, and accurate GPS distances.

For more information and app features, visit the Bushnell Golf App website.

5. Mounting to a Golf Cart

The Wingman is equipped with BITE magnetic technology, allowing it to securely attach to the metal bar of your golf cart for convenient access during play.



Figure 3: The BITE magnetic technology on the back of the Wingman for cart mounting.

Operating Instructions

1. Audio Playback

Once successfully paired via Bluetooth, you can stream audio from your smartphone to the Wingman speaker. Use the volume buttons (**+**/**-**) on the speaker to adjust the audio level. The play/pause button ( ) controls music playback.



Figure 4: Volume and playback controls on the Wingman speaker.

2. Audible GPS Distances

To hear audible Front/Center/Back GPS distances to the green, press the remote button located on the top of the speaker. Ensure the Bushnell Golf App is active and the correct golf course is selected for accurate distance readings.



Figure 5: The remote button on top of the Wingman for audible GPS distances.



Figure 6: The detachable remote control.

Maintenance

Cleaning

To clean your Wingman, gently wipe the exterior with a soft, damp cloth. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the device's finish and internal components.

Storage

When not in use, store the Wingman in a cool, dry environment. Protect it from extreme temperatures, direct sunlight, and high humidity to preserve its battery life and overall functionality.

Water Resistance

The Bushnell Wingman GPS Speaker is rated IPX6 for water resistance. This means it is protected against powerful water jets from any direction. It is suitable for use in light rain or splashes but is **not designed for submersion** in

water.

Troubleshooting

No Power

- Ensure the device is fully charged. Connect it to a power source using the provided charging cable and allow sufficient time for charging.
- Verify that the charging cable and power adapter are functioning correctly.

No Sound

- Check the Bluetooth connection between the Wingman and your smartphone. Re-establish the connection if necessary.
- Ensure the volume is turned up on both the Wingman speaker and your connected audio device.
- Confirm that audio is playing from your source device.

Inaccurate GPS Distances

- Verify that the Bushnell Golf App is open and has successfully loaded the correct golf course.
- Ensure the device has a clear, unobstructed view of the sky to receive a strong GPS signal.
- Check for any available app updates to ensure optimal performance.

Bluetooth Connectivity Issues

- Try unpairing the Wingman from your device's Bluetooth settings and then re-pairing it.
- Ensure no other Bluetooth devices are actively interfering with the signal.
- Restart both the Wingman and your smartphone.

Specifications

Feature	Detail
Brand	Bushnell
Model Name	Wingman
Model Number	361910
Connectivity Technology	Bluetooth
Battery Life	Up to 10 hours
Water Resistance	IPX6
Mounting Type	Tabletop (with BITE magnetic technology)
Supported Satellite Navigation System	GPS
Item Weight	0.92 kg

UPC	029757008015

Warranty Information

The Bushnell Wingman GPS Speaker is covered by a **1-Year limited warranty** from the date of purchase.

This warranty covers defects in materials and workmanship under normal use. For complete details regarding warranty terms, conditions, and how to make a claim, please refer to the official Bushnell website or contact their customer support directly.

Customer Support

Should you require further assistance, have questions about your Bushnell Wingman GPS Speaker, or need technical support, please utilize the following resources:

- Visit the official Bushnell Store on Amazon.
- Explore the Bushnell Golf website for product information, FAQs, and support documentation.
- Refer to the Bushnell Golf App for in-app support and updates.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08D8D73PD

More documents and user manuals: **https://manuals.plus/**