Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEXiBOOK JL1895

Lexibook Cyber Arcade Pocket Handheld Game Console JL1895 User Manual

Model: JL1895 | Brand: LEXiBOOK

Introduction

Welcome to the Lexibook Cyber Arcade Pocket, a portable handheld game console designed for entertainment on the go. This device features 150 built-in 8-bit games, including arcade, logic, and action titles, all displayed on a 1.8-inch (4.5 cm) color LCD screen. Its compact size makes it ideal for travel, and it includes a built-in speaker with adjustable volume. This manual provides essential information for setting up, operating, and maintaining your Cyber Arcade Pocket.

Product Overview



Image 1: Front view of the Lexibook Cyber Arcade Pocket, showing the 1.8-inch color LCD screen displaying a game. The console features red and blue sections with a D-pad, power button, reset button, volume buttons, start button, and action buttons.



Image 2: Angled view of the Lexibook Cyber Arcade Pocket, highlighting its compact design and the game displayed on its screen. The console's buttons and ergonomic shape are visible.



Image 3: A hand holding the Lexibook Cyber Arcade Pocket, demonstrating its small, portable size. The background shows an outdoor setting, emphasizing its suitability for on-the-go use.



Image 4: The Lexibook Cyber Arcade Pocket in its retail packaging, which highlights "150-in-1" games and the "1.8" LCD" screen. The packaging also shows examples of games.

Setup

Battery Installation

The Lexibook Cyber Arcade Pocket requires 3 AAA batteries (not included) for operation.

1. Locate the battery compartment on the back of the console.

2. Using a small screwdriver, carefully open the battery compartment cover.
3. Insert 3 new AAA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery compartment cover and secure it with the screw.

Note: Always use fresh batteries and dispose of old batteries responsibly. Do not mix old and new batteries, or different types of batteries.

Operating Instructions

Power On/Off

- To power on the console, press and hold the **Power button** (usually marked with a circle and a vertical line) located on the top left of the device.
- To power off, press and hold the **Power button** again until the screen turns off.

Game Selection

- Once powered on, the main menu will display a list of available games.
- Use the **D-pad** (directional pad) on the left side of the console to navigate through the game list.
- Press the **Start button** (usually on the top right) or an action button (A or B) to select and launch a game.

Controls

The console features standard gaming controls:

- **D-pad:** For directional movement within games.
- **Action Buttons (A, B):** For in-game actions such as jumping, shooting, or confirming selections.
- **Start Button:** To begin games, pause, or confirm selections.
- **Reset Button:** To restart the current game or return to the main menu.

Volume Adjustment

The built-in speaker's volume can be adjusted using the **VOL buttons** located near the top right of the console.

Maintenance

- Keep the console clean by wiping it with a soft, dry cloth. Avoid using liquid cleaners or solvents.
- Store the console in a cool, dry place away from direct sunlight and extreme temperatures.
- If the console will not be used for an extended period, remove the batteries to prevent leakage.
- Avoid dropping the console or exposing it to excessive force, as this may damage internal components or the screen.

Troubleshooting

- **Device does not power on:** Ensure batteries are correctly installed and are not depleted. Replace with new AAA batteries if necessary.
- **Screen is blank or flickering:** Try resetting the device using the Reset button. If the issue persists, replace the batteries.
- **No sound or low volume:** Check the volume buttons to ensure the volume is turned up.

- **Game freezes or malfunctions:** Press the Reset button to restart the game or return to the main menu.

Specifications

Feature	Detail
Model Number	JL1895
Number of Built-in Games	150
Display	1.8-inch (4.5 cm) Color LCD Screen
Power Source	3 x AAA Batteries (not included)
Controller Type	Push Button
Number of Players	1
Product Dimensions (L x W x H)	3.7" x 0.91" x 2.01"
Item Weight	45 Grams (1.59 ounces)
Material	Plastic
Age Range	3+ years
Manufacturer	Lexibook

Official Product Video

▶ **Watch video online**
Lexibook portable handheld game console Cyber Arcade Pocket 150 games, JL1895

Video: Official product video showcasing the Lexibook Cyber Arcade Pocket handheld game console (Model JL1895) in action, demonstrating gameplay and features. This video is provided by Lexibook Limited.

Warranty and Support

Information regarding product warranty and customer support is not available in the provided data. Please refer to the product packaging or the manufacturer's official website for details on warranty coverage and how to contact customer support for assistance.

© 2023 LEXiBOOK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08DKDLZQN

More documents and user manuals: **https://manuals.plus/**