**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Braun JB 3150WH

# Braun PowerBlend 3 JB 3150 WH Blender Instruction Manual

Model: JB 3150WH

## 1. Introduction

The Braun PowerBlend 3 JB 3150 WH Blender is a versatile kitchen appliance designed for efficient blending, chopping, and pureeing of various ingredients. Its powerful 800W motor and unique triangular glass jug ensure optimal processing for a wide range of recipes, from fresh smoothies to crushed ice and hot soups.

## 2. Important Safety Instructions

Please read all instructions carefully before using the appliance and retain them for future reference. Failure to follow these safety guidelines may result in injury or damage to the appliance.

- Always ensure the appliance is unplugged before assembly, disassembly, or cleaning.
- Do not immerse the motor unit in water or any other liquid. Clean with a damp cloth only.
- Keep hands and utensils out of the blending jug while operating to prevent severe injury and damage to the blender.
- Blades are sharp. Handle with extreme care during assembly, disassembly, and cleaning.
- Do not blend hot liquids without allowing them to cool slightly. Hot liquids can create pressure and cause the lid to eject, resulting in burns.
- Never operate the blender with an empty jug.
- Ensure the lid is securely in place before operating the appliance.
- This appliance is for household use only. Do not use outdoors.
- Supervise children to ensure they do not play with the appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.

## 3. Package Contents

Upon unpacking, please verify that all components are present and undamaged:

- 1 x Braun PowerBlend 3 JB 3150 WH Motor Unit (White)
- 1 x 1.5 Liter Heat-Resistant Glass Blending Jug
- 1 x Lid with Removable Measuring Cap
- 1 x Blade Assembly

## 4. Product Components




**Figure 1:** Front view of the Braun PowerBlend 3 JB 3150 WH Blender, showing the motor unit, glass jug, and control dial.




**Figure 2:** Top-down view of the blender, highlighting the lid and blade assembly within the glass jug.

1. **Motor Unit:** The base of the blender housing the 800W motor and control dial.
2. **Glass Blending Jug:** A 1.5-liter heat-resistant glass container with measurement markings, designed for efficient blending.
3. **Blade Assembly:** Detachable stainless steel blades located at the bottom of the blending jug for processing ingredients.
4. **Lid:** Secures the contents of the jug during operation, featuring a removable measuring cap for adding ingredients.
5. **Control Dial:** Located on the motor unit, used to select speed settings and activate the pulse function.

## 5. Setup

Follow these steps to set up your Braun PowerBlend 3 Blender:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, wash the glass jug, lid, and blade assembly in warm soapy water. Rinse thoroughly and dry. The motor unit should only be wiped with a damp cloth.
3. **Assemble Blades:** Ensure the blade assembly is securely attached to the bottom of the glass blending jug.
4. **Place Jug:** Position the assembled glass jug onto the motor unit. Ensure it is seated correctly and locked into place if your model features a locking mechanism.
5. **Connect Power:** Plug the power cord into a suitable electrical outlet.

## 6. Operating Instructions

The Braun PowerBlend 3 Blender offers adjustable speed settings and a pulse function for optimal control over your blending tasks.



**Figure 3:** The blender prepared with fruits and vegetables, ready for blending.



**Figure 4:** The blender in action, demonstrating its ice crushing capability.

### 6.1. Blending Ingredients

1. **Prepare Ingredients:** Cut solid ingredients into small pieces (approximately 2-3 cm) to ensure optimal blending.
2. **Add Ingredients:** Place your desired ingredients into the glass blending jug. For best results, add liquids first, followed by softer ingredients, then harder ingredients and ice. Do not exceed the maximum fill line indicated on the jug.
3. **Secure Lid:** Place the lid firmly onto the jug. Ensure the measuring cap is inserted into the lid opening.
4. **Select Speed:** Turn the control dial to your desired speed setting. Start with a lower speed and gradually increase if needed.
5. **Blend:** Allow the blender to operate until the desired consistency is achieved. The unique triangular shape of the jug promotes both horizontal and vertical blending for uniform results.
6. **Stop:** Turn the control dial back to the '0' (off) position to stop the blender. Unplug the appliance before removing the jug.

### 6.2. Using the Pulse Function

The pulse function provides short bursts of power at maximum speed, ideal for chopping tough ingredients, crushing ice, or achieving a coarse consistency.

- With ingredients in the jug and the lid secured, turn the control dial to the 'P' (Pulse) position and hold it.
- Release the dial to stop the pulse action. Repeat as necessary.

## 7. Cleaning and Maintenance

Regular cleaning ensures the longevity and hygienic operation of your blender. The Braun PowerBlend 3 is designed for easy disassembly and cleaning.

1. **Unplug:** Always unplug the appliance from the power outlet before cleaning.
2. **Disassemble:** Carefully remove the glass jug from the motor unit. Detach the blade assembly from the jug and remove the lid.
3. **Wash Parts:** The glass jug, lid, and blade assembly are dishwasher safe. Alternatively, wash them by hand in warm soapy water, rinse thoroughly, and dry. Exercise caution when handling the sharp blades.
4. **Clean Motor Unit:** Wipe the motor unit with a damp cloth. Do not immerse it in water or place it in a dishwasher.
5. **Storage:** Once all parts are clean and dry, reassemble the blender or store the components separately in a dry place.

## 8. Troubleshooting

If you encounter issues with your blender, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| Blender does not start. | Appliance not plugged in. Jug not correctly assembled or seated. | Ensure the power cord is securely plugged in. Check that the jug is correctly placed on the motor unit and locked if applicable. |
| Ingredients are not blending smoothly. | Too little liquid. Jug overloaded. Ingredients too large. | Add more liquid. Reduce the amount of ingredients. Cut ingredients into smaller pieces. Use the pulse function to break down larger chunks. |
| Loud noise or vibration during operation. | Jug not properly seated. Hard ingredients causing strain. | Ensure the jug is securely placed on the motor unit. Reduce the load or add more liquid. |
| Leakage from the bottom of the jug. | Blade assembly not tightened correctly. Seal damaged. | Ensure the blade assembly is securely tightened to the jug. Check the seal for damage; replace if necessary. |

If the problem persists after attempting these solutions, please contact customer support.

## 9. Specifications

| Feature | Specification |
|---|---|
| Brand | Braun |

| Feature | Specification |
|---|---|
| Model Number | JB 3150WH |
| Power | 800 Watts |
| Voltage | 230 Volts |
| Capacity | 1.5 Liters (1500 Milliliters) |
| Material | Glass (Jug) |
| Number of Speeds | 1 (with variable control and pulse function) |
| Dimensions (L x W x H) | 6.8 x 6.8 x 41 cm |
| Weight | 900 grams |
| Special Feature | Lightweight, Heat-resistant glass jug, Quiet operation |

## 10. Warranty and Support

This Braun appliance is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details.
For technical assistance, spare parts, or service inquiries, please contact Braun customer support. Contact information can typically be found in the warranty documentation or on the official Braun website.

© 2024 Braun. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

**Open the live page**

**https://manuals.plus/asin/B08FXTY1VM**

More documents and user manuals: **https://manuals.plus/**