**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**JWIN JTK-3400**

# Jwin JTK-3400 61-Key Touch Sensitive Electronic Organ User Manual

Model: JTK-3400

## Introduction

Thank you for choosing the Jwin JTK-3400 Electronic Organ. This instrument features 61 piano-style, touch-sensitive keys, a clear LED LCD screen, 300 tones, and 300 rhythms, offering a versatile musical experience. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your electronic organ to ensure optimal performance and longevity.




Front view of the Jwin JTK-3400 electronic organ, showing the 61 keys, control panel, and music rest.

## Setup

1. **Unpacking:** Carefully remove the organ from its packaging. Retain all packing materials for future transport or storage.

2. **Power Connection:** Connect the provided DC 9V power adapter to the DC 9V input jack on the rear panel of the organ. Plug the adapter into a standard electrical outlet.
3. **Music Rest:** Insert the included music rest into the designated slots above the control panel.
4. **Optional Connections:**
    - **Headphones:** For private practice, connect standard stereo headphones to the headphone jack.
    - **Sustain Pedal:** Connect a sustain pedal (not included) to the SUSTAIN jack for piano-like sustain effects.
    - **External Audio:** Use the AUDIO INPUT jack to connect an external audio source (e.g., MP3 player) to play along with music.
    - **Microphone:** Connect a microphone to the MIC input for vocal accompaniment.
    - **External Amplifier/Speakers:** Connect the L/R OUT jacks to an external amplifier or powered speakers for louder output.




Rear panel connections of the Jwin JTK-3400 electronic organ, including Sustain, MIDI, Audio Input, Mic, L/R Out, and DC 9V power input.

## Operating Instructions

### Basic Operation

- **Power On/Off:** Press the POWER button to turn the organ on or off.
- **Volume Control:** Use the VOLUME knob or buttons to adjust the overall sound level.
- **Tone Selection:** Use the TONE buttons or number pad to select from 300 available instrument voices. The selected tone will be displayed on the LCD screen.
- **Rhythm Selection:** Use the RHYTHM buttons or number pad to choose from 300 accompaniment rhythms.
- **Tempo Control:** Adjust the tempo of rhythms and demo songs using the TEMPO buttons.

## Advanced Features

- **Touch Sensitivity:** The 61 keys are touch-sensitive, meaning the volume changes based on how hard you press the keys, mimicking a real piano.
- **Pitch Bend:** Use the PITCH BEND wheel on the left side of the keyboard to smoothly alter the pitch of notes.




Close-up view of the pitch bend wheel located on the left side of the Jwin JTK-3400 electronic organ.

- **Transpose:** Adjust the overall pitch of the keyboard up or down in semitone steps.
- **Split:** Divide the keyboard into two sections, allowing different tones to be played on the left and right hands.
- **Dual Voice Layering:** Layer two different instrument voices to play simultaneously when a key is pressed.
- **Metronome:** Activate the metronome function for timing practice.
- **Recording and Playback:** Use the RECORD function to capture your performances and PLAYBACK to listen to them.
- **Sustain and Vibrato:** Apply sustain to notes or add a vibrato effect for expressive playing.
- **Accompaniment Functions:**
  - **Single Finger Chord:** Play chords by pressing a single key in the lower section of the keyboard.
  - **Multi-Finger Chord:** Play chords by pressing multiple keys in the lower section.
  - **Bass Chord:** Engage bass accompaniment patterns.
  - **Intro/Ending:** Add introductory and ending phrases to your rhythm patterns.
  - **Fill-in/Sync:** Insert fill-in patterns or synchronize rhythm starts.
- **Training Function:** Utilize the 3-step training function with 30 demo songs to learn and practice.
- **USB Music Player:** Connect a USB flash drive to play MP3 music files. Use the USB Music Volume Control and Previous/Next Song Selection buttons to manage playback.
- **EQ Mode/AB Repeat:** Adjust equalization settings or repeat specific sections of a song from the USB player.




Detailed view of the Jwin JTK-3400 electronic organ, highlighting the speaker grille, various control buttons, the LCD screen displaying 'JTK-3400 MUSICAL INFORMATION SYSTEM', and a side profile.

## Maintenance

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the organ. For stubborn dirt, slightly dampen the cloth with water and a mild detergent, then wipe dry immediately. Avoid abrasive cleaners or solvents.
- **Storage:** When not in use, store the organ in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Handling:** Always handle the organ with care. Avoid dropping it or subjecting it to strong impacts.
- **Power Off:** Always turn off the power when the organ is not in use or before disconnecting the power adapter.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| No sound | Power not connected; Volume too low; Headphones connected; External speakers off. | Check power connection; Increase volume; Disconnect headphones; Turn on external speakers. |
| Keys not responding | Organ is off; Function mode preventing key input. | Turn on the organ; Exit current function mode (e.g., demo mode, record mode). |
| Rhythm/Tone selection not working | Incorrect button pressed; System error. | Ensure correct selection buttons are used; Try restarting the organ. |
| USB music not playing | USB drive not formatted correctly; Incompatible file format; USB drive not inserted properly. | Ensure USB drive is FAT32 formatted; Use MP3 files; Reinsert USB drive. |

## Specifications

- **Brand:** JWIN
- **Model Name:** JTK-3400
- **Instrument Type:** Electronic Organ
- **Number of Keys:** 61 (Piano Style, Touch Sensitive)
- **Tones:** 300
- **Rhythms:** 300
- **Display:** LED LCD Screen
- **Demo Songs:** 30
- **Training Function:** 3-Step
- **Connectivity:** Sustain, MIDI, Audio Input, Mic, L/R Out, USB
- **Power:** DC 9V Adapter
- **Color:** Black
- **Product Weight:** 0.4 Kilogram

## Warranty and Support

The Jwin JTK-3400 Electronic Organ comes with a**2-year manufacturer warranty**. Please retain your proof of purchase for warranty claims.
For technical support, service, or further inquiries, please contact your local JWIN dealer or the authorized service center. Refer to the contact information provided with your product packaging or visit the official JWIN website for support details.
**ASIN:** B08H596N6N

© 2024 JWIN. All rights reserved.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

**Open the live page**

**https://manuals.plus/asin/B08H596N6N**

More documents and user manuals: **https://manuals.plus/**