Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HANGSUN SB-123

Hangsun Handheld Percussion Massager

Model: SB-123

Brand: HANGSUN

1. Introduction

Thank you for choosing the Hangsun Handheld Percussion Massager. This device is designed to provide a relaxing and invigorating massage experience, targeting various muscle groups to help relieve tension and fatigue. Featuring a powerful motor, multiple speed settings, and interchangeable massage nodes, it offers customizable relief for your back, shoulders, legs, and arms.

2. Important Safety Information

- Read all instructions before use.
- Do not use the massager on swollen, burned, inflamed, or injured skin areas.
- Consult a doctor before use if you have any medical conditions, including but not limited to pregnancy, diabetes, heart disease, or if you have a pacemaker.
- Keep out of reach of children.
- Do not use while sleeping or drowsy.
- Do not immerse the device in water or other liquids. This product is not water-resistant.
- Unplug the device from the power source when not in use and before cleaning.
- Use only the provided charging adapter.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.

3. Package Contents

Verify that all items are present in the package:

- Hangsun Handheld Percussion Massager (Model SB-123)
- Power Adapter

- 6 Interchangeable Massage Nodes

4. Product Overview

Familiarize yourself with the components and controls of your massager.



Image 4.1: Front view of the massager with labeled controls and massage head.

- **Massage Head:** Area where interchangeable nodes attach.
- **Speed Control Button:** Adjusts the massage intensity.
- **Mode Control Button:** Cycles through different massage patterns.
- **On/Off Button:** Powers the device on or off.

5. Charging the Device

The massager is cordless and powered by a rechargeable battery. Ensure the device is fully charged before first use.



Image 5.1: Massager highlighting its cordless nature and battery specifications.

1. Connect the power adapter to the charging port on the massager.
2. Plug the adapter into a standard electrical outlet.
3. The charging indicator light will illuminate.
4. Allow the device to charge completely. A full charge provides up to 150 minutes of operating time.
5. Unplug the massager once charging is complete. The device will not operate while plugged in and charging.

6. Attaching Massage Nodes

The massager comes with 6 different interchangeable massage nodes to customize your experience.



Image 6.1: Various massage nodes included with the device.

1. Ensure the massager is turned off before changing nodes.
2. Gently pull the currently attached node off the massage head.
3. Select the desired massage node.
4. Align the new node with the massage head and push it firmly until it clicks into place.

7. Operating Instructions

Follow these steps to operate your Hangsun Handheld Percussion Massager:



Image 7.1: Visual representation of the massager's power and speed capabilities.

1. **Power On/Off:** Press the On/Off button to turn the massager on. Press it again to turn it off.
2. **Adjust Speed:** Use the Speed Control button to cycle through 6 personalized speed settings, from gentle to vigorous. The massager can deliver up to 3600 pulses per minute.
3. **Select Mode:** Press the Mode Control button to choose from 6 different massage modes, which vary the massage pattern.
4. **Automatic Shut-off:** For safety and to prevent overheating, the massager will automatically switch off after 15 minutes of continuous use. You can restart it if desired.

8. Using the Massager

The ergonomic handle allows you to reach various body parts for a full-body massage.



Image 8.1: Massager in use on the neck area.

Apply the massager to your back, shoulders, legs, arms, and buttocks. Move the massager slowly over the desired area, applying gentle pressure. Adjust the speed and mode to your comfort level. Avoid prolonged use on a single spot.

9. Maintenance and Care

- **Cleaning:** Ensure the device is turned off and unplugged. Wipe the massager with a soft, slightly damp cloth. Do not use abrasive cleaners or immerse in water.
- **Storage:** Store the massager in a cool, dry place, away from direct sunlight and extreme temperatures. Keep it in its original packaging or a protective case to prevent damage.

10. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Massager does not turn on.	Battery is low or depleted.	Charge the massager fully.
Massager stops during use.	Automatic shut-off activated (15-minute timer).	Restart the massager if desired.
Weak massage intensity.	Speed setting is too low.	Increase the speed setting using the Speed Control button.

11. Specifications

- **Model:** SB-123
- **Power Source:** Battery Powered (Rechargeable)
- **Operating Time:** Up to 150 minutes (on a full charge)
- **Max Pulses Per Minute:** 3600
- **Speed Settings:** 6
- **Massage Modes:** 6
- **Dimensions:** 17.48 x 4.84 x 6.02 inches
- **Item Weight:** 1.81 Pounds (820 Grams)
- **Water Resistance Level:** Not Water Resistant

12. Warranty and Support

Hangsun products are manufactured to the highest quality standards. For warranty information or technical support, please refer to the warranty card included with your purchase or contact Hangsun customer service directly. Please retain your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08HHRKL6C

More documents and user manuals: **https://manuals.plus/**