Manuals+
Q & A | Deep Search | Upload

XREXS B08HWFM4JC

XREXS Large Digital Wall Clock Instruction Manual

Model: B08HWFM4JC

Introduction

Thank you for choosing the XREXS Large Digital Wall Clock. This manual provides essential information for setting up, operating, and maintaining your new clock. Please read these instructions thoroughly before use to ensure optimal performance and longevity of your device.

Figure 1: Front view of the XREXS Large Digital Wall Clock displaying time, day, and temperature.

Package Contents

- 1 x XREXS Large Digital Wall Clock (Model B08HWFM4JC)
- 2 x AAA Batteries (for memory function)
- 4 x AA Batteries (for main power)
- 1 x Instruction Manual

Product Features Overview

The XREXS Large Digital Wall Clock is designed for clear visibility and multi-functionality. Key features include:

- **Large LCD Display:** High-contrast, jumbo digits for easy reading from a distance.
- **Multi-Function Modes:** Clock, Alarm, and Timer modes.
- **Time Display:** 12 or 24-hour format.
- **Calendar Display:** Shows time, date, month, and day.
- **Temperature Display:** Indoor temperature in Celsius (°C) or Fahrenheit (°F).
- **Alarm with Snooze:** Clear alarm sounds with a 5-minute snooze function.
- **Count Up/Down Timer:** Timing period from 0 to 29 hours, 59 minutes, 59 seconds.
- **Battery Powered:** Cordless operation for flexible placement.
- **Mounting Options:** Wall-mountable or free-standing with a fold-out stand.

Figure 2: The clock can operate in Timer, Clock, or Alarm Clock modes.

Setup

1. Battery Installation

The clock requires 4 AA batteries for main power and 2 AAA batteries for memory backup. Batteries are

included in the package.

1. Open the battery compartments located on the back of the clock.
2. Insert 4 AA batteries into the main compartment, ensuring correct polarity (+/-).
3. Insert 2 AAA batteries into the memory backup compartment, ensuring correct polarity (+/-).
4. Close both battery compartments securely.

Figure 3: Rear view of the clock with battery compartments and wall mounting holes.

2. Initial Time, Date, and Temperature Setting

Use the buttons on the side/back of the clock to set the initial parameters:

- Press the **SET** button to enter setting mode.
- Use the **+** or **-** buttons to adjust the year, month, date, hour, and minute.
- Press the **12/24** button to switch between 12-hour and 24-hour time formats.
- Press the **°C/°F** button to toggle between Celsius and Fahrenheit for temperature display.
- Press **SET** again to confirm each setting and move to the next.
- Exit setting mode by pressing **SET** until the normal clock display resumes, or wait for 30 seconds for it to exit automatically.

3. Mounting Options

The clock offers versatile placement options:

- **Wall Mount:** Use the two keyhole slots on the back of the clock to hang it on screws or nails securely fastened to a wall.
- **Desk Stand:** Pull out the integrated fold-out stand on the back to place the clock on any flat surface.

Figure 4: The clock can be mounted on a wall or placed on a desk using its integrated stand.

Operating Instructions

1. Time Display Modes

Toggle between 12-hour and 24-hour formats by pressing the **+** / **12/24** button on the side/back of the clock.

2. Temperature Display

Switch between Celsius (°C) and Fahrenheit (°F) by pressing the **-** / **°C/°F** button on the side/back of the clock.

3. Alarm Function

The clock features an alarm with a snooze function.

1. **Setting the Alarm:** Press the **ALARM SET** button to enter alarm setting mode. Use the **+** or **-** buttons to adjust the alarm hour and minute. Press **ALARM SET** again to confirm.
2. **Activating/Deactivating Alarm:** In normal time mode, press the **ALARM SET** button to toggle the alarm on or off. An alarm icon will appear on the display when active.
3. **Snooze Function:** When the alarm rings, press the **SNOOZE** button to activate a 5-minute snooze. The alarm will ring again after 5 minutes. To turn off the alarm completely, press any other button.

Figure 5: The snooze button and other buttons for alarm control.

4. Timer Function (Count Up/Down)

The clock includes a versatile timer for various activities.

1. **Entering Timer Mode:** Press the **TIMER** button to switch to timer mode.
2. **Setting Countdown Timer:** In timer mode, use the **TIMER:hour**, **TIMER:min**, and **TIMER:sec** buttons to set the desired countdown duration (up to 29 hours, 59 minutes, 59 seconds).
3. **Starting/Pausing Timer:** Press the **SNOOZE** button (labeled Timer: ▶II) to start or pause the timer.
4. **Resetting Timer:** Press the **TIMER:clear** button to reset the timer to 0:00:00.

5. **Count Up Function:** If the timer is started from 0:00:00, it will function as a count-up timer.
6. **Timer Alert:** A 90-second