Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Panasonic NN-SB658S

Panasonic NN-SB658S Countertop Microwave Oven Instruction Manual

Model: NN-SB658S

Safety Information Package
Contents Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Important Safety Information

Read all instructions carefully before using the microwave oven. Failure to follow these instructions may result in electric shock, fire, or injury.

- Do not attempt to operate this oven with the door open or if the door is damaged.
- Do not place metal containers, foil, or utensils inside the microwave oven.
- Ensure proper ventilation around the unit. Do not block air vents.
- Do not heat sealed containers, as they may explode.
- Always supervise children when they are near the microwave oven.
- Do not use corrosive chemicals or vapors in this appliance.
- Only use microwave-safe cookware.
- Liquids heated in a microwave oven can boil over unexpectedly. Use caution when removing containers.

2. Package Contents

Verify that all components are present and undamaged upon unpacking.

- Panasonic NN-SB658S Microwave Oven Unit
- Glass Turntable Tray
- Roller Ring
- Instruction Manual

3. Setup and Installation

3.1 Placement

Place the microwave oven on a flat, stable, heat-resistant surface. Ensure there is adequate space for ventilation:

- Minimum 4 inches (10 cm) of clearance on the top, sides, and rear.
- Do not place the oven near heat sources such as a range or oven.
- Avoid placing it near water or in areas of high humidity.

3.2 Electrical Connection

Connect the microwave oven to a properly grounded 3-prong outlet. Ensure the voltage matches the rating label on the back of the oven. Do not use extension cords or adapters.

3.3 Turntable Installation

1. Place the roller ring securely in the center depression on the oven floor.
2. Position the glass turntable tray on top of the roller ring, ensuring it sits properly on the center hub.



Figure 1: Interior view showing the glass turntable and roller ring correctly placed inside the microwave oven.

4. Operating Instructions

4.1 Basic Microwave Cooking

1. Place food in a microwave-safe container on the glass turntable. Close the oven door securely.
2. Press the **COOK TIME** button.
3. Use the **+/-** buttons to set the desired cooking time.
4. Press the **POWER LEVEL** button repeatedly to select the desired power level (e.g., P10 for 100%, P7 for 70%).
5. Press **START** to begin cooking.

4.2 Smart Touch Controls

This microwave features smart touch controls instead of a traditional numerical keypad. Time and power adjustments are made using dedicated **+/-** buttons and specific function buttons.



Figure 2: Front view of the Panasonic NN-SB658S microwave, highlighting the control panel with smart touch buttons.

4.3 Turbo Defrost

The Turbo Defrost feature allows for quick and efficient thawing of frozen foods.

1. Place the frozen food in a microwave-safe dish.
2. Press the **TURBO DEFROST** button.
3. Use the **+/-** buttons to enter the weight of the food in pounds (e.g., 1.0 for 1 pound).
4. Press **START**. The oven will automatically calculate the defrosting time and power level.
5. The oven may beep during defrosting, indicating that the food should be turned or separated for even thawing.

4.4 Child Safety Lock

To prevent unintended operation, activate the child safety lock.

- **To Activate:** Press and hold the **START** button for 3 seconds. A lock indicator will appear on the display.
- **To Deactivate:** Press and hold the **START** button for 3 seconds again. The lock indicator will disappear.

5. Maintenance and Cleaning

Regular cleaning helps maintain the performance and longevity of your microwave oven. Always unplug the oven before cleaning.

5.1 Exterior Cleaning

Wipe the exterior surfaces with a soft, damp cloth. For stubborn stains, use a mild detergent. Avoid abrasive cleaners or scouring pads.

5.2 Interior Cleaning

Wipe the interior walls, door seal, and door with a soft, damp cloth after each use. For food splatters, heat a cup of water with a few lemon slices for 2-3 minutes, then wipe clean with a soft cloth. This also helps to remove odors.

5.3 Turntable and Roller Ring

The glass turntable and roller ring can be removed and washed in warm, soapy water or in the dishwasher. Ensure they are completely dry before placing them back in the oven.

6. Troubleshooting Guide

Before contacting customer service, review the following common issues and solutions.

Problem	Possible Cause	Solution
Oven does not start.	Door not closed properly; Power cord unplugged; Circuit breaker tripped; Child lock activated.	Ensure door is latched; Plug in power cord; Reset circuit breaker; Deactivate child lock.
Food not heating.	Incorrect cooking time/power level; Microwave-safe dish not used.	Adjust time/power; Use appropriate cookware.
Turntable not rotating.	Turntable or roller ring not positioned correctly; Obstruction.	Reposition turntable/roller ring; Remove any obstructions.
Display is dim or unreadable.	Environmental lighting; Power issue.	Ensure adequate room lighting; Check power connection.

7. Product Specifications

- **Brand:** Panasonic
- **Model:** NN-SB658S
- **Capacity:** 1.3 Cubic Feet
- **Cooking Power:** 1100 Watts
- **Installation Type:** Countertop
- **Special Features:** Child Safety Lock, Turbo Defrost
- **Controller Type:** Button, Touch
- **Material:** Glass (Inner and Turntable)
- **Item Weight:** Approximately 37.7 pounds
- **Package Dimensions:** Approximately 22 x 20 x 15 inches

8. Warranty and Customer Support

For warranty information or technical assistance, please refer to the warranty card included with your product or visit the official Panasonic website. You may also contact Panasonic customer support directly for service inquiries.
Please retain your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08HZDGZM1

More documents and user manuals: **https://manuals.plus/**