Skullcandy V2VYW-N161

Skullcandy Spoke True Wireless Earbuds User Manual

Model: V2VYW-N161

1. Introduction

Welcome to the Skullcandy Spoke True Wireless Earbuds. This manual provides essential information for setting up, operating, and maintaining your earbuds. The Spoke earbuds offer a streamlined audio experience with key features designed for convenience and durability.

Key features include:

- Up to 14 Hours Total Battery Life (4 hours in buds + 10 hours in charging case)
- IPX4 Sweat and Water Resistant design
- Solo Bud Use capability
- Integrated EQ Modes

2. What's in the Box

Verify that all components are present in your product packaging:

- Skullcandy Spoke True Wireless Earbuds
- Charging Case
- Ear Gels (Small, Medium, Large)
- Micro-USB Charging Cable

Image: Included components of the Skullcandy Spoke True Wireless Earbuds, featuring the earbuds, charging case, ear gels, and charging cable.

3. Setup

3.1. Charging Your Earbuds

Before first use, fully charge your Skullcandy Spoke earbuds and charging case. Place the earbuds into the charging case. Connect the micro-USB charging cable to the charging case and a power source. The LED indicators on the case will show charging status.

- Total battery life: Up to 14 hours (4 hours in earbuds, 10 hours from charging case).

Image: Visual representation of the Skullcandy Spoke's battery life, showing 4 hours for the earbuds and an additional 10 hours provided by the charging case.

3.2. Bluetooth Pairing

1. Remove both earbuds from the charging case. They will automatically enter pairing mode.
2. On your device (smartphone, laptop, etc.), open the Bluetooth settings.
3. Select 'Skullcandy Spoke' from the list of available devices.
4. Once connected, you will hear an audio prompt, and the earbud LED will indicate a successful connection.

Image: The Skullcandy Spoke True Wireless Earbuds and their charging case, ready for use or pairing.

4. Operating Instructions

4.1. Power On/Off

- **Power On:** Remove earbuds from the charging case. They will power on automatically. Alternatively, press and hold the button on each earbud for 2 seconds.
- **Power Off:** Place earbuds back into the charging case. They will power off automatically. Alternatively, press and

hold the button on each earbud for 4 seconds.

4.2. Controls

The Skullcandy Spoke earbuds feature a single button on each earbud for various functions:

Action	Left Earbud	Right Earbud
Play/Pause	Press 1x	Press 1x
Volume Up	N/A	Press 2x
Volume Down	Press 2x	N/A
Track Forward	N/A	Press 3x
Track Back	Press 3x	N/A
Answer/End Call	Press 1x	Press 1x
Activate Voice Assistant	Press and Hold (2s)	Press and Hold (2s)

4.3. Solo Bud Use

Either earbud can be used independently. Simply remove one earbud from the case, and it will automatically connect to your device. The other earbud can remain in the case or be powered off.

4.4. EQ Modes

The Skullcandy Spoke earbuds include built-in EQ modes to optimize audio for different content types. Refer to the Skullcandy support website for specific instructions on how to cycle through available EQ modes, as this functionality may vary or require the Skullcandy app.

Image: Overview of Skullcandy Spoke features, including battery life, water resistance, and solo bud functionality.

5. Maintenance

5.1. Cleaning

To maintain optimal performance and hygiene, regularly clean your earbuds and charging case. Use a soft, dry, lint-free cloth. Avoid using abrasive materials or harsh chemicals. Gently remove any earwax or debris from the earbud tips and speaker mesh.

5.2. Water Resistance

The Skullcandy Spoke earbuds are rated IPX4 sweat and water resistant. This means they are protected against splashing water from any direction. They are not designed for submersion in water. Avoid exposing them to pressurized water, high-velocity water, or prolonged submersion. Ensure earbuds are dry before placing them back in the charging case to prevent damage.

6. Troubleshooting

If you encounter issues with your Skullcandy Spoke earbuds, try the following solutions:

- **No Power:** Ensure earbuds and charging case are fully charged.
- **Earbuds Not Pairing:**
  - Ensure Bluetooth is enabled on your device.
  - Forget 'Skullcandy Spoke' from your device's Bluetooth list and attempt to re-pair.
  - Place both earbuds back in the case, close it for a few seconds, then remove them to re-initiate pairing mode.
- **No Sound or Low Volume:**
  - Check the volume level on both your device and the earbuds.
  - Ensure earbuds are properly seated in your ears.
  - Clean any debris from the earbud speaker mesh.
- **One Earbud Not Working:**
  - Ensure both earbuds are charged.
  - Try resetting the earbuds by placing them in the case, closing it, and then removing them.

For further assistance, refer to the Skullcandy support website.

7. Specifications

Feature	Specification
Model Name	Spoke
Model Number	V2VYW-N161
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth
Noise Control	Passive Sound Isolation
Water Resistance Level	IPX4 Water Resistant
Battery Life	Up to 14 Hours Total (4 hrs in bud + 10 hrs in case)
Frequency Range	20Hz - 20KHz
Impedance	32 Ohm
Control Type	Volume Control, Touch
Material	Plastic
Item Weight	57 Grams
Product Dimensions	16 x 6.5 x 3.5 cm
Compatible Devices	Cellphones, Laptops

8. Warranty and Support

Your Skullcandy Spoke True Wireless Earbuds are covered by a manufacturer's warranty. For detailed warranty information, product registration, and technical support, please visit the official Skullcandy website or contact their customer service. Keep your proof of purchase for warranty claims.

For additional resources and frequently asked questions, please visit:Skullcandy Support

© 2023 Skullcandy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question