Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iHome iBT700B

iHome iBT700 Waterproof Bluetooth Speaker User Manual

Model: iBT700B

Introduction

This manual provides detailed instructions for the operation and maintenance of your iHome iBT700 Waterproof Bluetooth Speaker. Designed for both indoor and outdoor use, this portable speaker offers high-quality audio, a long-lasting rechargeable battery, and robust waterproof and sand-proof capabilities. Please read this manual thoroughly to ensure proper use and to maximize the lifespan of your device.



The iHome iBT700 speaker, showcasing its compact and durable design.

Setup

Charging the Speaker

Before first use, fully charge the iBT700 speaker. Connect the provided USB charging cable to the charging port on the speaker and to a USB power adapter (not included) or a computer's USB port. The charging indicator light will illuminate during charging and turn off when fully charged. A full charge provides up to 20 hours of wireless audio playback.



The iBT700 speaker, highlighting its rechargeable battery and compact dimensions.

Powering On/Off

To power on the speaker, press and hold the **Power On/Off** button located on the top panel until you hear an audible tone. To power off, press and hold the same button again until the speaker shuts down.

Bluetooth Pairing

1. Ensure the speaker is powered on. The Bluetooth pairing LED will flash rapidly, indicating it is in pairing mode.
2. On your Bluetooth-enabled device (smartphone, tablet, etc.), go to the Bluetooth settings and enable Bluetooth.
3. Select "iHome iBT700" from the list of available devices.
4. Once successfully paired, the Bluetooth pairing LED will glow solid blue, and you will hear a confirmation tone.
5. The speaker will automatically attempt to reconnect to the last paired device when powered on.



Interacting with the speaker's controls for Bluetooth pairing and audio streaming.

Operating Instructions

Audio Playback

- **Play/Pause:** Press the **Play/Pause** button to start or pause audio playback.
- **Volume Control:** Press the **Volume Up (+)** or **Volume Down (-)** buttons to adjust the speaker's volume.
- **Track Navigation:** Double-press the **Volume Up (+)** button for the next track, and double-press the**Volume Down (-)** button for the previous track.



An illustration of the speaker's internal components, demonstrating its powerful sound capabilities with a full-range driver and passive subwoofer.

Speakerphone Function

The iBT700 features a built-in hands-free speakerphone with digital echo canceling. When a call comes in while connected via Bluetooth:

- **Answer Call:** Press the **Talk/End** button (often integrated with Play/Pause).
- **End Call:** Press the **Talk/End** button again.
- **Reject Call:** Press and hold the **Talk/End** button.

Audio Caller ID is compatible with Apple iOS 10+ devices.

Outdoor Mode (EQ Mode)

For enhanced sound performance in outdoor environments, activate the Outdoor Mode. Press the **EQ Mode** button on the top panel to toggle between standard and outdoor audio profiles. The outdoor mode provides an audio boost

suitable for open spaces.

Wireless Stereo (TWS) Pairing

If you have a second iHome iBT700 speaker (sold separately), you can pair them wirelessly for true stereo sound. Refer to the specific instructions provided with your second speaker for TWS pairing, as this feature allows for an immersive audio experience.



Detailed view of the speaker's features including wireless stereo capability, durable weave, speakerphone, and carry strap.

Maintenance

Waterproof and Sand-proof Care

The iBT700 is certified IP67 waterproof and sand-proof. This means it can be submerged in water up to 1 meter for 30 minutes and is protected from dust and sand ingress. To maintain its integrity:

- Ensure the charging port cover is securely closed before exposing the speaker to water or sand.
- After exposure to saltwater or chlorinated water, rinse the speaker with fresh water and allow it to air dry completely before charging or using.
- Avoid exposing the speaker to extreme temperatures or harsh chemicals.



The iBT700 speaker on a sandy surface, highlighting its durable and sand-proof design.

Cleaning

Wipe the speaker with a soft, damp cloth. Do not use abrasive cleaners or solvents.

Battery Care

To prolong battery life, avoid fully discharging the battery frequently. If storing the speaker for an extended period, charge it to about 50% every few months.

Troubleshooting

Problem	Solution
Speaker does not power on.	Ensure the battery is charged. Connect the speaker to a power source and try again.

Problem	Solution
Cannot pair with Bluetooth device.	• Ensure the speaker is in pairing mode (flashing Bluetooth LED). • Make sure Bluetooth is enabled on your device. • Move the speaker closer to your device. • Forget "iHome iBT700" from your device's Bluetooth list and try pairing again.
No sound or low volume.	• Increase the volume on both the speaker and your connected device. • Ensure the speaker is properly paired and connected. • Check if the audio source is playing.
Poor sound quality.	• Move the speaker closer to your device to reduce interference. • Ensure there are no obstructions between the speaker and your device. • Try disabling Outdoor Mode if indoors.

Specifications

Feature	Detail
Model Name	iHome
Model Number	iBT700B
Speaker Type	Outdoor
Special Features	Portable, Waterproof, Built In Microphone
Connectivity Technology	Bluetooth
Wireless Communication Range	Up to 100 Feet
Battery Life	Up to 20 Hours
Water Resistance Level	IP67 Waterproof
Product Dimensions	3.11"D x 4.26"W x 5.52"H
Item Weight	1.14 Pounds
Included Components	iHome PLAYPRO Portable Bluetooth Speaker, USB charging cable (not explicitly listed but implied)

Warranty and Support

Warranty Information

The iHome iBT700 speaker comes with a **Limited Warranty** or **Full Warranty** as specified at the time of purchase. Please retain your proof of purchase for warranty claims. For detailed warranty terms and conditions, refer to the warranty card included with your product or visit the official iHome support website.

Customer Support

For further assistance, technical support, or to inquire about replacement parts, please visit the official iHome brand

store or support website. You can find contact information and FAQs there.
Official iHome Store: iHome Store on Amazon

© 2024 iHome. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08JD55PZ6

More documents and user manuals: **https://manuals.plus/**