Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Seagate STKC4000403

Seagate One Touch 4TB Portable External Hard Drive Instruction Manual

Model: STKC4000403

Introduction

The Seagate One Touch 4TB Portable External Hard Drive (Model: STKC4000403) is designed to provide convenient and reliable storage for your photos, videos, and files. Its compact design and plug-and-play functionality make it an ideal solution for expanding storage on your PC or Mac, whether at home or on the go. This manual provides essential information on setting up, operating, maintaining, and troubleshooting your device.

Product Overview

The Seagate One Touch HDD features a minimalist brushed metal enclosure, combining durability with a sleek aesthetic. It offers quick and easy data transfer via USB 3.0, allowing for efficient backup and access to your digital content.



Image: Seagate One Touch 4TB Portable External Hard Drive in Red.



Image: Angled view of the Seagate One Touch 4TB Portable External Hard Drive, highlighting its compact size.

Key Features:

- **High Capacity:** 4TB of storage for extensive photo and file collections.
- **Portable Design:** Compact and lightweight for easy transport.
- **Fast Connectivity:** USB 3.0 for quick data transfers.

- **Cross-Platform Compatibility:** Works with both PC (Windows) and Mac.
- **Automated Backup:** Options for single-click or scheduled backups.

Setup Guide

Setting up your Seagate One Touch HDD is straightforward. Follow these steps to get started:

1. **Unpack the Drive:** Carefully remove the Seagate One Touch drive and the included USB 3.0 cable from its packaging.
2. **Connect to Computer:** Plug one end of the USB 3.0 cable into the port on your Seagate One Touch drive. Connect the other end of the cable to an available USB 3.0 port on your computer (PC or Mac). For optimal performance, use a USB 3.0 port (often blue or marked with a 'SS' symbol).
3. **Initial Recognition:** Your computer should automatically detect the drive.
4. **For Windows Users:** The drive is typically pre-formatted for Windows and ready for use immediately. It will appear as a new drive letter in 'This PC' or 'My Computer'.
5. **For Mac Users:** While the drive can be used with Mac out of the box, reformatting may be required for full compatibility with Apple's Time Machine backup software. Instructions for reformatting can be found in your Mac's Disk Utility application or on the Seagate support website.

Operating Instructions

Once your Seagate One Touch drive is connected and recognized, you can begin managing your data.

Data Transfer:

- **Drag and Drop:** Simply drag files and folders from your computer to the Seagate One Touch drive icon in your file explorer (Windows) or Finder (Mac).
- **Copy and Paste:** Right-click on files/folders, select 'Copy', then navigate to the Seagate drive, right-click, and select 'Paste'.

Backup Options:

The Seagate One Touch drive supports various backup methods:

- **Single-Click Backup:** Utilize the included Seagate backup software (available for download or pre-loaded on the drive) to perform quick, on-demand backups with a single click.
- **Scheduled Backups:** Configure the Seagate backup software to automatically perform daily, weekly, or monthly backups, ensuring your data is always protected without manual intervention.
- **Time Machine (Mac):** If you have reformatted the drive for Mac, you can use Apple's built-in Time Machine feature for continuous and incremental backups.

Software and Services

Your Seagate One Touch drive comes with valuable complimentary software and services to enhance your digital life:



Image: Logos representing Mylio Create and Adobe Creative Cloud Photography Plan.

- **Mylio Create:** Enjoy a one-year complimentary subscription to Mylio Create, a powerful photo management and editing software that helps you organize, edit, and share your photos across all your devices.
- **Adobe Creative Cloud Photography Plan:** Receive a four-month membership to the Adobe Creative Cloud Photography plan, which includes Adobe Photoshop Lightroom and Photoshop, for advanced photo editing and manipulation.

Note: Software and service redemption must occur within one year of drive registration. Availability may vary by country.

Maintenance

Proper care of your Seagate One Touch HDD will ensure its longevity and reliable performance:

- **Safe Ejection:** Always safely eject the drive from your computer before disconnecting the USB cable. This prevents data corruption and potential damage to the drive.
- **Physical Protection:** Avoid dropping the drive or exposing it to excessive shock, vibration, extreme temperatures, or moisture. Store it in a cool, dry place when not in use.
- **Regular Backups:** While the drive itself is a backup solution, consider having multiple backup strategies (e.g., cloud storage, another external drive) for critical data.
- **Software Updates:** Periodically check the Seagate website for firmware updates for your drive and software updates for the Seagate backup utility to ensure optimal performance and compatibility.
- **Cleaning:** Use a soft, dry, lint-free cloth to clean the exterior of the drive. Do not use liquid cleaners or aerosols.

Troubleshooting

If you encounter issues with your Seagate One Touch HDD, refer to the following common solutions:

Drive Not Recognized:

- **Check Connections:** Ensure the USB cable is firmly connected to both the drive and a working USB port on your computer.
- **Try Different Port/Cable:** Test with a different USB port on your computer or a different compatible USB cable.
- **Restart Computer:** Sometimes a simple restart can resolve recognition issues.
- **Disk Management (Windows):** Open Disk Management (right-click 'This PC' -> 'Manage' -> 'Disk Management') to see if the drive appears there, even if not assigned a letter.
- **Disk Utility (Mac):** Open Disk Utility (Applications -> Utilities -> Disk Utility) to see if the drive is listed. You may need to mount it or check its format.

Slow Transfer Speeds:

- **Use USB 3.0 Port:** Ensure the drive is connected to a USB 3.0 port on your computer. USB 2.0 ports will significantly reduce transfer speeds.
- **Close Other Applications:** Close any other programs that might be actively using the drive or consuming significant system resources.
- **Check Cable Length:** Shorter, high-quality USB cables generally offer better performance.

Data Access Issues:

- **Run Disk Check:** Use your operating system's built-in disk checking tools (e.g., 'Error checking' in Windows, 'First Aid' in Mac Disk Utility) to scan and repair minor errors.
- **Reformat (Last Resort):** If the drive is severely corrupted and data is not critical, reformatting the drive can resolve many issues, but it will erase all data.

Specifications

Feature	Detail
Brand	Seagate
Series	One Touch
Model Number	STKC4000403
Digital Storage Capacity	4 TB
Hard Disk Type	Mechanical Hard Disk
Hard Disk Form Factor	2.5 Inches
Connectivity Technology	USB
USB Ports	3 (USB 3.0)
Compatible Devices	PC, Mac (Laptop)
Color	Red
Item Weight	9.5 ounces
Product Dimensions (LxWxH)	0.46 x 3.07 x 4.52 inches
Date First Available	September 18, 2020

Warranty and Support

Seagate stands behind the quality of its products. Your One Touch HDD includes:

- **Two-Year Limited Warranty:** Provides coverage for manufacturing defects.
- **Two-Year Rescue Data Recovery Service Plan:** Offers peace of mind by providing professional data recovery services in case of unexpected data loss due to accidental damage or mechanical failure.

For detailed warranty information, product registration, software downloads, and additional support resources, please

visit the official Seagate Store: Seagate Store on Amazon.

© 2024 Seagate Technology LLC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08JDSN1M6

More documents and user manuals: **https://manuals.plus/**