Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Panasonic HC-X1500

Panasonic HC-X1500 4K Professional Camcorder Instruction Manual

Model: HC-X1500

Introduction

This manual provides essential information for the safe and effective use of your Panasonic HC-X1500 4K Professional Camcorder. The HC-X1500 is a compact and lightweight camcorder designed for professional video production, capable of recording UHD 4K and Full HD video. It features a 1/2.5-inch 8.29M MOS sensor, a Venus processing engine, and a 24x optical zoom lens. Please read this manual thoroughly before using the product and retain it for future reference.



Image: The Panasonic HC-X1500 4K Professional Camcorder, showcasing its compact design and lens.

What's in the Box

Verify that all items listed below are included in your package. If any items are missing or damaged, contact your retailer.

- Panasonic HC-X1500 UHD 4K HDMI Pro Camcorder with 24x Zoom
- Rechargeable Battery Pack (5900mAh)
- AC Adapter
- AC Cable
- Eye Cup
- Lens Hood
- SanDisk Extreme PRO UHS-I Memory Card (64GB)
- Soft Padded Carrying Case
- Table Top Tripod
- Lens Cleaning Kit

- Blower Brush
- Lens Pen Cleaner
- 9-in-1 USB Card Reader
- Memory Card Wallet



Image: All items included in the Panasonic HC-X1500 starter bundle, including the camcorder, battery, memory card, and cleaning accessories.

Setup

1. Attaching the Lens Hood

Align the lens hood with the front of the lens and twist clockwise until it locks into place. The lens hood helps to reduce flare and protect the lens.

2. Installing the Battery

1. Ensure the camcorder is powered off.
2. Open the battery compartment cover.
3. Insert the rechargeable battery pack, ensuring the contacts align correctly. Push until it clicks into place.
4. Close the battery compartment cover.

3. Charging the Battery

Connect the AC adapter to the camcorder's DC input terminal and then to a power outlet. The charging indicator will illuminate. A full charge typically takes several hours.

4. Inserting an SD Card

The HC-X1500 features two SD card slots. Use UHS-I compatible SD cards for optimal performance, especially when recording 4K video.

1. Open the SD card slot cover.
2. Insert the SD card into the desired slot (Slot 1 or Slot 2) with the label facing the correct direction, until it clicks.
3. Close the SD card slot cover.



Image: Top view of the Panasonic HC-X1500, showing the dual SD card slots and various control buttons.

Operating the Camcorder

1. Powering On/Off

Slide the POWER switch to the ON position to turn on the camcorder. To turn off, slide the switch to OFF.

2. Basic Recording

1. Open the LCD monitor or extend the viewfinder.
2. Point the camcorder at your subject.
3. Press the **REC START/STOP** button to begin recording. The recording indicator will light up.
4. Press the **REC START/STOP** button again to stop recording.

3. Zoom Operation

Use the zoom lever located on the top of the camcorder to control the optical zoom. Push the lever towards **T** (Telephoto) to zoom in, and towards **W** (Wide) to zoom out. The 24x optical zoom can be extended with i.ZOOM for 32x in 4K and 48x in Full HD.

4. Focus Control

The camcorder supports both automatic and manual focus. Use the **FOCUS A/M/M** switch to select your desired mode. In manual mode, rotate the focus ring on the lens to adjust focus. The camcorder features high-precision AF with face detection.



Image: Side view of the Panasonic HC-X1500, highlighting the focus ring, ND filter switch, and other controls.

5. Image Stabilization

The HC-X1500 incorporates 5-axis HYBRID Image Stabilization, combining optical and electronic stabilization to correct camera shake. Ensure O.I.S. is enabled for smoother footage, especially when shooting handheld.

6. Recording Modes (4K/HD)

The camcorder records in .mp4, .mov, and AVCHD codecs. You can select your desired recording resolution and frame rate through the menu system. The 1/2.5-inch 8.29M MOS sensor always shoots at 4K resolution, which is then scaled for Full HD delivery if selected.

7. Live Streaming

The HC-X1500 supports Full-HD live streaming over 2.4 GHz Wi-Fi using RTSP/RTP/RTMP/RTMPS protocols. Refer to the advanced settings in the menu for configuring streaming parameters and connecting to a network.

8. Menu Navigation

Use the **MENU** button and the joystick/selector dial to navigate through the camcorder's settings. Press the joystick/dial to confirm selections.

Maintenance

Cleaning the Camcorder

- **Lens:** Use a soft, lint-free cloth or a lens brush/blower to gently remove dust. For stubborn smudges, use a specialized lens cleaning solution applied to a cloth, not directly to the lens.
- **Body:** Wipe the camcorder body with a soft, dry cloth. For dirt, slightly dampen the cloth with water and then wipe dry. Avoid using harsh chemicals or solvents.
- **LCD Monitor/Viewfinder:** Use a soft, dry cloth. Do not press hard on the screen.

Battery Care

- Store batteries in a cool, dry place when not in use.

- Avoid fully discharging batteries frequently to prolong their lifespan.
- Do not expose batteries to extreme temperatures.

Storage

When storing the camcorder for extended periods, remove the battery and SD cards. Store the camcorder in a dry, dust-free environment, preferably in its carrying case.

Troubleshooting

No Power

- Ensure the battery is fully charged and correctly inserted.
- Verify the AC adapter is properly connected to both the camcorder and a working power outlet.

Cannot Record

- Check if an SD card is inserted and has sufficient free space.
- Ensure the SD card is not write-protected.
- Verify the camcorder is not in playback mode.

Image is Blurry

- Check the focus mode (Auto/Manual). If in manual, adjust the focus ring.
- Ensure the lens is clean and free from smudges.
- Verify that image stabilization is active, especially in low light or when zooming.

Wi-Fi Connection Issues

- Ensure the camcorder is within range of the Wi-Fi access point.
- Check Wi-Fi settings in the camcorder menu for correct network selection and password.
- Restart both the camcorder and the Wi-Fi router.

Specifications

Feature	Specification
Brand	Panasonic
Model Number	HC-X1500
Photo Sensor Technology	MOS
Video Capture Resolution	4K
Maximum Focal Length	600 Millimeters
Maximum Aperture	1.8 f
Flash Memory Type	SD

Video Capture Format	MP4, MOV, AVCHD
Supported Audio Format	PCM
Screen Size	9 Inches (LCD Monitor)
Connectivity Technology	Wi-Fi
Item Weight	6.31 pounds
Product Dimensions	10.12 x 6.26 x 5.08 inches
Special Features	Lightweight, 5-Axis Hybrid O.I.S.



Image: Diagram illustrating the internal cooling system of the Panasonic HC-X1500 camcorder.

Warranty and Support

Your Panasonic HC-X1500 camcorder is covered by a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty period and coverage details. For technical support, service, or to download the latest firmware and detailed manuals, please visit the official Panasonic support website. You can typically find support contact information and resources at www.panasonic.com/support.
When contacting support, please have your camcorder's model number (HC-X1500) and serial number ready.

© 2024 Panasonic Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08JPJWDSV

More documents and user manuals: **https://manuals.plus/**