Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Gardena 11114-20

Gardena 11114-20 EasyPump Spray 1L Battery Operated Instruction Manual

Model: 11114-20

1. Introduction

Thank you for choosing the Gardena EasyPump Spray. This battery-operated sprayer is designed for convenient and efficient watering and misting of plants in your garden or home. Its ergonomic design and adjustable spray features make it a versatile tool for various gardening tasks. Please read this manual carefully before first use to ensure safe operation and optimal performance.





Image 1: The Gardena EasyPump Spray, a 1-liter battery-operated sprayer in dark gray with a blue accent.

2. Important Safety Instructions

To prevent injury and damage, always observe the following safety precautions:

- Always keep batteries out of reach of children.
- Do not use the sprayer with harsh chemicals. Only use with water or approved plant care solutions.
- Keep the device away from heat sources and open flames.
- Do not disassemble or modify the product. Unauthorized modifications can lead to malfunction and void the warranty.
- Always follow local regulations for the disposal of batteries and chemical containers.
- Ensure the liquid temperature does not exceed 35°C (95°F).

3. Product Components

The Gardena EasyPump Spray consists of the following main parts:

- **Sprayer Head:** Contains the battery compartment, trigger button, and nozzle.
- **Brass Nozzle:** Adjustable for different spray patterns.
- **1-Liter Bottle:** Translucent bottle with water level memory.
- **Side Water Supply Port:** An additional opening for easy filling.
- **Suction Tube:** Extends into the bottle to draw liquid.





Image 2: Overview of the Gardena EasyPump Spray, showing the main body, sprayer head, and side filling port.

4. Setup and Preparation

4.1. Battery Installation

1. Unscrew the sprayer head from the bottle by turning it counter-clockwise.
2. Locate the battery compartment on the underside of the sprayer head.
3. Open the battery compartment cover.
4. Insert two (2) AA alkaline batteries (not included), ensuring correct polarity (+/-).
5. Close the battery compartment cover securely.



Image 3: A user installing AA batteries into the battery compartment of the sprayer head.

4.2. Filling the Sprayer

1. Ensure the sprayer head is securely attached or removed for easier filling.
2. Unscrew the cap of the side water supply port on the bottle body.
3. Fill the bottle with the desired liquid (water or plant care solution) up to the 1-liter capacity mark. The translucent bottle allows you to monitor the liquid level.
4. Securely close the side water supply port cap.
5. If the sprayer head was removed, reattach it by screwing it clockwise until tight.



Image 4: A user filling the Gardena EasyPump Spray through the convenient side water supply port.

5. Operating Instructions

5.1. Activating the Spray

Once filled and with batteries installed, simply press and hold the trigger button on the sprayer head to activate the spray. The battery-operated pump will continuously spray as long as the button is held down.





Image 5: A woman demonstrating the use of the Gardena EasyPump Spray to mist plants outdoors.

5.2. Adjusting the Spray Pattern

The high-quality brass nozzle allows you to switch between different spray types:

- **Fine Mist:** Turn the brass nozzle clockwise for a fine, gentle mist, ideal for delicate plants or seedlings.
- **Full Jet:** Turn the brass nozzle counter-clockwise for a concentrated, powerful jet, suitable for targeted

watering or cleaning.



Image 6: A close-up view of the brass nozzle producing a fine mist spray.



Image 7: A close-up view of the brass nozzle producing a concentrated jet spray.

5.3. 360° Function

The innovative 360° function allows you to spray at any angle, even diagonally or upside down, without interrupting the flow or inhaling air. This feature ensures consistent spraying performance regardless of the sprayer's orientation.

6. Maintenance and Storage

- **Cleaning:** After each use, especially when using plant care solutions, rinse the bottle and flush the sprayer head with clean water to prevent clogging.
- **Storage:** Store the sprayer in a cool, dry place, away from direct sunlight and freezing temperatures. Remove batteries if storing for extended periods.
- **Nozzle Care:** If the nozzle becomes clogged, carefully clean it with a small brush or needle.

7. Troubleshooting

Problem	Possible Cause	Solution
Sprayer does not activate.	Batteries are dead or incorrectly installed. Battery compartment cover is not secure.	Replace batteries with new AA alkaline batteries. Check battery polarity and ensure the cover is closed tightly.
Weak or inconsistent spray.	Low battery power. Nozzle is partially clogged. Insufficient liquid in the bottle.	Replace batteries. Clean the brass nozzle. Refill the bottle.
Liquid leaks from the sprayer.	Sprayer head or side cap not securely tightened. Damaged seals.	Ensure all caps and the sprayer head are tightly secured. Contact customer support if seals appear damaged.

8. Technical Specifications

Feature	Detail
Model Number	11114-20
Brand	Gardena
Capacity	1 Liter (3.3 fl oz)
Power Source	Battery Powered
Batteries Required	2 x AA Alkaline (not included)
Material	Plastic
Color	Dark Gray

Feature	Detail
Product Dimensions	5.31"W x 11.02"H
Item Weight	7.1 ounces (200 Grams)
Maximum Liquid Temperature	35°C (95°F)

9. Warranty and Support

The Gardena EasyPump Spray 11114-20 comes with a warranty of up to 2 years. For warranty claims, technical support, or further inquiries, please refer to the official Gardena website or contact your local Gardena dealer. Please retain your proof of purchase for warranty purposes.
For more information, visit the officialGardena Store.

© 2025 Gardena. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08KGM4TS7

More documents and user manuals: **https://manuals.plus/**