Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Philips Beauty BRE740/14

Philips Beauty Epilator Series 8000 User Manual

Model: BRE740/14

Brand: Philips Beauty



Image: Philips Epilator Series 8000 with all included accessories.

Introduction

Discover smooth skin up to 4 weeks without the use of chemicals or wax, even in sensitive areas. The Philips Epilator Series 8000 (BRE740/14) is designed for use on the legs and body. This 5-in-1 pack includes an epilator and four additional tools for shaving, trimming, pedicure, and exfoliation. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device.

Important Safety Information

- Always ensure the device is fully charged before cordless wet use. Do not use the device with the cord while wet.
- Keep the appliance dry when charging.
- Do not use the epilator on irritated skin, varicose veins, moles, or sunburned skin. Consult a doctor if you have any skin conditions or concerns.
- For hygienic reasons, do not share the appliance with other persons.
- Keep the appliance out of reach of children.

What's in the Box

Your Philips Beauty Epilator Series 8000 comes with the following components:



Image: All 9 accessories included with the Philips Epilator Series 8000.

- Epilator main unit
- Delicate area cap
- Optimal contact cap (Skin stretcher cap)
- Shaver head with trimming comb
- Trimming head with bikini comb
- Body exfoliation head
- Pedicure head
- Drawstring pouch
- Cleaning brush
- Power adapter

Setup

Charging the Device

Before first use, fully charge the epilator. The device is cordless and can be used wet or dry. A full charge takes approximately 2 hours and provides up to 40 minutes of cordless usage.

1. Connect the power adapter to the charging port at the bottom of the epilator.
2. Plug the adapter into a power outlet.
3. The charging indicator light will blink while charging and remain solid when fully charged.

Operating Instructions

General Usage Tips

- For optimal results, hold the epilator at a 90-degree angle to your skin.
- Move the device slowly against the direction of hair growth.
- The built-in Opti-light helps illuminate fine hairs for thorough removal.
- The device supports both wet and dry use. Using it in the shower or bath with soap can make the experience more comfortable.

Using the Epilator Head



Image: Epilator head with Opti-light for enhanced visibility during use.

The epilator head features rotating ceramic discs with a micro-ridged surface designed to firmly grab hairs as short as 0.5mm. Attach the epilator head to the main unit. You can use the delicate area cap or optimal contact cap for sensitive areas or to stretch the skin for easier epilation.

Using the Shaver Head and Trimmer

▶ **Watch video online**

Philips Epilator 8000 5 in 1: Shaver+Trimmer+Pedicure+Exfoliator

Video: Official Philips demonstration of the Epilator Series 8000's 5-in-1 functions, including shaver, trimmer, pedicure, and exfoliator heads.

Attach the shaver head for a close shave. It includes a trimming comb for precise trimming. The separate trimming head with a bikini comb is ideal for maintaining the bikini area.

Using the Pedicure Head



Image: The 3-in-1 rotating precision disc for pedicure use.

Attach the pedicure head to gently remove rough skin from your feet, providing heel-to-toe smoothness.

Using the Body Exfoliation Head



Image: The body exfoliation brush head.

Use the body exfoliation head to remove dead skin cells and help prevent ingrown hairs. It is recommended for use on the body, not the face.

Maintenance

Cleaning the Device

- After each use, remove the attached head and rinse it under running water.
- Use the small cleaning brush to remove any trapped hairs from the epilator discs or shaver blades.
- Ensure all parts are dry before reattaching or storing the device.
- The main unit can be rinsed under water as it is waterproof.

Troubleshooting

- **Ineffective Hair Removal:** Ensure the epilator is held at a 90-degree angle and moved slowly against hair growth. Hair might be too short; allow it to grow slightly longer (0.5mm minimum).
- **Pain/Discomfort:** Epilation can cause initial discomfort. Using the device wet (in shower/bath) can reduce pain. Ensure skin is stretched taut, especially in sensitive areas. Discomfort usually decreases with regular use.
- **Battery Not Holding Charge:** Ensure the charging cable is securely connected. If the issue persists, contact customer support.
- **Skin Irritation/Bumps:** This can occur after epilation. Apply a soothing lotion. Ensure the exfoliation brush is used regularly to prevent ingrown hairs.

Specifications

Product Dimensions	7.28 x 2.55 x 8.26 inches; 1.3 Pounds
Item model number	BRE740/14
Batteries	1 Lithium Ion batteries required. (included)
UPC	075020091574
Manufacturer	AmazonUs/NOUJ9
ASIN	B08KV24XVZ
Country of Origin	China
Brand	Philips Beauty
Color	White With Rose Accent
Power Source	Battery Powered
Water Resistance Level	Waterproof
Charging Time	2 Hours
GTIN	075020091574

Warranty & Support

This product comes with a 3-year warranty. For detailed warranty information or further support, please refer to the official user manual PDF provided by Philips. You can access the full user manual here.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08KV24XVZ

More documents and user manuals: **https://manuals.plus/**