Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

W-KING D9-1

W-KING D9-1 Bluetooth Speaker User Manual

Model: D9-1 | Brand: W-KING

1. Introduction

Thank you for choosing the W-KING D9-1 Bluetooth Speaker. This powerful and versatile portable speaker is designed to deliver high-quality audio for various environments, from indoor gatherings to outdoor adventures. Featuring 100W peak output, IPX6 waterproof rating, and a long-lasting battery, the D9-1 ensures your music accompanies you wherever you go. Please read this manual carefully to understand the product's features and ensure proper operation.



Figure 1.1: W-KING D9-1 Bluetooth Speaker

2. Product Overview

2.1 Package Contents

- W-KING D9-1 Portable Loud Bluetooth Speaker
- 3.5mm Audio Cable
- Type-C Charging Cable
- User Manual

2.2 Speaker Components and Controls

Familiarize yourself with the speaker's layout and controls for optimal use.



Figure 2.1: Top Panel Controls and Features

1. **Power Button:** Press and hold to power on/off.
2. **Volume Down (-):** Decrease volume.
3. **Play/Pause Button:** Play or pause audio. Press to answer/end calls.
4. **Volume Up (+):** Increase volume.
5. **EQ Button:** Cycle through EQ modes (Indoor/Bass Boost, Outdoor/Clear Mids & Treble).
6. **NFC Area:** Tap NFC-enabled Android devices for quick pairing.



Figure 2.2: Internal Speaker Components

The speaker features two 3.7-inch woofers (35W PEAK each), two 1.2-inch tweeters (15W PEAK each), and a super large 7.2-inch passive bass radiator for powerful, all-round HD sound and deep bass.

3. Setup

3.1 Charging the Speaker

Before first use, fully charge the speaker. Connect the provided Type-C charging cable to the speaker's charging port and a 5V 2A power adapter (not included). The charging indicator will show the charging status and turn off when fully charged. A full charge provides up to 40 hours of playtime at low volume.

3.2 Powering On/Off

- **Power On:** Press and hold the Power button for 2-3 seconds.
- **Power Off:** Press and hold the Power button for 2-3 seconds.

3.3 Bluetooth Pairing

The speaker will automatically enter Bluetooth pairing mode when powered on for the first time or if no device is connected. The Bluetooth indicator will flash.

1. Turn on your device's Bluetooth function.
2. Search for "W-KING D9-1" in the list of available devices.
3. Select "W-KING D9-1" to connect. The Bluetooth indicator will become solid when connected.

For quick pairing with Android devices, use the NFC function:

- Ensure NFC is enabled on your Android phone.
- Tap your phone to the NFC area on the speaker's top panel.
- Confirm the pairing prompt on your phone.



Figure 3.1: NFC One-Touch Pairing (Android Only)

3.4 True Wireless Stereo (TWS) Pairing

You can pair two W-KING D9-1 speakers for a 200W peak powerful stereo surround sound experience. Note: D9 and D9-1 models cannot be paired together.

1. Ensure both D9-1 speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), double-press the Play/Pause button. You will hear a prompt indicating TWS pairing mode.
3. The two speakers will automatically connect to each other. Once connected, you will hear a confirmation sound.
4. Connect your device to the primary speaker via Bluetooth as described in Section 3.3.



Figure 3.2: True Wireless Stereo Pairing

4. Operating Instructions

4.1 Audio Playback

- **Bluetooth:** Play audio from your connected Bluetooth device.
- **TF Card:** Insert a TF card into the designated slot. The speaker will automatically switch to TF card playback. (Note: U-Disk is not supported).
- **AUX Input:** Connect an audio device using the 3.5mm audio cable to the AUX port. The speaker will automatically switch to AUX mode.



Figure 4.1: Multiple Playback Options

4.2 EQ Modes

Press the EQ button to switch between different sound modes:

- **Indoor Mode (Bass Boost):** Enhances bass for a richer sound experience, ideal for indoor listening.
- **Outdoor Mode (Clear Mids & Treble):** Optimizes for clear vocals and crisp treble, suitable for outdoor environments.



Figure 4.2: EQ Mode Selection

4.3 Power Bank Function

The W-KING D9-1 can act as a power bank to charge your smart devices. Connect your device to the speaker's USB-A output port using a compatible charging cable. This port supports power bank functionality only and is not for USB playback.



Figure 4.3: Power Bank Functionality

4.4 Hands-Free Calling

When connected via Bluetooth, the built-in microphone allows for hands-free calls.

- **Answer Call:** Press the Play/Pause button once.
- **End Call:** Press the Play/Pause button once during a call.
- **Reject Call:** Press and hold the Play/Pause button for 2 seconds.



Figure 4.4: Hands-Free Calling Feature

5. Maintenance

To ensure the longevity and optimal performance of your W-KING D9-1 speaker, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use abrasive cleaners or solvents.
- **Water Resistance (IPX6):** The speaker is IPX6 waterproof, meaning it can withstand powerful water jets. It is suitable for use in rain or near splashes. However, it is not designed for submersion. After use in wet conditions, thoroughly wipe the speaker dry, especially around the buttons and ports, to prevent water accumulation that could affect button functionality.
- **Dust Protection:** The speaker is designed to be dustproof. For best results, avoid exposing it to excessive dust or sand for prolonged periods. If used in sandy environments, gently brush off any sand from the grille and ports.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To preserve battery life, charge the speaker regularly, even if not in frequent use. Avoid fully discharging the battery for extended periods.



Figure 5.1: IPX6 Waterproof Feature



Figure 5.2: Dustproof Design

6. Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully using the provided Type-C cable and a 5V 2A adapter.
No sound.	Volume too low; incorrect input mode; device not connected.	Increase volume on both speaker and connected device. Ensure correct input mode (Bluetooth, AUX, TF). Re-pair Bluetooth device.
Bluetooth connection unstable or fails.	Device too far; interference; NFC interference.	Move device closer to speaker (within 100ft). Avoid obstacles. Disconnect and re-pair. If using NFC, ensure phone is not left on the NFC area after pairing.
TWS pairing fails.	Incorrect model; speakers already connected to other devices.	Ensure both speakers are D9-1 models (D9 and D9-1 are not compatible for TWS). Disconnect both speakers from any Bluetooth devices before attempting TWS pairing.
Power bank function not working.	Speaker battery too low; incorrect cable.	Ensure speaker has sufficient charge. Use a proper USB charging cable for your device.

7. Specifications

Feature	Detail
Model Name	D9-1
Brand	W-KING
Speaker Type	Woofer

Feature	Detail
Speaker Maximum Output Power	100 Watts (Peak) / 60W (RMS)
Subwoofer Diameter	3.7 Inches (Woofers)
Connectivity Technology	Wireless (Bluetooth 5.0), Auxiliary (3.5mm), NFC, TF card
Battery Life	Up to 40 Hours (at low volume)
Waterproof Rating	IPX6
Product Dimensions	10.7D x 31.5W x 18.8H Centimetres (approx. 33.02 x 12.7 x 22.86 cm)
Item Weight	3.12 Kilograms
Included Components	Speaker, 3.5mm Audio Cable, User Manual, Type-C Charging Cable
Manufacturer	SHENZHEN WEIKING TECHNOLOGY CO., LTD

8. Warranty and Support

For warranty information or technical support, please contact the seller or manufacturer directly. Refer to your purchase documentation for specific warranty terms and contact details.
Manufacturer: SHENZHEN WEIKING TECHNOLOGY CO., LTD
Place of Business: shenzhen/longhua, guangdong 518109,CN
For further assistance, you may visit the official W-KING store on Amazon:W-KING Amazon Store

© 2024 W-KING. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08L4VGN34

More documents and user manuals: **https://manuals.plus/**