Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Geepas G034047UK

Geepas 48L Mini Oven and Grill (Model G034047UK)

Instruction Manual

1. Introduction

Thank you for purchasing the Geepas 48L Mini Oven and Grill. This appliance is designed for versatile cooking, including baking, roasting, grilling, and rotisserie functions. Please read this manual thoroughly before operating the appliance to ensure safe and efficient use. Keep this manual for future reference.



Image 1.1: The Geepas 48L Mini Oven and Grill, a compact electric oven with a glass door and control knobs.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.

- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause hazards.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off”, then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Oversize foods or metal utensils must not be inserted in a toaster oven as they may create a fire or risk of electric shock.
- A fire may occur if the oven is covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation.
- Do not place any of the following materials in the oven: paper, cardboard, plastic, and the like.
- Do not store any materials, other than manufacturer’s recommended accessories, in this oven when not in use.
- Do not place cooking utensils or baking dishes on the glass door.

3. Package Contents

Please check the package contents carefully. If any items are missing or damaged, contact your retailer.

- Geepas 48L Mini Oven and Grill Unit
- Bake/Food Tray
- Grill Bake Tray/Wire Rack
- Tray Handle
- Rotisserie Fork
- Rotisserie Handle
- Instruction Manual



Image 3.1: Included accessories for the Geepas 48L Mini Oven, showing the bake tray, wire rack, rotisserie fork, and handles.

4. Product Overview

Familiarize yourself with the components and controls of your Geepas Mini Oven.

Control Panel

1. **Temperature Control Knob:** Adjusts cooking temperature from 100°C to 230°C.
2. **Function Selector Knob:** Selects cooking mode (e.g., upper heating, lower heating, both, rotisserie).
3. **Timer Knob:** Sets cooking time up to 60 minutes with an auto shut-off feature.
4. **Power Indicator Light:** Illuminates when the oven is operating.



Image 4.1: Close-up view of the control panel with three rotary knobs for temperature, function, and timer.



Image 4.2: Detailed view of the 60-minute timer knob with auto shut-off feature.

5. Setup

5.1 Unpacking

- Remove all packaging materials and promotional labels from the oven.
- Ensure all accessories listed in Section 3 are present.
- Wipe the exterior of the oven with a damp cloth. Clean the interior and accessories with warm, soapy water, rinse, and dry thoroughly.

5.2 Placement

- Place the oven on a stable, heat-resistant, and level surface.
- Ensure there is adequate ventilation around the oven (at least 10-15 cm clearance on all sides).

- Do not place the oven near flammable materials or under cabinets.

5.3 Initial Use (Burn-in)

Before cooking food, operate the oven for 15 minutes to burn off any manufacturing residues and odors.

1. Plug the oven into a grounded electrical outlet.
2. Set the temperature control to 230°C.
3. Set the function selector to both upper and lower heating elements.
4. Set the timer to 15 minutes. The power indicator light will turn on.
5. A slight odor or smoke may be present during this initial operation; this is normal. Ensure the area is well-ventilated.
6. Once the timer rings, the oven will turn off. Allow it to cool completely before first use with food.

6. Operating Instructions

This section details how to use the various functions of your Geepas Mini Oven.

6.1 General Operation

1. Place food on the appropriate accessory (bake tray, wire rack) and insert it into the desired rack position inside the oven.
2. Close the oven door securely.
3. Set the **Temperature Control Knob** to the desired temperature.
4. Set the **Function Selector Knob** to the desired cooking mode (e.g., Bake, Grill, Roast).
5. Set the **Timer Knob** to the desired cooking time. The power indicator light will illuminate.
6. When the cooking time expires, the timer will ring, and the oven will automatically shut off.
7. Carefully remove cooked food using oven mitts and the tray handle.

6.2 Cooking Functions

The oven offers four selector positions for versatile cooking:

- **Upper Heating:** Ideal for grilling and browning the top of dishes.
- **Lower Heating:** Suitable for baking items that require heat from the bottom, like pies or pastries.
- **Upper and Lower Heating:** Standard mode for baking, roasting, and general cooking.
- **Rotisserie with Upper Heating:** For roasting whole chickens or other meats evenly.



Image 6.1: The oven in use, baking pizza on the upper rack and fries on the lower tray, demonstrating its capacity and versatility.

6.3 Rotisserie Function

The rotisserie function allows for even roasting of poultry and other meats.

1. Skewer the meat onto the rotisserie fork, ensuring it is centered and secured.
2. Insert the rotisserie assembly into the designated slots inside the oven.
3. Place the drip tray (bake tray) on the bottom rack to catch drippings.
4. Set the **Function Selector Knob** to the rotisserie setting (usually combined with upper heating).
5. Set the **Temperature Control Knob** and **Timer Knob** according to your recipe.
6. When cooking is complete, use the rotisserie handle to carefully remove the hot rotisserie assembly from the oven.



Image 6.2: A whole chicken roasting on the rotisserie spit inside the oven, demonstrating the rotisserie function.

7. Maintenance and Cleaning

Regular cleaning and maintenance will prolong the life of your oven.

7.1 Cleaning

- Always unplug the oven from the power outlet and allow it to cool completely before cleaning.
- **Exterior:** Wipe the exterior surfaces with a damp cloth and mild detergent. Do not use abrasive cleaners or scourers.
- **Interior:** Wipe the interior walls with a damp cloth and mild detergent. For stubborn stains, a non-abrasive oven cleaner designed for conventional ovens can be used, following the product instructions. Ensure all cleaner residue is removed.
- **Accessories:** The bake tray, wire rack, rotisserie fork, and handles can be washed in warm, soapy water or placed in a dishwasher. Rinse thoroughly and dry before storing.
- Do not immerse the main oven unit, power cord, or plug in water or any other liquid.



Image 7.1: A hand wiping down the removable bake tray, illustrating the ease of cleaning the accessories.

7.2 Storage

Store the cooled and cleaned oven in a dry place, away from direct sunlight and out of reach of children.

8. Troubleshooting

If you encounter any issues with your oven, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Oven does not turn on.	Not plugged in; power outage; timer not set.	Ensure plug is securely in outlet; check household circuit breaker; set the timer knob to desired cooking time.

Problem	Possible Cause	Solution
Food not cooking evenly.	Incorrect rack position; overcrowding; uneven food placement.	Adjust rack position; avoid overcrowding the oven; ensure food is spread evenly on the tray.
Smoke or odor during operation.	First use burn-off; food spills; excessive grease.	Normal for first use (see Section 5.3); clean interior and accessories thoroughly; reduce amount of grease on food.
Rotisserie not rotating.	Rotisserie not properly installed; function selector not set to rotisserie.	Ensure rotisserie assembly is correctly seated in the drive and support slots; select the rotisserie function on the knob.

9. Specifications

Feature	Specification
Model Number	G034047UK
Capacity	48 Liters
Power / Wattage	2000W
Voltage	Refer to product label (typically 220-240V, 50/60Hz)
Timer	60 minutes with auto shut-off
Temperature Range	100°C - 230°C
Material	Stainless Steel
Color	Black
Product Dimensions (approx.)	60 x 41 x 44 cm (L x W x H)
Item Weight	8 Kilograms

10. Warranty and Support

10.1 Warranty Information

This Geepas 48L Mini Oven and Grill comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects and faults under normal household use. It does not cover damage caused by misuse, accident, unauthorized modification, or failure to follow the instructions in this manual.
Please retain your proof of purchase for warranty claims.

10.2 Customer Support

For technical assistance, warranty claims, or general inquiries, please contact Geepas customer service through their official website or the contact information provided with your purchase documentation.

© 2024 Geepas. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08LNXQJQH

More documents and user manuals: **https://manuals.plus/**