Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Gardena 15202-34

Gardena Sileno Minimo Robotic Lawnmower 500m² User Manual

Model: 15202-34

1. Introduction

This manual provides essential instructions for the safe and efficient operation, installation, and maintenance of your Gardena Sileno Minimo Robotic Lawnmower. Please read this manual thoroughly before using the product and retain it for future reference. The Gardena Sileno Minimo is designed for automatic lawn care on areas up to 500 square meters.

2. Safety Information

Warning: Always ensure the robotic lawnmower is switched off and disconnected from its power source before performing any maintenance or cleaning. Keep hands and feet away from rotating blades. Do not operate the mower if children or pets are in the working area. Familiarize yourself with all controls and proper use of the appliance.

- Read all instructions carefully before use.
- Do not allow children or persons unfamiliar with these instructions to operate the lawnmower.
- Ensure the installation of the boundary wire is correct to prevent the mower from leaving the designated area.
- Never lift the mower while it is operating. The blades will stop automatically if the mower is lifted.
- Regularly inspect the blades for wear and damage. Replace worn or damaged blades promptly.

3. Package Contents

The Gardena Sileno Minimo package includes the following components:

- Gardena Sileno Minimo Robotic Lawnmower
- Charging Station
- 150 meters of Boundary Wire
- 150 x Pegs for boundary wire fixation
- 4 x Connectors
- 5 x Connection Terminals
- Power Supply Unit
- Hex Key for blade adjustment
- User Manual (IT/ES)



Image: Contents of the Gardena Sileno Minimo box, including the robotic lawnmower, charging station, boundary wire, pegs, connectors, and power supply.

4. Setup

4.1 Charging Station Placement

Select a flat, accessible location for the charging station, ideally in a shaded area to protect it from direct sunlight. Ensure there is sufficient space around the station for the robotic lawnmower to dock easily. The charging station must be connected to a power outlet.

4.2 Boundary Wire Installation

The boundary wire defines the mowing area. Lay the wire around the perimeter of your lawn and around any obstacles (e.g., flowerbeds, ponds, large trees) that the mower should avoid. Secure the wire to the ground using the provided pegs. Maintain recommended distances from edges and obstacles as specified in the detailed manual. Connect both ends of the boundary wire to the charging station. A guide wire should also be installed to help the mower navigate complex areas and find its way back to the charging station.

4.3 Initial Charging

Once the charging station and boundary wire are installed, place the robotic lawnmower into the charging station. Allow it to fully charge before its first operation. A full charge typically takes approximately 60-90 minutes, providing about 60 minutes of mowing time.

5. Operating Instructions

5.1 Bluetooth App Control

The Gardena Sileno Minimo can be easily controlled via the Gardena Bluetooth app on your smartphone. Download the app and pair it with your mower. The app allows you to:

- Define your lawn size and desired mowing days/times.
- Adjust cutting schedules.
- Monitor the mower's status and battery level.
- Initiate or pause mowing cycles.

The Bluetooth connection has a range of up to 10 meters.



Image: A smartphone displaying the Gardena app interface, indicating successful Bluetooth connection to the robotic lawnmower.

5.2 Manual Operation

The mower can also be operated directly using the control panel on the device. Refer to the detailed manual for specific button functions and menu navigation.

5.3 Cutting Height Adjustment

The cutting height can be adjusted between 20mm and 45mm. Use the provided hex key to adjust the cutting deck height as desired. This adjustment mechanism is located on the top of the mower.

5.4 Weather and Terrain Adaptability

The Sileno Minimo is designed to operate in various weather conditions, including rain and intense sun. It can handle slopes up to 25% gradient. The mower features SensorControl, which adapts the mowing frequency to the grass growth rate. It also detects frozen ground and will pause operation until conditions are suitable.




Image: The robotic lawnmower operating on a lawn with simulated rain and an indication of its ability to handle slopes up to 25%.

5.5 Pro-Silent Operation

The Gardena Sileno Minimo operates at a low noise level of approximately 57 dB(A), allowing for quiet operation without disturbing you or your neighbors, even during nighttime mowing schedules.



Image: The robotic lawnmower on a lawn with a graphic indicating its quiet operation, symbolized by a person meditating.

5.6 AI-Precise Navigation

The mower's navigation system allows it to precisely maneuver through complex garden layouts and narrow passages, ensuring comprehensive coverage of the mowing area.




Image: The robotic lawnmower navigating a corner of a lawn, illustrating its precise movement in tight spaces.

6. Maintenance

6.1 Cleaning

The Gardena Sileno Minimo is water-resistant (IPX5) and can be easily cleaned with a garden hose. Regularly clean the underside of the mower, removing grass clippings and debris from the cutting deck and wheels. Ensure the mower is switched off and disconnected from the charging station before cleaning.

6.2 Blade Replacement

The blades are consumable parts and should be replaced regularly to ensure optimal cutting performance. The blades are fixed to the cutting disc with screws, making them easy to replace. Always use genuine Gardena replacement blades. Refer to the detailed manual for instructions on how to safely replace the blades.

7. Troubleshooting

If you encounter issues with your Gardena Sileno Minimo, consider the following general troubleshooting steps:

- **Error Messages:** If an error message appears on the display, consult the detailed user manual for specific error codes and recommended solutions.
- **Charging Issues:** Ensure the charging station is properly connected to power and the mower is correctly docked. Check for any obstructions preventing proper contact.
- **Mowing Irregularities:** Verify that the boundary wire is correctly installed and intact. Check for any obstacles in the mowing area. Ensure blades are sharp and correctly installed.
- **App Connectivity:** Ensure your smartphone's Bluetooth is enabled and within range (10m) of the mower. Restart the app or the mower if connection issues persist.
- **Firmware Updates:** Check the Gardena website or app for any available firmware updates, as these can resolve known issues and improve performance.

For persistent problems, contact Gardena customer support.

8. Specifications

Brand	Gardena
Model Number	15202-34
Recommended Lawn Area	Up to 500 m²
Cutting Height	20-45 mm
Max Slope Performance	25%
Connectivity	Bluetooth (up to 10m)
Noise Level	Approx. 57 dB(A)
Battery Type	Lithium-ion (1 included)
Typical Charging Time	75-90 minutes
Typical Mowing Time on One Charge	60-70 minutes
Product Dimensions (L x W x H)	59.5 x 49.5 x 30.4 cm (approx. 60 x 31 x 50 cm)
Weight	7 kg
Material	Plastic
Water Resistance	IPX5



Image: Diagram showing the dimensions (52 cm length, 34 cm width, 22 cm height) and weight (6.1 kg) of the Gardena Sileno Minimo robotic lawnmower.

9. Warranty and Support

Gardena products are manufactured to high-quality standards. For warranty information, please refer to the warranty card included with your product or visit the official Gardena website. For technical support, spare parts, or service inquiries, please contact your local Gardena service center or authorized dealer. Ensure you have your product model number (15202-34) and purchase details available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08LZ3K3H9

More documents and user manuals: **https://manuals.plus/**