Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Timberchic B08P3NMZ6B

TIMBERCHiC 100% Wood Wall Planks Instruction Manual

Model: Baxter Blonde (4" x 20 Sq Ft)

1. Product Overview

TIMBERCHiC Wood Wall Planks are designed to provide a natural wood aesthetic for interior wall decoration. These peel-and-stick panels feature a smooth finish and are suitable for various DIY home decor applications. The planks are made from responsibly sourced Red Pine and White Oak, offering a blend of contemporary style and organic warmth.



Image: A living room featuring a wall adorned with Timberchic wood planks, showcasing the product's installed appearance.

2. Product Features

- **Material:** Crafted from 100% real wood (Red Pine and White Oak).
- **Finish:** Premium smooth finish for a refined appearance.
- **Adhesion:** Equipped with industrial-strength 3M adhesive backing for permanent installation.
- **Sustainability:** Made in the USA from sustainably sourced timbers, free from chemicals like asbestos or lead paint.
- **Dimensions:** Each pack includes approximately 32 planks in varying lengths (12–42 inches), 1/8 inch thick, covering 20 sq. ft.
- **Durability:** Designed to be fade-resistant and warp-resistant.



Image: An example of Timberchic wood planks installed on a living room wall, highlighting their aesthetic appeal.

3. Preparation for Installation

3.1 Acclimation

Before installation, remove the planks from their packaging and allow them to acclimate to the room's environment for 2-3 days. This helps prevent warping or movement after installation.

3.2 Surface Preparation

Ensure the wall surface is clean, dry, and smooth. Wipe walls with a damp cloth to remove any dust or debris, then allow to dry completely.

3.3 Measuring and Planning

Measure the area where the planks will be installed. If the wall is not level, measure down from the ceiling and draw a level line to guide your first row of planks. For optimal appearance, plan to stagger seams between planks.



Image: A visual guide for calculating the required square footage of planks for a wall.

3.4 Tools Required

The following tools are recommended for installation:

- Level
- Measuring Tape
- Pencil
- Utility Knife or Saw (for cutting planks)
- J-Roller (for ensuring tight bond)

4. Installation Guide

Follow these steps for a successful installation of your TIMBERCHiC wood wall planks:

1. **Prepare Planks:** Ensure planks have acclimated to the room for 2-3 days.
2. **Clean Wall:** Wipe the wall clean with a damp cloth and let it dry completely.
3. **Establish Level Line:** If your wall is not perfectly level, use a level and pencil to draw a straight guideline for your first row of planks.
4. **Peel and Stick:** Carefully peel the protective backing from the 3M adhesive strip on the back of a plank.
5. **Position and Apply:** Align the plank with your guideline or the previous row. Press firmly along the entire length of the plank onto the wall.
6. **Ensure Bond:** Use a J-roller to apply even pressure across the entire surface of the installed plank. This ensures a strong, permanent bond with the wall.
7. **Stagger Seams:** For the best aesthetic outcome, stagger the seams of subsequent rows. Cut planks as needed to fit at the ends of rows or around obstacles.
8. **Repeat:** Continue the process, working your way across and up the wall until the desired area is covered.



Image: Visual representation of the peel, stick, and transform installation process.



Image: Detail of peeling the adhesive backing from a Timberchic wood plank.



Image: A woman and child installing wood planks, illustrating the user-friendly nature of the product.

5. Care and Maintenance

TIMBERCHiC wood wall planks are designed for durability and require minimal maintenance. To keep your planks looking their best:

- **Cleaning:** Wipe with a dry or slightly damp cloth to remove dust. Avoid harsh chemical cleaners, as they may damage the wood finish.
- **Protection:** The planks are fade-resistant and warp-resistant under normal indoor conditions. Avoid prolonged exposure to direct sunlight or extreme humidity changes to preserve their appearance.
- **Repairs:** In case of minor scratches, wood repair markers or light sanding followed by a suitable wood finish can be used.

6. Troubleshooting

6.1 Adhesion Issues

If planks are not adhering properly:

- Ensure the wall surface was thoroughly cleaned and dry before application.
- Verify that sufficient and even pressure was applied with a J-roller during installation.
- The adhesive is industrial-strength and designed for a permanent bond. If a plank needs to be repositioned, it should be done quickly after initial placement, as removal can be difficult and may damage the wall surface or the plank's adhesive.

6.2 Cutting Planks

Cutting the 1/8-inch thick planks can be challenging with a utility knife. For cleaner and easier cuts, especially for multiple planks, a saw (such as a miter saw or table saw) with a fine-tooth blade is recommended. This helps prevent splitting and ensures precise edges.

7. Specifications

Feature	Detail
Brand	Timberchic
Model Number	Timberchic
Material	Pine Wood, Wood
Color	Baxter Blonde
Size	4" Wide - 20 Sq. Ft.
Item Thickness	0.13 Inches
Item Weight	7.66 pounds
Product Dimensions	43 x 4 x 4 inches
Number of Items (in pack)	10
Coverage	20 square feet
Style	Modern
Finish	Premium
UPC	850019429213

8. Support Information

For further assistance, questions, or to explore other Timberchic products, please visit the official Timberchic store or contact customer support through their website. You can also find more information and product samples via the Timberchic Store on Amazon.



Image: Timberchic sample pack, available for customers to review product options.

© 2025 Timberchic. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08P3NMZ6B

More documents and user manuals: **https://manuals.plus/**