COSORI GK172-CO

COSORI Electric Kettle User Manual

Model: GK172-CO
Brand: COSORI

1. Introduction

Thank you for choosing the COSORI Electric Kettle. This manual provides important information for the safe operation, maintenance, and troubleshooting of your new appliance. Please read all instructions thoroughly before use and retain for future reference.

Key Features:

- **Rapid Boiling:** Equipped with British Strix thermostat and 1500 watts, the hot water heater swiftly brings water to a boil, fast boiling water in few minutes. Safer than microwaves and stoves.
- **No Plastic Spout & Filter:** Our stainless steel filter and spout makes our kettle safer than others with plastic filters, even if they have a glass or stainless steel exterior.
- **Safe & Smart:** With automatic shut-off and boil-dry protection, this kettle prioritizes safety, ensuring a secure user experience.
- **Joyful Precision:** Specifically designed with a drip-free spout and scald-proof lid, effortlessly controlling water flow and preventing burns.
- **More Stylish:** This kettle features a contemporary design with a blue LED indicator light, allowing you to easily know when your water is boiling, even in a dark kitchen.
- **Versatile Glass Kettle:** More than just boiling water. Brew tea, coffee, and quick meals with ease.

2. Product Overview

The COSORI Electric Kettle is designed for efficiency and safety, featuring a durable glass body and stainless steel components for pure water contact.



Figure 1: COSORI Electric Kettle in operation, showing rapid boiling and blue LED illumination.



Figure 2: Close-up of the kettle's interior, highlighting the stainless steel filter and spout for no plastic contact with water.

3. Setup

1. **Unpacking:** Carefully remove all packaging materials and inspect the kettle for any damage.
2. **First Use Cleaning:** Before first use, fill the kettle with water to the MAX line, boil, and then discard the water. Repeat this process 2-3 times to remove any manufacturing residues.
3. **Placement:** Place the power base on a dry, flat, stable, and heat-resistant surface. Ensure it is away from the edge of the counter to prevent accidental tipping.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

4. Operating Instructions

1. **Filling the Kettle:** Open the lid by pressing the button on the handle. Fill the kettle with fresh, cold water to your desired level, ensuring it is between the MIN (0.50 L) and MAX (1.70 L) marks. Close the lid securely.

2. **Placing on Base:** Place the kettle firmly onto the power base. The 360° rotatable base allows for easy placement from any angle.
3. **Starting Boil:** Press the ON/OFF switch located on the handle downwards. The blue LED indicator light will illuminate, indicating that the kettle is heating.
4. **Automatic Shut-Off:** The kettle will automatically shut off once the water has reached a rolling boil. The blue LED light will turn off, and the switch will return to the UP position.
5. **Pouring:** Carefully lift the kettle from the base and pour the hot water. The drip-free spout ensures controlled pouring.

5. Maintenance

Cleaning:

Always unplug the kettle and allow it to cool completely before cleaning. The kettle should be hand washed. Do not immerse the power base in water.



Figure 3: The wide mouth design of the kettle allows for effortless cleaning by hand.

Descaling:

Regular descaling is recommended to maintain optimal performance, especially in areas with hard water. Follow these steps:

1. Fill the kettle with 1 cup of vinegar or lemon juice and 2 cups of water.
2. Boil the liquid and leave it for 2 hours, then use a cloth to clean and wipe.
3. Rinse the kettle with clean water, and dry with a soft, clean cloth.
4. Repeat as needed.

6. Troubleshooting

Problem	Possible Cause	Solution
Kettle does not turn on.	Not plugged in; power switch not pressed; kettle not properly seated on base.	Ensure power cord is securely plugged in. Press the ON/OFF switch down. Re-seat the kettle firmly on the power base.
Water spots or rust-like residue inside.	Mineral deposits from hard water.	Perform descaling procedure as described in the Maintenance section.
Kettle boils dry.	Insufficient water; lid left open.	Ensure water level is above MIN mark. Always close the lid securely before boiling. The kettle has boil-dry protection, but repeated occurrences can damage the unit.
Lid is difficult to open/close.	Mineral buildup or minor misalignment.	Clean around the lid mechanism. Ensure no debris is obstructing the hinge.

7. Specifications

- **Model Name:** GK172
- **Model Number:** GK172-CO
- **Brand:** COSORI
- **Color:** Black
- **Capacity:** 1.7 Liters (1.8 Quarts)
- **Power:** 1500W
- **Material:** Glass, Stainless Steel (ZERO plastic inside)
- **Product Dimensions:** 9"L x 6.3"W x 10"H
- **Item Weight:** 2.5 Pounds
- **Special Features:** Stainless Steel Filter, Automatic shutoff with accurate monitor (Strix Thermostat), No Plastic Spout, Blue LED Indicator Light
- **Included Components:** User Manual, Power Base, Electric Glass Kettle

8. Warranty and Support

COSORI provides a warranty for this product. For detailed warranty information, please refer to the official user manual provided with your purchase or visit the COSORI website.
For any questions, concerns, or issues regarding your COSORI Electric Kettle, please contact COSORI Customer Support:

Website: Visit the COSORI Store on Amazon

User Manual (PDF): Download PDF Manual

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question