Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Edifier EDF100002

EDIFIER D12 Compact Stereo Speaker System

User Manual

1. Introduction

Thank you for purchasing the Edifier D12 Compact Stereo Speaker System. This manual provides essential information for setting up, operating, and maintaining your speaker system to ensure optimal performance and longevity. Please read this manual thoroughly before using the product and retain it for future reference.

2. Package Contents

Please check the box contents. If any items are missing or damaged, contact your retailer.

- Edifier D12 Speaker System
- Wireless Remote Control
- Power Cable
- RCA to RCA Audio Cable
- 3.5mm to RCA Audio Cable
- User Manual (this document)

3. Product Overview

3.1 Speaker Front View



Figure 1: Front view of the Edifier D12 speaker system, showcasing the dual woofers and tweeters.

The front of the Edifier D12 features two 4-inch mid-bass drivers and two 19mm silk dome tweeters, designed to deliver clear and balanced audio. The wooden enclosure helps minimize acoustic resonance.

3.2 Top Panel Controls

On the top panel of the speaker, you will find three rotary knobs for easy adjustment:

- **Volume/Input Selector:** Rotate to adjust the master volume. Press to cycle through input sources (Bluetooth, AUX, Line In).
- **Treble Control:** Rotate to adjust the high-frequency output.
- **Bass Control:** Rotate to adjust the low-frequency output.

3.3 Rear Panel Connections



Figure 2: Rear panel of the Edifier D12, showing power input, power switch, and audio input/output ports.

The rear panel provides all necessary connections:

- **Power Switch:** Toggles the speaker system on or off.
- **Power Input:** Connect the supplied power cable here.
- **LINE OUT:** 3.5mm output for connecting to an external subwoofer or other active speakers.
- **AUX IN:** 3.5mm stereo input for connecting devices with a 3.5mm audio output.
- **LINE IN (L/R):** RCA stereo input for connecting devices with RCA audio outputs.

3.4 Remote Control



Figure 3: The included wireless remote control for the Edifier D12 speaker system.

The wireless remote control allows convenient operation from a distance:

- **Power Button:** Turns the speaker on/off or puts it into standby.
- **Volume Up/Down (+/-):** Adjusts the master volume.

- **Play/Pause:** Controls playback in Bluetooth mode.
- **Previous/Next Track:** Skips tracks in Bluetooth mode.
- **Movie Mode:** Activates a sound profile optimized for movies.
- **Music Mode:** Activates a sound profile optimized for music.
- **AUX:** Selects AUX input.
- **LINE:** Selects LINE IN input.
- **Bluetooth:** Selects Bluetooth input.
- **Mute:** Mutes or unmutes the audio.

4. Setup

4.1 Speaker Placement



Figure 4: The Edifier D12 speaker positioned on a flat surface in a room.

Place the speaker on a stable, flat surface such as a desk, shelf, or TV stand. For optimal stereo imaging, ensure there are no obstructions directly in front of the speaker. Avoid placing the speaker in direct sunlight or near heat sources.

4.2 Power Connection

1. Ensure the power switch on the rear panel is in the OFF position.
2. Connect the supplied power cable to the power input port on the rear panel of the speaker.
3. Plug the other end of the power cable into a wall outlet.

4.3 Audio Source Connection

Choose one of the following methods to connect your audio source:

- **AUX Input:** Use a 3.5mm to 3.5mm audio cable (not included) or the supplied 3.5mm to RCA cable (connecting to the 3.5mm end) to connect your device's headphone jack to the AUX IN port on the speaker.
- **LINE IN Input:** Use the supplied RCA to RCA audio cable to connect your device's RCA audio output (e.g., CD player, turntable with pre-amp) to the LINE IN (L/R) ports on the speaker.
- **Bluetooth:** For wireless connection, refer to the Bluetooth Pairing section in Operating Instructions.

5. Operating Instructions

5.1 Powering On/Off

1. Flip the power switch on the rear panel to the ON position. The indicator light on the front will illuminate.
2. To turn off, flip the power switch to the OFF position.

5.2 Selecting Input Source

You can select the input source using either the top panel control or the remote control:

- **Top Panel:** Press the Volume/Input selector knob repeatedly to cycle through Bluetooth, AUX, and LINE IN modes.
- **Remote Control:** Press the dedicated AUX, LINE, or Bluetooth buttons.

5.3 Bluetooth Pairing



Figure 5: The Edifier D12 speaker with a smartphone, illustrating Bluetooth connectivity.

1. Turn on the speaker and select Bluetooth input mode. The indicator light will flash rapidly, indicating it's in pairing mode.
2. On your audio device (e.g., smartphone, tablet), enable Bluetooth and search for available devices.
3. Select

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08QRSVP6N

More documents and user manuals: **https://manuals.plus/**