Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZOKOP XPB46-RS4

ZOKOP XPB46-RS4 Semi-automatic Twin Tube Washing Machine User Manual

Model: XPB46-RS4

1. Introduction

Thank you for choosing the ZOKOP XPB46-RS4 Semi-automatic Twin Tube Washing Machine. This manual provides important information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read this manual thoroughly before use and retain it for future reference.

2. Safety Instructions

WARNING: To reduce the risk of fire, electric shock, or injury, read all instructions before using this appliance.

- Ensure the power supply is 110V/60Hz as specified.
- Do not immerse the machine in water or spray water directly onto it.
- Keep children away from the appliance during operation.
- Unplug the machine from the power outlet when not in use or before cleaning.
- Do not wash waterproof clothing or items that float easily, as this may cause abnormal vibration.
- Do not open the spin tub lid until the spin cycle has completely stopped.
- Use only detergents suitable for washing machines.

3. Product Features

- Compact and portable design with powerful washing capabilities.
- Durable stainless steel washing dewatering cylinder.
- Low noise operation.
- Simultaneous washing and dehydration functions.

- Extended 2-meter drain pipe and inlet pipe for flexible placement.
- Rated washing capacity of 8 lbs (3.6 kg) and spin capacity of 5 lbs (2.2 kg).

4. Parts Identification

Familiarize yourself with the components of your washing machine.



Figure 4.1: Front view of the washing machine with control panel and twin tubs visible.



Figure 4.2: Top view of the control panel and water inlets.



Figure 4.3: Interior view of the washing tub.



Figure 4.4: Interior view of the spin tub with stainless steel drum.

Components:

- Wash Tub (left side)
- Spin Tub (right side)
- Wash Timer Knob
- Wash Selector Knob (Standard/Drain)
- Spin Timer Knob

- Water Inlets (2)
- Drain Hose (2m)
- Water Inlet Hose (2m)
- Draining Basket (for spin tub)

5. Setup and Installation

1. **Unpacking:** Carefully remove the washing machine from its packaging. Inspect for any damage during transit.
2. **Placement:** Place the machine on a flat, stable surface to minimize vibration and noise during operation. Ensure there is enough space around the machine for ventilation and access.
3. **Drain Hose Connection:** Connect the provided 2-meter drain pipe to the drain outlet on the machine. Ensure the drain hose is positioned to allow water to flow freely into a sink, bucket, or floor drain. The drain hose should not be kinked or elevated too high.
4. **Water Inlet Connection:** Connect the 2-meter water inlet hose to a water faucet. Insert the other end into one of the water inlets on the top of the washing machine. You can manually fill the wash tub or spin tub as needed.
5. **Power Connection:** Plug the power cord into a standard 110V/60Hz electrical outlet.

6. Operating Instructions

6.1 Washing Procedure

1. **Load Laundry:** Open the wash tub lid and place clothes loosely into the wash tub. Do not overload the machine; ensure clothes can move freely. The maximum washing capacity is 8 lbs.
2. **Add Water:** Fill the wash tub with water to the desired level. You can use either of the water inlets on top of the machine.
3. **Add Detergent:** Add an appropriate amount of laundry detergent directly into the wash tub.
4. **Set Wash Time:** Turn the "Wash Time" knob to select the desired washing duration (e.g., 0-15 minutes).
5. **Select Wash Mode:** Turn the "Wash Selector" knob to "Standard" for normal washing.
6. **Start Washing:** The machine will start washing automatically once the timer is set.
7. **Drain Water:** Once washing is complete, turn the "Wash Selector" knob to "Drain" to empty the water from the wash tub.

6.2 Spin Drying Procedure

1. **Transfer Laundry:** Carefully transfer the washed clothes from the wash tub to the spin tub. Ensure clothes are evenly distributed inside the spin tub to prevent imbalance.
2. **Insert Draining Basket:** Place the provided draining basket on top of the clothes inside the spin tub.
3. **Close Lid:** Close the spin tub lid securely.
4. **Set Spin Time:** Turn the "Spin Time" knob to select the desired spin duration (e.g., 0-5 minutes). The maximum spin capacity is 5 lbs.
5. **Start Spinning:** The machine will begin the spin cycle. Do not open the lid during operation.
6. **Remove Laundry:** Once the spin cycle is complete and the tub has stopped rotating, open the lid and carefully remove the spun clothes.

Note: For rinsing, you can either fill the wash tub with clean water and run a short wash cycle, or manually rinse clothes

before transferring to the spin tub.

7. Maintenance and Cleaning

Regular maintenance ensures the longevity and optimal performance of your washing machine.

- **Exterior Cleaning:** Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Interior Cleaning:** After each use, wipe down the inside of the wash and spin tubs to remove any residue. For deep cleaning, fill the wash tub with warm water and a cup of white vinegar, run a short cycle, then drain and rinse.
- **Drain Filter (if applicable):** Check and clean any lint filters or drain filters regularly to prevent blockages.
- **Storage:** When not in use for extended periods, unplug the machine, drain all water, and leave the lids open for 24 hours to allow the interior to dry completely to prevent mold and mildew. Store in a dry, well-ventilated area.

8. Troubleshooting

Problem	Possible Cause	Solution
Machine does not start	Not plugged in; power outage; timer not set.	Check power connection; ensure power is on; set wash/spin timer.
Water does not drain	Drain hose kinked or blocked; drain selector not set to "Drain".	Straighten drain hose; clear any blockages; set wash selector to "Drain".
Excessive vibration/noise during spin	Clothes unevenly distributed in spin tub; machine not on a level surface.	Redistribute clothes evenly; ensure machine is on a flat, stable surface.
Water leakage	Hoses not properly connected; tub overloaded.	Check all hose connections; reduce laundry load.

9. Specifications

Feature	Detail
Model	XPB46-RS4
Power Supply	110V/60Hz
Rated Washing Capacity	8 lbs (3.6 kg)
Rated Spin Capacity	5 lbs (2.2 kg)
Rated Wash Input Power	300W
Rated Spin Input Power	250W
Total Power	550W
Dimensions (L x W x H)	(23.23 x 13.98 x 26.57) inches / (59 x 35.5 x 67.5) cm

Feature	Detail
Weight	11 kg / 24.25 lbs
Material	Plastic PP, Stainless Steel
Motor Speed	1300 rpm/mins

10. Warranty and Support

This product is covered by a manufacturer's warranty. Please refer to your purchase documentation for specific warranty terms and conditions. For technical support, parts, or service inquiries, please contact the retailer or manufacturer directly.

Included Components:

- 1 x Twin Tube Washing Machine
- 1 x 2m Water Inlet Hose
- 1 x 2m Drain Pipe

© 2023 ZOKOP. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08R67MXX2

More documents and user manuals: **https://manuals.plus/**