Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lyght G982

Lyght Mini ATM Savings Bank Model G982 User Manual

Electronic Voice Piggy Bank with Fingerprint Password

Introduction

Thank you for choosing the Lyght Mini ATM Savings Bank, Model G982. This electronic savings bank is designed to help users manage their money with features like automatic banknote rolling, a coin slot, and a secure password-protected opening mechanism with a simulated fingerprint confirmation. Please read this manual carefully to ensure proper setup and operation of your device.



Image: Front view of the Lyght Mini ATM Savings Bank, showcasing the keypad, banknote slot, coin slot, and simulated fingerprint sensor.

Product Features

- **Electronic Deposit:** Automatically rolls in banknotes when inserted into the designated slot.
- **Coin Slot:** Accepts coins through a slot on the top of the bank.
- **Personalized Security:** Features a customizable 4-digit password for access.
- **Simulated Fingerprint Confirmation:** Enhances the interactive security experience.

- **Voice Prompts:** Provides English voice feedback for operations.
- **Storage Capacity:** Can hold approximately 600 coins or 1000 paper banknotes.
- **Durable Construction:** Made from high-quality ABS material.
- **Additional Functions:** Includes voice clock and voice alarm clock features.

Setup

1. Battery Installation

The Lyght Mini ATM Savings Bank requires 3 AA batteries (not included) for operation. Locate the battery compartment on the bottom or back of the unit. Open the compartment cover, insert the batteries according to the polarity indicators (+/-), and close the cover securely.

2. Initial Power On and Default Password

After installing batteries, the bank will power on. The default password to open the safe is **0000**. You will need this to access the contents and to set your personal password.

Operating Instructions

1. Depositing Money

- **Banknotes:** Insert banknotes into the banknote slot located at the top front of the bank. The bank will automatically roll the money inside.
- **Coins:** Drop coins into the coin slot on the top surface of the bank.



Image: Illustration of how to deposit banknotes into the automatic roller and coins into the top slot of the savings bank.

2. Opening the Safe

To open the safe and retrieve your savings, follow these steps:

1. **Enter Password:** Input your 4-digit password using the keypad. The default password is 0000.
2. **Confirm Fingerprint:** Place your finger on the simulated fingerprint sensor. The bank will provide a voice confirmation.
3. **Turn Knob:** Within 10 seconds of successful confirmation, turn the knob clockwise to unlock the door.
4. **Open Door:** Pull the door open to access the contents.



Image: Step 1 of opening the safe: A hand entering the password on the keypad.



Image: Step 2 of opening the safe: A finger placed on the simulated fingerprint sensor for confirmation.



Image: Step 3 of opening the safe: A hand turning the door knob clockwise to unlock the safe.

3. Changing Your Password

To change the password from the default 0000 or your current password:

1. With the safe door open, press and hold the '*' (star) button.
2. Enter your new 4-digit password.
3. Press the '#' (hash) button to confirm the new password.
4. Close the safe door. Your new password is now set.

Maintenance

- **Cleaning:** Wipe the exterior of the bank with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- **Battery Replacement:** Replace batteries when the voice prompts become weak or the bank stops responding. Always replace all batteries at the same time with new ones of the same type (AA).
- **Storage:** Store the bank in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

- **Bank does not power on:** Check battery installation. Ensure batteries are inserted correctly and are not depleted. Replace with new batteries if necessary.
- **Cannot open the safe:**
  - Ensure you are entering the correct 4-digit password.
  - Remember to turn the knob clockwise within 10 seconds after fingerprint confirmation.
  - If you forgot your password, remove the batteries for a few minutes to reset the bank to its default password (0000).
- **Banknote roller not working:** Ensure banknotes are inserted straight and are not crumpled or too thick. Check for any obstructions in the slot.
- **Fingerprint sensor not responding:** The fingerprint sensor is for simulated confirmation only. It does not read actual fingerprints. Ensure you are pressing it after entering the password.
- **Voice prompts are unclear or distorted:** This usually indicates low battery power. Replace the batteries.

Specifications

Feature	Detail
Product Dimensions	5.31 x 5.2 x 7.52 inches
Item Weight	1.4 pounds
Model Number	G982
Manufacturer	Shenzhen Like Electronic Co.,Ltd
Power Source	3 x AA Batteries (not included)

Warranty Information

Specific warranty details are not provided in the product information. Please refer to the retailer or manufacturer's website for current warranty policies.

Support

For further assistance or inquiries, please contact Lyght customer support through their official website or the retailer where the product was purchased. No specific contact information was provided in the product data.

Official Product Videos

No official seller videos were found in the provided product data to embed in this manual.

© 2025 Lyght. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08SC8B3VP

More documents and user manuals: **https://manuals.plus/**