Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZOKOP A201

ZOKOP A201 Portable Twin Tub Washing Machine User Manual

Model: A201 (XPB35-ZK35)

1. Introduction

Thank you for choosing the ZOKOP A201 Portable Twin Tub Washing Machine. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your appliance. Please read these instructions carefully before use and retain them for future reference.



Image: The ZOKOP A201 washing machine, demonstrating its compact and portable design suitable for small spaces.

2. Safety Instructions

To reduce the risk of fire, electric shock, or injury when using your appliance, follow these basic precautions:

- Ensure the power supply matches the voltage specified on the appliance's rating label.
- Do not operate the machine with a damaged power cord or plug.
- Keep the appliance away from heat sources and direct sunlight.
- Do not immerse the electrical parts in water or other liquids.
- Supervise children to ensure they do not play with the appliance.
- Always unplug the machine before cleaning or performing any maintenance.
- Do not overload the washing or spin tubs.
- Ensure the drain hose is properly positioned to prevent water leakage.

3. Product Overview

The ZOKOP A201 is a semi-automatic twin tub washing machine designed for washing and spin-drying clothes. It features separate tubs for washing and spinning, allowing for simultaneous operation.

Components and Controls



Image: Top view of the control panel, highlighting the Wash Timer, Wash Selector, and Spin Timer knobs.

- **Wash Timer:** Sets the duration of the wash cycle.
- **Wash Selector:** Chooses between 'Gentle' and 'Normal' wash modes, or 'Drain'.
- **Spin Timer:** Sets the duration of the spin-dry cycle.
- **Wash Tub:** For washing and rinsing clothes.
- **Spin Tub:** For spin-drying clothes.
- **Lids:** Separate lids for the wash and spin tubs. The spin tub lid is detachable for cleaning.



Image: Detachable lid and spin cap of the spin tub, illustrating ease of access for maintenance.

4. Setup

Unpacking

Carefully remove the washing machine from its packaging. Inspect for any damage incurred during transit. Retain packaging materials for potential future transport or service.

Placement

Place the washing machine on a firm, level surface to minimize vibration and noise during operation. Ensure there is adequate space around the unit for ventilation and access to water and drainage.



Image: The washing machine positioned in a bathroom, indicating a suitable environment for operation.

Water Connection

Connect the water inlet hose to a suitable water tap. Ensure the connection is secure to prevent leaks. The machine typically uses cold water for washing.

Drainage

Position the drain hose to direct wastewater into a sink, bucket, or floor drain. Ensure the hose is not kinked or obstructed to allow for proper drainage.

---

5. Operating Instructions

Washing Clothes

1. **Load Clothes:** Open the wash tub lid and place clothes loosely into the wash tub. Do not exceed the maximum load capacity of 7.7 pounds.

2. **Add Water:** Fill the wash tub with water to the appropriate level for your load size.
3. **Add Detergent:** Add the recommended amount of laundry detergent directly into the wash tub.
4. **Select Wash Mode:** Turn the 'Wash Selector' knob to either 'Gentle' for delicate items or 'Normal' for regular loads.
5. **Set Wash Timer:** Turn the 'Wash Timer' knob to the desired wash duration (e.g., 0-15 minutes). The machine will start washing.



Image: Visual representation of the washing and dewatering processes occurring simultaneously in the twin tubs.

Rinsing Clothes

1. **Drain Water:** After the wash cycle, turn the 'Wash Selector' knob to 'Drain' to empty the soapy water from the wash tub.
2. **Refill:** Close the drain and refill the wash tub with clean water.
3. **Rinse Cycle:** Set the 'Wash Timer' for a short duration (e.g., 3-5 minutes) to rinse the clothes. Repeat if necessary.
4. **Final Drain:** Drain the rinse water.

Spin Drying Clothes

1. **Transfer Clothes:** Carefully transfer the rinsed clothes from the wash tub to the spin tub.
2. **Distribute Evenly:** Arrange the clothes evenly inside the spin tub to prevent imbalance and excessive vibration.
3. **Place Spin Cap:** Place the spin cap firmly on top of the clothes in the spin tub.
4. **Close Lid:** Close the spin tub lid.
5. **Set Spin Timer:** Turn the 'Spin Timer' knob to the desired spin duration (e.g., 0-5 minutes). The machine will begin spin-drying.

---

6. Maintenance

Cleaning the Exterior

Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners or solvents that could damage the surface.

Cleaning the Spin Tub and Cap

The spin tub lid and cap are detachable for easy cleaning. Remove them periodically and rinse with water to remove any lint or residue.



Image: Detailed views of various components, including the spin tub interior, useful for maintenance.

Storage

If storing the machine for an extended period, ensure both tubs are completely drained and dry. Disconnect the power cord and store it safely.

7. Troubleshooting

If you encounter issues with your ZOKOP A201 washing machine, refer to the following common problems and solutions:

- **Machine does not start:**
  - Check if the power cord is securely plugged into a working outlet.
  - Ensure the timer knobs are set to a duration greater than zero.

- **Water does not drain:**
  - Verify the 'Wash Selector' knob is set to 'Drain'.
  - Check if the drain hose is kinked, blocked, or positioned too high.
- **Excessive vibration during spin:**
  - Ensure clothes are evenly distributed in the spin tub.
  - Confirm the machine is placed on a firm, level surface.
  - Make sure the spin cap is properly placed on top of the clothes.
- **Water leakage:**
  - Check all hose connections for tightness.
  - Ensure the drain hose is properly positioned and not overflowing.

For issues not covered here, please contact customer support.

8. Specifications

Brand	ZOKOP
Model	A201 (XPB35-ZK35)
Operation Mode	Semi-Automatic
Wash Capacity	7.7 Pounds
Maximum Rotational Speed	1300 RPM
Controls Type	Knob
Access Location	Top Load
Special Features	Lightweight, Portable
Color	White
UPC	757208835629
Dimensions (W x D x H)	21.26" x 13.78" x 25.20"



Image: Dimensional drawing of the ZOKOP A201, providing exact measurements for placement.

9. Warranty and Support

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact the seller directly. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08V4VTVT5

More documents and user manuals: **https://manuals.plus/**