Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JN B08WHBSBXW

JN 1.5 Cup One-Touch Pulse Mini Food Chopper User Manual

Model: B08WHBSBXW

Introduction

Thank you for purchasing the JN 1.5 Cup One-Touch Pulse Mini Food Chopper. This manual provides important information regarding the safe operation, maintenance, and care of your appliance. Please read these instructions thoroughly before first use and retain them for future reference.

Important Safety Information

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- To protect against electrical shock, do not immerse the motor base in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- **CAUTION: Blades are sharp. Handle with care.**
- This appliance has a **Safety Lock** feature. The motor will not operate unless the lid is properly secured on the bowl.

Parts and Features

Familiarize yourself with the components of your mini food chopper:

- **Motor Base:** Contains the motor and control button.
- **Chopping Blade:** Stainless steel blade for efficient chopping.
- **1.5 Cup Processing Bowl:** Transparent bowl with Min/Max markings.
- **Lid:** Secures the bowl and activates the safety lock.
- **One-Touch Pulse Button:** For controlled chopping.



Figure 1: Components of the JN Mini Food Chopper.



Figure 2: Fully assembled JN Mini Food Chopper.

Setup

1. Before first use, wash the processing bowl, lid, and chopping blade in warm, soapy water. Rinse thoroughly and dry. The motor base should be wiped clean with a damp cloth.
2. Place the motor base on a clean, dry, and stable surface.
3. Carefully place the chopping blade onto the center post inside the processing bowl. Ensure it sits securely.
4. Add your ingredients to the processing bowl. Do not exceed the "Max" fill line.
5. Place the lid onto the processing bowl, aligning the tabs on the lid with the slots on the bowl. Twist the lid clockwise until it locks into place.
6. Place the assembled bowl and lid onto the motor base, ensuring it is properly seated and locked. The safety lock feature prevents operation if not correctly assembled.



Figure 3: Processing bowl with Max/Min markings and lid in place.

Operating Instructions

This mini food chopper is designed for chopping various ingredients. It features a simple one-touch pulse operation.

1. Ensure the chopper is properly assembled as described in the "Setup" section.
2. Plug the power cord into a standard electrical outlet.
3. Press and hold the pulse button located on the motor base to begin chopping. The motor will run as long as the button is held down.
4. Release the pulse button to stop chopping.
5. Use short, quick pulses for coarse chopping, or hold for longer durations for finer results. Monitor the consistency of your ingredients through the transparent bowl.
6. Once chopping is complete, unplug the appliance from the outlet.
7. Carefully remove the motor base, then twist and lift the lid.
8. Remove the chopping blade before emptying the bowl. Always handle the blade by its plastic hub.



Figure 4: Detail of the One-Touch Pulse Button.

Tips for Best Results:

- Cut large ingredients into smaller, uniform pieces (approximately 1-inch cubes) before processing.
- Do not overfill the bowl. Process in batches if necessary.
- For best results with hard ingredients, use short, quick pulses.
- Avoid processing extremely hard items like coffee beans or whole spices, as this may damage the blade or motor.

Cleaning and Maintenance

Proper cleaning ensures the longevity and performance of your mini food chopper.

1. Always unplug the appliance before cleaning.
2. Remove the chopping blade, processing bowl, and lid from the motor base.

3. **Hand Wash Only:** The processing bowl, lid, and chopping blade should be washed by hand in warm, soapy water. Rinse thoroughly and dry immediately.
4. **Caution:** The chopping blade is very sharp. Handle with extreme care during cleaning.
5. Wipe the motor base with a damp cloth. Never immerse the motor base in water or any other liquid.
6. Do not use abrasive cleaners or scouring pads, as they may scratch the surfaces.
7. Ensure all parts are completely dry before reassembling or storing.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in. Lid or bowl not properly assembled/locked.	Ensure the power cord is securely plugged into a working outlet. Verify that the lid is twisted and locked onto the bowl, and the bowl is correctly seated on the motor base, engaging the safety lock.
Ingredients are not chopping evenly.	Bowl is overfilled. Ingredients are too large.	Reduce the amount of ingredients in the bowl and process in smaller batches. Cut ingredients into smaller, uniform pieces before processing.
Motor sounds strained or stops.	Overloading the motor. Hard ingredients.	Reduce the quantity of ingredients. Ensure ingredients are suitable for chopping (avoid extremely hard items). Allow the motor to cool down if it has overheated.

Specifications

- **Model:** B08WHBSBXW
- **Brand:** JN
- **Capacity:** 1.5 Cups
- **Material:** Stainless Steel (blade), Plastic (bowl, lid, base)
- **Color:** Black
- **Number of Speeds:** 1 (Pulse)
- **Special Feature:** Safety Lock
- **Product Dimensions:** 17.78 x 12.7 x 15.24 cm (7 x 5 x 6 inches)
- **Item Weight:** 708 g (1.56 lbs)
- **Care Instructions:** Hand Wash (bowl, lid, blade); Wipe clean (motor base)

Warranty and Support

For warranty information or product support, please contact the manufacturer directly. Keep your purchase receipt as proof of purchase.
For further assistance, you may visit the product page on Amazon:JN 1.5 Cup Mini Food Chopper on Amazon.ca

© 2023 JN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08WHBSBXW

More documents and user manuals: **https://manuals.plus/**