Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Eureka NEC101

Eureka NEC101 Cordless Vacuum Cleaner

INSTRUCTION MANUAL

1. Product Overview

The Eureka NEC101 is a lightweight, cordless stick vacuum designed for versatile and efficient home cleaning. Weighing just 5 lbs, it offers easy maneuverability for daily tasks. Its 2-in-1 design allows for quick conversion from a stick vacuum to a handheld unit, perfect for various surfaces and hard-to-reach areas. Equipped with a powerful 150W motor, dual cleaning modes, and built-in LED headlights, it ensures a thorough clean on hardwood, tile, and low-pile carpets.



Image: The Eureka NEC101 Cordless Vacuum Cleaner, showcasing its full stick vacuum configuration and a detached handheld unit.

2. Package Contents

Verify that all components are present in the box:



Main Vacuum Unit (Host): The primary motor and dust cup assembly.



Wall Mount Bracket: For convenient storage and charging.



Charger (MC2805A): Power adapter for battery charging.



Crevice Tool: For narrow spaces and corners.



User Manual: This instruction booklet.

3. Setup and Assembly

The Eureka NEC101 is designed for quick and intuitive assembly:

1. **Connect the Extension Wand:** Insert the top end of the extension wand into the main vacuum unit until it clicks securely into place.
2. **Attach the Floor Brush:** Connect the bottom end of the extension wand to the floor brush head, ensuring it also clicks firmly.
3. **Verify Connections:** Gently pull on each connection point to ensure they are fully engaged and stable before use.



Image: A person demonstrating the intuitive assembly of the Eureka NEC101, showing the main unit connected to the extension wand and floor head.

4. Charging the Battery

Before first use, fully charge the vacuum's lithium-ion battery. The battery provides approximately 30 minutes of runtime on a full charge, with a charging time of about 30 minutes.

- Locate the charging port on the main vacuum unit.
- Plug the charger into the port and then into a standard wall outlet.
- The battery indicator lights on the unit will illuminate to show charging status and remaining battery life.

5. Operating Instructions

Power Modes

The NEC101 features dual power modes to suit different cleaning needs:

- **Low Mode:** Ideal for delicate surfaces like hardwood and tile floors, offering efficient suction for everyday dust and debris.
- **High Mode:** Provides stronger suction for deeper cleaning on low-pile carpets and more stubborn messes.

LED Headlights

The integrated LED headlights on the floor brush illuminate hidden dirt and dust under furniture and in dimly lit areas, ensuring no spot is missed.



Image: A close-up view of the vacuum's floor head, highlighting its bright LED headlights illuminating the floor.

2-in-1 Versatility

Easily convert your stick vacuum into a portable handheld unit for targeted cleaning:

- Press the release button to detach the main vacuum unit from the extension wand.
- Attach the crevice tool directly to the handheld unit for cleaning upholstery, stairs, car interiors, and tight corners.



Image: A person using the Eureka NEC101 in handheld mode to clean carpeted stairs, demonstrating its versatility.

Maneuverability

The swivel steering allows the vacuum head to pivot easily, making it simple to navigate around furniture and obstacles for a comprehensive clean.



Image: The Eureka NEC101 vacuum cleaning under a low piece of furniture, showcasing its flexible swivel steering.

6. Maintenance and Care

Emptying the Dust Cup

The 0.5L dust cup is designed for easy, mess-free disposal:

- Hold the vacuum over a trash bin.
- Press the dust cup release button to open the bottom flap and empty contents.
- Close the flap securely after emptying.



Image: A hand demonstrating the easy emptying process of the Eureka NEC101's dust cup directly into a trash bin.

Washing the Filter

The foam filter is washable for prolonged performance:

- Twist and remove the dust cup from the main unit.
- Remove the foam filter from inside the dust cup.
- Rinse the filter under running water until clean.
- Allow the filter to air dry completely for at least 24 hours before reinserting it into the dust cup. Ensure it is completely dry to prevent damage to the motor.

7. Troubleshooting

If you encounter issues with your Eureka NEC101, try these common solutions:

- **No Power:** Ensure the battery is fully charged. Check that the charger is properly connected to both the vacuum and the power outlet.

- **Reduced Suction:** Empty the dust cup if it's full. Check and clean the foam filter, ensuring it's dry before reassembly. Inspect the floor brush and extension wand for any blockages.
- **Brush Roll Not Spinning:** Check for hair or debris tangled around the brush roll and clear it. Ensure the floor brush is securely attached to the extension wand.

For persistent issues, refer to the detailed troubleshooting section in your user manual or contact customer support.

8. Product Specifications

Brand	Eureka
Model Name	Cordless Vacuum Cleaner (NEC101)
Item Weight	5 pounds
Product Dimensions	9.9"L x 6.2"W x 43.1"H
Runtime	30 minutes
Charging Time	30 minutes
Capacity	0.5 Liters
Wattage	150 watts
Filter Type	Foam (Washable)
Special Features	Lightweight, Headlight, Washable Filter
Recommended Uses	Bare Floor, Hardwood, Tile Floor, Carpet

9. Warranty and Customer Support

The Eureka NEC101 Cordless Vacuum Cleaner comes with a 1.5-year limited warranty. For warranty claims, technical support, or additional assistance, please visit the official Eureka website or contact their customer service department. Keep your purchase receipt for warranty validation.

For more information, visit the Eureka Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08YNMQ1MC

More documents and user manuals: **https://manuals.plus/**