Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lyght 982

Lyght Kids Safe Box Model 982 Instruction Manual

Electronic Piggy Bank with Fingerprint and Code Access

1. Important Safety Information

- This product is suitable for children over 6 years old.
- Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Always insert batteries correctly, observing the + and - polarities.
- Remove batteries if the product is not used for an extended period.
- Keep small parts away from young children to prevent choking hazards.

2. Package Contents

- 1 x Lyght Kids Safe Box Model 982
- 1 x Instruction Manual (this document)

3. Product Overview

The Lyght Kids Safe Box is an electronic piggy bank designed to help children learn about saving money. It features a password-protected door, a simulated fingerprint sensor, and slots for both coins and banknotes.



Image: Front view of the Lyght Kids Safe Box in pink, showing the keypad, fingerprint sensor, and slots.

Key Components:

- **Coin Slot:** Located on the top for depositing coins.
- **Banknote Slot:** Located on the front for automatic feeding of banknotes.
- **Keypad:** For entering the security password.
- **Fingerprint Sensor:** A simulated sensor for confirming access after entering the password.
- **Door Knob:** Used to open the safe door after successful authentication.
- **Battery Compartment:** Located at the bottom of the safe box.

4. Setup

4.1 Battery Installation

1. Locate the battery compartment cover on the bottom of the safe box.
2. Use a screwdriver to open the battery compartment.
3. Insert 3 AA batteries (not included), ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

▶ **Watch video online**
Pass code:0000.

Video: Demonstration of battery installation and initial setup for the safe box.

4.2 Initial Password

The default password for the safe box is **0000**.

1. Enter the default password "0000" on the keypad.
2. Press the simulated fingerprint sensor.
3. Turn the door knob clockwise to open the door.

4.3 Setting a New Password

1. With the safe door open, press and hold the '*' (star) button on the keypad.
2. While holding the '*' button, enter your desired new 4-digit password.
3. Press the '#' (hash) button to confirm the new password.
4. Release the '*' button. Your new password is now set.



Image: Visual guide for entering the password and opening the safe door.



Image: Illustration of the safe box keypad, relevant for password setting.

5. Operation

5.1 Depositing Money

- **Banknotes:** Place banknotes into the banknote slot on the front. The safe box will automatically roll them in.
- **Coins:** Insert coins into the coin slot on the top of the safe box.



Image: A banknote being inserted into the safe box's automatic feeder.



Image: A child depositing a coin into the safe box.

5.2 Opening the Safe

1. Enter your 4-digit password on the keypad.
2. Press the simulated fingerprint sensor. The sensor will light up and a voice prompt will confirm.
3. Turn the door knob clockwise to open the door.



Image: Interior view of the safe box with the door open.

5.3 Voice Settings

The safe box features adjustable voice prompts. You can choose between voice mode and silent mode to suit your preference. Refer to the specific button on the keypad (often marked with a speaker icon) or consult the quick start guide for detailed instructions on toggling this feature.

▶ **Watch video online**
kids safe box piggy bank for boys girls

Video: Official video demonstrating the features and basic operation of the Lyght Kids Safe Box, including depositing money and opening the safe.

▶ **Watch video online**
ATM Savings Piggy Bank Password Safe Great Gift for Kids

Video: Official video showcasing the Lyght Kids Safe Box as an ATM savings bank, highlighting its password and fingerprint features for children.

6. Maintenance

6.1 Battery Replacement

When the safe box's sounds become faint or the door mechanism slows down, it is time to replace the batteries. Follow the battery installation steps in Section 4.1.

6.2 Cleaning

Wipe the exterior of the safe box with a soft, dry cloth. Do not use abrasive cleaners or immerse the product in water.

7. Troubleshooting

7.1 Safe Door Does Not Open

- **Incorrect Password:** Ensure you are entering the correct 4-digit password. If you forgot your password, remove and reinsert the batteries to reset it to the default "0000".
- **Low Batteries:** Replace the batteries with fresh ones.
- **Knob Not Turned:** After entering the password and pressing the fingerprint sensor, ensure you turn the door knob clockwise within 5 seconds.

7.2 Fingerprint Sensor Functionality

The fingerprint sensor on this safe box is a **simulated feature**. It is designed to add an extra layer of fun and security confirmation after the password is entered, but it does not scan actual fingerprints. Any finger will activate the sensor after the correct password has been input.

7.3 Unexpected Alarms or Sounds

If the safe box emits unexpected alarms, check the following:

- Ensure the door is closed properly after use.
- Verify that the password was entered correctly. Repeated incorrect entries may trigger an alarm.
- Check the voice settings (Section 5.3) if the sounds are too loud or unwanted.

8. Specifications



Image: Dimensions of the Lyght Kids Safe Box.



Image: Illustration of the safe box's capacity for banknotes and coins.

Feature	Detail
Brand	Lyght
Model Number	982
Material Type	Plastic
Color	Pink/Pink
Item Dimensions (L x W x H)	5.3"L x 5.2"W x 7.52"H
Item Weight	1.2 pounds
Banknote Capacity	Up to 1000 pieces
Coin Capacity	Up to 600 pieces
Power Source	3 x AA Batteries (not included)

9. Warranty and Support

For any product inquiries, technical support, or warranty information, please contact the seller or manufacturer directly through your purchase platform. Please retain your proof of purchase for any warranty claims.

You can also visit the official Lyght store for more information:Lyght Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08Z3XLPVB

More documents and user manuals: **https://manuals.plus/**