Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Panasonic MC-CG373G

Panasonic MC-CG373G Canister Vacuum Cleaner Instruction Manual

Model: MC-CG373G | Brand: Panasonic

1. Safety Information

Please read all instructions carefully before using this appliance. Keep this manual for future reference.

- Ensure the power supply voltage matches the rating label on the vacuum cleaner.
- Do not operate the vacuum cleaner with a damaged cord or plug.
- Do not use the appliance to pick up water or wet materials.
- Avoid vacuuming hot ashes, burning cigarettes, or sharp objects.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Unplug the appliance from the power outlet before cleaning or performing maintenance.
- This appliance is for household use only.

2. Product Overview

The Panasonic MC-CG373G is a powerful and efficient canister vacuum cleaner designed for effective home cleaning.

Key Features:

- **Power:** 1800 Watts for strong suction.
- **Capacity:** 1.4 Liters dust container.
- **Filtration:** Equipped with a HEPA exhaust filter for cleaner air.
- **Portability:** Lightweight at 4 kg with a large front handle for easy carrying.
- **Nozzles:** Includes two nozzles, one being a Full Capture Nozzle for thorough cleaning.
- **Design:** Elegant finishing with a diamond cut design.
- **Cord Length:** 5-meter cable, providing an 8-meter cleaning radius.

Components:



Figure 2.1: Overview of the Panasonic MC-CG373G Canister Vacuum Cleaner, showing the main unit, hose, and cleaning wand.



Figure 2.2: The Full Capture Nozzle, illustrating its ability to clean effectively in both open and closed positions, ensuring no dirt is missed.



Figure 2.3: Location of the HEPA Exhaust Filter, which helps to trap fine dust and allergens, releasing cleaner air.

3. Setup

Follow these steps to assemble your vacuum cleaner before first use:

1. **Attach the Hose:** Insert the flexible hose into the suction inlet on the main unit until it clicks securely into place.
2. **Connect the Wand:** Connect the metal extension wand to the handle of the flexible hose. Ensure it is firmly attached.
3. **Attach the Nozzle:** Securely attach your desired cleaning nozzle (e.g., Full Capture Nozzle) to the end of the extension wand.
4. **Check Dust Container:** Ensure the dust container is properly installed and empty before use.
5. **Power Connection:** Extend the power cord and plug it into a suitable 230V electrical outlet.



Figure 3.1: The Panasonic MC-CG373G vacuum cleaner fully assembled and ready for use, showcasing its compact design.

4. Operating Instructions

Operating your Panasonic vacuum cleaner is straightforward:

1. **Power On:** Press the power button located on the main unit to turn on the vacuum cleaner.
2. **Adjust Suction (if applicable):** Some models may have adjustable suction power. Refer to the controls on your unit.
3. **Start Cleaning:** Move the nozzle across the surface you wish to clean. For optimal results, use slow, overlapping strokes.
4. **Using Attachments:** Utilize the included crevice tool for tight spaces and the upholstery attachment for furniture and curtains.
5. **Power Off:** After cleaning, press the power button again to turn off the appliance.
6. **Cord Rewind:** Gently pull the power cord to activate the automatic cord rewind feature.



Figure 4.1: The vacuum cleaner's large front handle, making it easy to carry and maneuver during operation.

▶ **Watch video online**

Video 4.1: This video demonstrates the portability and ease of use of the Panasonic MC-CG373G vacuum cleaner, highlighting its compact design and powerful suction for efficient cleaning.

5. Maintenance

Regular maintenance ensures optimal performance and extends the life of your vacuum cleaner.

1. **Emptying the Dust Container:** Empty the dust container regularly, ideally after each use or when it reaches the 'MAX' fill line. To empty, detach the hose, open the container lid, and dispose of the contents.
2. **Cleaning the Filters:** The HEPA exhaust filter should be checked and cleaned periodically. Gently tap the filter to remove loose dust. If washable, rinse under cold water and allow to air dry completely before reinserting. Do not use detergents or hot water.
3. **Cleaning Nozzles and Attachments:** Remove any tangled hair, threads, or debris from the cleaning nozzles and attachments.
4. **Wiping the Unit:** Wipe the exterior of the vacuum cleaner with a soft, damp cloth. Do not use abrasive cleaners or solvents.

6. Troubleshooting

If you encounter any issues with your vacuum cleaner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum cleaner does not turn on.	No power supply; power cord not plugged in; power button not pressed.	Check power outlet; ensure cord is securely plugged in; press power button firmly.
Low suction power.	Dust container full; filters clogged; hose or nozzle blocked.	Empty dust container; clean or replace filters; check hose and nozzle for obstructions.
Unusual noise during operation.	Foreign object in hose/nozzle; motor issue.	Turn off and unplug the unit, then check for and remove any obstructions. If noise persists, contact customer support.
Overheating.	Clogged filters; blocked airflow.	Turn off and unplug the unit. Allow it to cool down. Clean all filters and check for blockages in the hose or nozzle.

7. Specifications

Detailed technical specifications for the Panasonic MC-CG373G Canister Vacuum Cleaner:

Brand Name: Panasonic

Model Number: MC-CG373D

Product Type: Canister Vacuum Cleaner

Power Source: Corded Electric

Wattage: 1800 Watts

Voltage: 230 Volts

Capacity: 1.4 Liters

Item Weight: 4 Kilograms

Product Dimensions (L x W x H): 37.6 cm x 25.6 cm x 21.9 cm

Color: Orange

Noise Level: 60 Decibels

Special Features: Wheels

Surface Recommendation: Upholstery (and general floor cleaning)

Included Components: Cleaner (main unit), two nozzles, metal wand, crevice tool, upholstery attachment.

Manufacturer: Panasonic Marketing Middle East and Africa FZE

Country of Origin: Malaysia

8. Warranty and Support

Your Panasonic MC-CG373G Canister Vacuum Cleaner comes with a manufacturer's warranty.

- **Warranty Period:** This product carries a manufacturer's warranty for 1 year from the date of purchase.
- **Claiming Warranty:** For maintenance or further details regarding your warranty, you can contact the manufacturer/agent directly.
- **Additional Support:** For general inquiries or assistance, you may also contact Amazon customer service.

© 2026 Panasonic. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08ZYDPZJ5

More documents and user manuals: **https://manuals.plus/**