Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hatteker WKUS-113b

Hatteker Electric Pro Li Hair Clippers

MODEL: WKUS-113B USER MANUAL

1. Important Safety Instructions

To reduce the risk of electric shock, injury, or damage, please read all instructions carefully before using this appliance. Keep this manual for future reference.

- Do not immerse the appliance in water while charging.
- Keep the appliance away from water when not in use or when charging.
- Do not use the appliance if it is damaged or if the cord is frayed.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities unless they have been given supervision or instruction.
- Keep out of reach of children.
- Only use the provided USB charging cable.
- Unplug the appliance before cleaning or performing maintenance.

2. Product Overview & Package Contents

The Hatteker Electric Pro Li Hair Clipper is a versatile grooming tool designed for precise hair cutting, outlining, and beard trimming. It features a durable ceramic T-blade, is fully washable, and offers cordless operation.



Image 1: Hatteker Electric Pro Li Hair Clipper. This image displays the main unit of the hair clipper, highlighting its sleek design and T-blade.

Key Features:

- **Whole Body Washable:** IPX6 waterproof rating for easy cleaning under running water.
- **USB Fast Charge:** USB Type-C charging, 2 hours for a full charge, providing up to 180 minutes of cordless use.
- **Titanium Ceramic T-Blade:** Zero-gapped design for precise outlining without irritating the scalp.
- **Magnetic Guide Combs:** Includes 1mm, 2mm, and 3mm guide combs for various hair lengths.
- **LED Display:** Indicator light shows charging status (red for low/charging, green for full/working).

Package Contents:



Image 2: Package Contents. This image shows all items included in the box: the hair clipper, guide combs, USB charging cable, and cleaning brush.

- Hatteker Electric Pro Li Hair Clipper
- 3 Magnetic Guide Combs (1mm, 2mm, 3mm)

- USB Type-C Charging Cable
- Cleaning Brush
- User Manual

3. Setup

3.1 Charging the Clipper

1. Insert the USB Type-C end of the charging cable into the port at the bottom of the clipper.
2. Connect the USB-A end of the cable to a USB power adapter (not included), laptop, power bank, or car charger.
3. The LED indicator light will show red while charging.
4. A full charge takes approximately 2 hours. The LED indicator will turn green when fully charged.



Image 3: Charging Method. This image illustrates how to connect the USB-C cable to the clipper and various power sources like a wall adapter, power bank, or car charger.

3.2 Attaching Guide Combs

The clipper comes with magnetic guide combs for easy attachment and removal.

1. Select the desired guide comb (1mm, 2mm, or 3mm) based on the hair length you wish to achieve.
2. Align the guide comb with the clipper blade and gently place it over the blade. The magnets will secure it in place.
3. To remove, simply pull the guide comb away from the blade.



Image 4: Magnetic Guide Combs. This image shows the different sizes of magnetic guide combs (1.5mm, 3.0mm, 4.5mm, 6.0mm) and how they attach to the clipper head. Note: Actual included sizes are 1mm, 2mm, 3mm.

4. Operating Instructions

4.1 General Hair Trimming

1. Ensure the clipper is fully charged.
2. Attach the desired guide comb for the desired hair length.
3. Press the power button to turn on the clipper. The LED indicator will turn green.
4. Hold the clipper with the blade flat against the hair and move it slowly against the direction of hair growth.
5. For best results, ensure hair is clean and dry.

4.2 Outlining and Zero-Gapped Trimming

The zero-gapped T-blade is ideal for precise outlining, detailing, and creating sharp lines.

1. Remove any guide comb for the closest cut.
2. Turn on the clipper.
3. Hold the clipper at a slight angle to the skin, using the edge of the blade to create sharp lines around the neckline, sideburns, or beard.
4. Use short, controlled strokes for accuracy.



Image 5: Precision Trimming. This image demonstrates the clipper's ability to create sharp lines and intricate designs, highlighting its zero-gapped blade for detailed work.

4.3 Beard Trimming

Use the guide combs for an even beard length or the bare blade for shaping and detailing.



Image 6: Beard Trimming. This image shows the clipper being used to trim and shape a beard, demonstrating its versatility for facial hair.

5. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your clipper.

5.1 Cleaning the Clipper

1. Turn off the clipper and disconnect it from the charging cable.
2. Remove any attached guide combs.
3. Use the provided cleaning brush to brush away loose hairs from the blade and inside the clipper head.
4. Since the clipper is IPX6 waterproof, you can rinse the entire unit under running water. Ensure the water is not excessively hot.
5. After rinsing, shake off excess water and allow the clipper to air dry completely before storing or recharging.



Image 7: Waterproof Cleaning. This image shows the hair clipper being rinsed under running water, demonstrating its full washability.

5.2 Blade Care

The ceramic blade is designed for durability. For optimal performance, ensure it is kept clean and free of hair buildup.

- Do not attempt to sharpen the blades yourself.
- Avoid dropping the clipper, as this may damage the ceramic blade.

6. Troubleshooting

Problem	Possible Cause	Solution
Clipper does not turn on.	Battery is depleted.	Charge the clipper for at least 2 hours.
Clipper not charging.	Loose connection or faulty cable/adapter.	Ensure USB cable is securely connected. Try a different USB port or adapter.
Poor cutting performance.	Blades are clogged with hair.	Clean the blades thoroughly with the brush and rinse under water.
Clipper pulls hair.	Blades are dull or clogged.	Clean the blades. If the problem persists, contact customer support.

7. Specifications

Feature	Detail
Model Number	WKUS-113b
Power Source	Battery Powered (Rechargeable)
Charging Time	Approx. 2 hours
Run Time	Up to 180 minutes
Waterproof Rating	IPX6 (Whole Body Washable)
Blade Material	Ceramic
Connector Type	USB Type-C
Guide Combs Included	1mm, 2mm, 3mm
Dimensions	8.78 x 6.61 x 2.13 inches
Weight	10.55 ounces
Manufacturer	Hatteker

8. Warranty and Support

Hatteker products are manufactured to high-quality standards. For any warranty claims, technical support, or product inquiries, please refer to the warranty information provided at the time of purchase or contact Hatteker customer service directly through their official website or the retailer where the product was purchased.

Please retain your proof of purchase for warranty purposes.

© 2023 Hatteker. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B091BNL7TP

More documents and user manuals: **https://manuals.plus/**