Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun 7322118634

Braun MultiQuick 7 Hand Blender Motor Instruction Manual

Model: 7322118634

Introduction

This manual provides essential information for the safe and effective use of your Braun MultiQuick 7 Hand Blender Motor (Model 7322118634). This motor is a genuine Braun spare part designed for compatibility with all Braun MultiQuick 7 hand blenders. It features a powerful 1000-watt motor with Smart Speed Control and a silent DC motor, operating at 13300 RPM.
Please read these instructions thoroughly before installation and operation. Keep this manual for future reference.

Safety Information

- Always unplug the appliance before assembling, disassembling, or cleaning.
- Do not immerse the motor unit in water or any other liquid. Clean with a damp cloth only.
- Keep hands, hair, clothing, and utensils away from moving parts during operation.
- This motor is designed for use with compatible Braun MultiQuick 7 hand blender attachments only.
- Ensure the motor is securely attached to the blending shaft before use.
- Do not operate the appliance if the motor unit or cord is damaged.

Setup and Assembly

The Braun MultiQuick 7 motor unit is designed for easy attachment to various compatible accessories.

1. **Unpacking:** Carefully remove the motor unit from its packaging. Retain packaging for storage or return if necessary.
2. **Initial Cleaning:** Before first use, wipe the motor unit with a damp cloth. Do not submerge.
3. **Attaching Accessories:** Align the motor unit with the desired MultiQuick 7 accessory (e.g., blending shaft, whisk, chopper). Push the motor unit onto the accessory until it clicks securely into place.



Image: Illustrates the process of detaching or attaching the motor unit to a blending part. The motor unit is shown being separated from the lower blending part.

4. **EasyClick Plus System:** The EasyClick Plus system ensures a secure and simple attachment. To detach, press the release buttons on the sides of the motor unit and pull the accessory off.



Image: A circular graphic demonstrating the EasyClick Plus system. Hands are shown pressing release buttons on the motor unit to detach it from an accessory, with arrows indicating the action.

Operating Instructions

The Braun MultiQuick 7 motor features Smart Speed Control for intuitive operation.

1. **Power Connection:** Once the motor unit is securely attached to an accessory, plug the power cord into a suitable electrical outlet.
2. **Smart Speed Control:** The motor's speed is controlled by how much pressure you apply to the main power button. Press gently for lower speeds and harder for higher speeds.



Image: A hand gripping the Braun MultiQuick 7 motor unit, demonstrating the ergonomic design and placement of the power button.

3. **Power Indicator:** The motor unit includes a power indicator light that illuminates when the unit is powered on and ready for use.



Image: A close-up view of the top part of the Braun MultiQuick 7 motor, showing the illuminated power indicator with green bars, indicating power level or readiness.

4. **ActiveBlade Technology:** When using the blending shaft, the ActiveBlade technology allows the shaft to move up and down, blending even the hardest foods with less effort.



Image: An illustration showing the ActiveBlade mechanism of the blending shaft, with green arrows indicating its vertical movement for enhanced blending.

5. **Continuous Operation:** Do not operate the motor continuously for more than 60 seconds with heavy loads to prevent overheating. Allow a short break between cycles.

Maintenance and Cleaning

Proper maintenance ensures the longevity and performance of your Braun MultiQuick 7 motor unit.

- **Motor Unit Cleaning:** The motor unit itself is not dishwasher safe and should never be immersed in water. Wipe the exterior with a damp cloth and mild detergent, then dry thoroughly.
- **Accessory Cleaning:** Detach all accessories from the motor unit. Most MultiQuick 7 accessories (blending shaft, whisk, chopper bowl) are dishwasher safe or can be washed by hand with warm soapy water. Refer to the specific accessory's manual for detailed cleaning instructions.

- **Storage:** Store the motor unit and accessories in a dry, clean place, away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Motor does not start.	Not plugged in; power outlet faulty; motor unit not properly attached to accessory.	Ensure plug is firmly in outlet; test outlet with another appliance; re-attach motor unit until it clicks.
Motor stops during operation.	Overheating due to prolonged use or heavy load; food blockage.	Unplug and let cool for 15-30 minutes; clear any food blockage from the accessory.
Unusual noise or vibration.	Accessory not properly attached; damaged accessory or motor.	Re-attach accessory securely; inspect accessory and motor for visible damage. If damage is present, discontinue use and contact service.

Specifications

Feature	Detail
Brand	Braun
Model Number	7322118634
Type	Hand Blender Motor (Spare Part)
Body Material	Plastic
Wattage	1000 watts
Motor Type	Powerful, Silent DC motor
RPM	13300
Speed Control	Smart Speed Control
Color	Black and Silver
Compatibility	All Braun MultiQuick 7 Hand Blenders
Item Weight	710 g
Package Dimensions	20.6 x 16 x 10.6 cm

Warranty and Support

This Braun MultiQuick 7 Hand Blender Motor comes with an International Warranty. For specific warranty terms and conditions, please refer to the warranty card included with your original product purchase or visit the official Braun website.

For technical support, spare parts, or service inquiries, please contact Braun customer service in your region. You may

also visit the official Braun website for a list of authorized service centers.



Image: The Braun Service logo, indicating official support channels.

Extended warranty options may be available from third-party providers. Please review their terms and conditions carefully.

© 2025 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09231LX78

More documents and user manuals: **https://manuals.plus/**