Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Panasonic TH-32H400E

Panasonic TH-32H400E 32 Inch HD LED TV User Manual

Model: TH-32H400E

Introduction

Thank you for purchasing the Panasonic TH-32H400E 32 Inch HD LED TV. This manual provides essential information for the safe and efficient use of your new television. Please read it thoroughly before operating the device and keep it for future reference.



Image: Front view of the Panasonic TH-32H400E 32 Inch HD LED TV.

Safety Information

To ensure safe operation and prevent damage, please observe the following safety precautions:

- Do not expose the TV to rain or moisture to prevent fire or electric shock.
- Ensure proper ventilation. Do not block ventilation openings.
- Place the TV on a stable, level surface to prevent it from falling.
- Keep the TV away from direct sunlight, heat sources, and extreme temperatures.
- Do not open the TV casing. Refer all servicing to qualified personnel.
- Unplug the power cord during lightning storms or when unused for long periods.

Package Contents

Verify that all items are included in the package:

- Panasonic TH-32H400E 32 Inch HD LED TV
- TV Stand
- Remote Control
- Power Cord
- User Manual (this document)

Setup

1. Attaching the Stand

Carefully place the TV screen-down on a soft, clean surface. Align the stand with the mounting holes on the bottom of the TV. Secure the stand using the provided screws. Ensure the stand is firmly attached before placing the TV upright.



Image: Side view of the TV, illustrating the attached stand.

2. Connecting Power

Plug the power cord into the TV's power input, then plug the other end into a wall outlet. The TV supports AC 100-240V, 50-60Hz.

3. Connecting External Devices

Your TV is equipped with various ports for connecting external devices:

- **HDMI:** Connect Blu-ray players, game consoles, or set-top boxes. This model has 1 HDMI port.
- **USB:** Connect USB storage devices for media playback. This model has 1 USB 3.0 port.
- **Antenna/Cable:** Connect your antenna or cable TV signal.

4. Initial Setup

Upon first power-on, the TV will guide you through the initial setup process. This typically includes selecting your preferred language (English is supported), scanning for available channels, and setting the time zone.

Operating

1. Remote Control

The TV is controlled using the included infrared remote control. Point the remote directly at the TV's IR sensor for optimal response.

2. Basic Functions

- **Power:** Press the power button to turn the TV on or off.
- **Volume:** Use the volume up/down buttons to adjust the sound level.

- **Channel:** Use the channel up/down buttons to change channels.
- **Mute:** Press to temporarily turn off the sound.

3. Input Selection

Press the 'Input' or 'Source' button on your remote control to switch between connected devices (e.g., HDMI 1, USB, TV Tuner).

4. Picture and Sound Settings

Access the TV's menu to customize picture (brightness, contrast, color) and sound (bass, treble, sound mode) settings to your preference.

5. Internet Services

This TV may support various internet services. Depending on regional availability and specific TV software, it could potentially support streaming platforms like Netflix, Hulu, and Amazon Prime Video.

Maintenance

To maintain your TV's performance and appearance:

- **Cleaning the Screen:** Gently wipe the screen with a soft, dry, lint-free cloth. For stubborn marks, use a screen-cleaning solution specifically designed for TVs, applied to the cloth, not directly to the screen.
- **Cleaning the Cabinet:** Wipe the TV cabinet with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Ventilation:** Ensure the ventilation openings on the back of the TV are not blocked by dust or debris.

Troubleshooting

Refer to the table below for common issues and their solutions:

Problem	Possible Cause	Solution
No power	Power cord disconnected; outlet not working	Check power cord connection; test outlet with another device.
No picture, but sound is present	Incorrect input source selected; external device off	Press 'Input' button to select correct source; ensure external device is on.
No sound, but picture is present	Volume muted or too low; audio cables loose	Unmute or increase volume; check audio cable connections.
Remote control not working	Batteries dead or incorrectly inserted; obstruction between remote and TV	Replace batteries; ensure clear line of sight to TV's IR sensor.

Specifications

Detailed technical specifications for the Panasonic TH-32H400E TV:

Feature	Detail
Brand Name	Panasonic

Feature	Detail
Model Number	TH-32H400E
Model Series	H400E
Screen Size	32 Inch
Display Technology	LED
Resolution	1366x768 Pixels (HD)
Refresh Rate	60 Hz
Aspect Ratio	16:9
Image Contrast Ratio	3000:1
Viewing Angle	178 Degrees
Speaker Description	Total Audio Power Output 10W
Surround Sound Channel Configuration	2.0
Connectivity Technology	HDMI
Total HDMI Ports	1
Total USB 3.0 Ports	1
Control Method	Remote
Remote Control Technology	Infrared
Mounting Type	Tabletop
VESA Mounting Standard	200 x 200 mm
Color	Black
Dimensions (W x D x H)	732 × 178 × 479 mm
Item Weight	4.85 kg
Line Voltage	AC 100-240V, 50-60Hz
Year of Manufacture	2021
Water Resistance Level	Not Water Resistant

Warranty and Support

Your Panasonic TH-32H400E TV comes with a limited warranty. For specific warranty terms and conditions, please refer to the warranty card included in your package or visit the official Panasonic website for your region.

For technical support, service inquiries, or to purchase accessories, please contact Panasonic customer service through their official channels. Contact information can typically be found on the Panasonic website or in your product documentation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B092DX65DV

More documents and user manuals: **https://manuals.plus/**