Manuals+
Q & A | Deep Search | Upload

Ledwood Xtreme 240

LEDWOOD Xtreme 240 Portable Bluetooth Speaker User Manual

Model: Xtreme 240

1. Important Safety Instructions

Please read these instructions carefully before using the device and keep them for future reference. Improper use may result in electric shock, fire, or other hazards.

- Do not expose the speaker to extreme temperatures, direct sunlight, or high humidity.
- Do not immerse the speaker in water. While it is IPX5 splash-resistant, it is not waterproof.
- Keep the speaker away from heat sources, such as radiators, stoves, or other heat-producing appliances.
- Use only the provided charging cable or a certified equivalent.
- Do not attempt to disassemble, repair, or modify the speaker yourself. Contact qualified service personnel for any repairs.
- Keep out of reach of children.

2. Package Contents

Ensure all items are present in the package:

- 1 x LEDWOOD XT240 Portable Bluetooth Speaker
- 1 x USB-C Charging Cable
- 1 x AUX Cable (3.5mm)
- 1 x Carrying Strap
- 1 x User Manual

3. Product Overview

Figure 3.1: Front view of the LEDWOOD Xtreme 240 speaker, showcasing the main speaker grille and integrated blue LED lights on the sides.

Figure 3.2: Top view of the LEDWOOD Xtreme 240 speaker, highlighting the control panel buttons and the protective flap covering the charging and input ports.

3.1. Controls and Ports

Familiarize yourself with the speaker's controls and connection ports:

- **Power Button:** Press and hold to turn the speaker On/Off. Short press to change LED light modes.
- **Mode Button (M):** Short press to switch between Bluetooth, AUX, USB, and FM Radio modes.
- **Play/Pause Button (►/–):** Short press to play or pause music. In FM mode, short press to auto-scan.
- **Volume Down / Previous Track Button (-/◀◀):** Short press for previous track. Press and hold to decrease volume.
- **Volume Up / Next Track Button (+/►►):**Short press for next track. Press and hold to increase volume.
- **USB-C Charging Port:** For charging the speaker.
- **USB Port:** For USB flash drive playback.
- **AUX Input (3.5mm):** For connecting external audio devices via AUX cable.

4. Getting Started

4.1. Charging the Speaker

1. Connect the USB-C charging cable to the speaker's USB-C port.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate. Once fully charged, the light will change or turn off.
4. A full charge provides approximately 5 hours of playback.

4.2. Power On/Off

- **To Power On:** Press and hold the Power button for a few seconds until you hear an audible prompt and the LED lights activate.
- **To Power Off:** Press and hold the Power button again for a few seconds until you hear an audible prompt and the LED lights turn off.

5. Operation Modes

5.1. Bluetooth Mode

Figure 5.1: Wireless Connection Icon

Figure 5.2: iOS/Android Compatibility Icon

1. Turn on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED light.
2. Enable Bluetooth on your device (smartphone, tablet, etc.).
3. Search for "LEDWOOD XT240" in your device's Bluetooth list and select it to pair.
4. Once successfully paired, the speaker will emit an audible confirmation, and the LED light will stop flashing.
5. You can now play audio from your device through the speaker.

5.2. AUX Mode

1. Turn on the speaker.
2. Connect one end of the 3.5mm AUX cable to the speaker's AUX input port.
3. Connect the other end of the AUX cable to the audio output jack of your external device.
4. Press the **Mode (M)** button to switch to AUX mode. The speaker will indicate the mode change.
5. Play audio from your external device. Volume can be controlled via both the speaker and your device.

5.3. USB Playback Mode

1. Turn on the speaker.
2. Insert a USB flash drive containing MP3 audio files into the speaker's USB port.
3. Press the **Mode (M)** button to switch to USB mode. The speaker will automatically begin playing music from the USB drive.
4. Use the Play/Pause, Next Track, and Previous Track buttons to control playback.

5.4. FM Radio Mode

1. Turn on the speaker.
2. Press the **Mode (M)** button repeatedly until you enter FM Radio mode.
3. To auto-scan for available stations, short press the **Play/Pause (►/–)** button. The speaker will scan and save all available stations.
4. Use the **Next Track (►►)** and **Previous Track (◀◀)** buttons to navigate between saved FM stations.

5.5. TWS (True Wireless Stereo) Function

Figure 5.3: TWS Function Icon

The TWS function allows you to pair two LEDWOOD Xtreme 240 speakers together for a true stereo sound experience.

1. Ensure both Xtreme 240 speakers are powered on and in Bluetooth mode, but not connected to any device.
2. On one of the speakers (this will be the primary speaker), press and hold the **Play/Pause (►/–)** button for 2-3 seconds. The speaker will emit a pairing tone.
3. The two speakers will automatically connect to each other. Once connected, you will hear a confirmation tone.

4. Now, connect your Bluetooth device to the primary speaker (the one you initiated TWS pairing on).
5. Audio will now play in stereo across both speakers.

5.6. Voice Assistant

Figure 5.4: Voice Assistant Icon

When connected via Bluetooth, you can activate your device's voice assistant (e.g., Siri, Google Assistant) through the speaker.

- Short press the **Play/Pause (►/–)** button to activate the voice assistant on your connected smartphone.
- Speak your command into the speaker's microphone.

6. Maintenance and Care

- **Cleaning:** Use a soft, dry cloth to clean the speaker's surface. Do not use abrasive cleaners or solvents.
- **Water Resistance:** The speaker has an IPX5 rating, meaning it is resistant to splashes and light rain. Do not submerge it in water or expose it to strong jets of water. Ensure the port cover is securely closed when near water.
- **Storage:** Store the speaker in a cool, dry place when not in use. Avoid storing it in areas with extreme temperatures or high humidity.
- **Battery:** To prolong battery life, charge the speaker fully before first use and at least once every three months if not used regularly.

7. Troubleshooting

Problem	Possible Cause	Solution
Speaker does not turn on.	Low battery.	Charge the speaker fully using the provided USB-C cable.
No sound.	Volume too low; incorrect mode; device not connected.	Increase volume on both speaker and connected device. Ensure correct mode (Bluetooth, AUX, USB). Re-pair Bluetooth device or check AUX/USB connection.

Problem	Possible Cause	Solution
Bluetooth connection fails.	Speaker not in pairing mode; device too far; interference.	Ensure speaker is in Bluetooth pairing mode. Move device closer to speaker. Turn off other Bluetooth devices to reduce interference. Forget device on your phone and re-pair.
FM Radio reception is poor.	Weak signal.	Move the speaker to a location with better reception. Re-scan for stations.
TWS pairing fails.	Speakers already connected to a device; incorrect pairing procedure.	Ensure both speakers are disconnected from any Bluetooth devices. Follow the TWS pairing instructions carefully.

8. Specifications

Figure 8.1: LEDWOOD Xtreme 240 with dimensions

Feature	Specification
Model Name	Xtreme 240
Brand	Ledwood
Connectivity Technology	Bluetooth, Auxiliary, USB
Maximum Speaker Output Power	200 Watts (Peak) / 20 Watts RMS
Audio Output Mode	Stereo
Speaker Type	Outdoor
Special Feature	Splashproof (IPX5)
Compatible Devices	Game Console, MP3 Player, Laptop, Smartphone, Tablet, Television

Feature	Specification
Color	Black
Average Battery Life	5 hours
Speaker Size	7.5 Centimeters
Water Resistance Level	IPX5 (Splashproof)
Bluetooth Range	10 Meters
Number of Audio Channels	2.0
Power Source	Battery Powered (Cable Electric for charging)
Battery Capacity	3000 mAh
Product Dimensions (L x W x H)	34 x 14.3 x 14.8 cm
Weight	2.67 Kilograms

9. Warranty and Support

The LEDWOOD Xtreme 240 speaker comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions.

For technical support, troubleshooting assistance, or warranty claims, please contact LEDWOOD customer service through their official website or the contact information provided in your product documentation.

© 2023 Ledwood. All rights reserved.