CHICCO 00007388100000

CHICCO Home Bottle Warmer User Manual

Model: 00007388100000

Brand: CHICCO

1. Introduction

Thank you for choosing the CHICCO Home Bottle Warmer. This device is designed to quickly and safely warm baby bottles and food jars, ensuring your baby's meal is always at the perfect temperature. It features a user-friendly touch interface and specialized programs, including one for preserving breast milk nutrients. Please read this manual carefully before use to ensure proper operation and maintenance.



This image displays the CHICCO Home Bottle Warmer, a compact white device designed to warm baby bottles and food jars. A baby bottle is shown placed inside the warmer. To the right, the product's retail packaging highlights key features such as 'Quick and accurate' warming, 'Warms in just 4 minutes', '5 modes', and 'Preserves breastmilk nutrients'. The warmer features a touch interface with icons for different bottle types and a power button.

2. Important Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions before use.
- Do not immerse the cord, plug, or the appliance itself in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.

- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot liquids.
- Always check the temperature of the food before feeding the baby.
- This appliance has an automatic shut-off feature for maximum safety.

3. Package Contents

Please check the box for the following items:

- CHICCO Home Bottle Warmer Unit
- Practical Basket for smaller formats
- Instruction Manual (this document)

4. Product Overview

The CHICCO Home Bottle Warmer features a sleek design with an intuitive touch interface for easy operation.

Key Components:

- **Heating Chamber:** Where the bottle or jar is placed for warming.
- **Touch Interface Panel:** Contains control buttons and indicators.
- **Power Button:** To turn the device on/off.
- **Mode Selection Buttons:** Icons for different warming modes (e.g., bottle, jar, breast milk).
- **Indicator Lights:** Show current status or selected mode.
- **Removable Basket:** For holding smaller bottles or food jars securely.

5. Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, wipe the exterior of the warmer with a damp cloth. Clean the removable basket with warm soapy water, rinse thoroughly, and dry. Do not immerse the main unit in water.
3. **Placement:** Place the bottle warmer on a stable, flat, heat-resistant surface, away from direct sunlight or heat sources. Ensure there is adequate ventilation around the unit.

4. **Connect:** Plug the power cord into a suitable electrical outlet.

6. Operating Instructions

General Warming Procedure:

1. **Add Water:** Pour clean tap water into the heating chamber. The amount of water depends on the size of the bottle/jar and the desired warming time. Refer to the water level markings inside the chamber or the specific program guidelines.
2. **Place Bottle/Jar:** Place the baby bottle or food jar into the heating chamber. For smaller items, use the provided basket. Ensure the bottle/jar is securely positioned.
3. **Select Mode:** Press the power button to turn on the warmer. Use the touch interface to select the appropriate warming mode:
    - **Bottle Mode:** For standard milk bottles (plastic or glass).
    - **Breast Milk Mode:** A gentle warming cycle designed to preserve breast milk nutrients.
    - **Food Jar Mode:** For warming baby food jars.
    - **Defrost Mode:** For thawing frozen milk bags or food jars.
4. **Start Warming:** Once the mode is selected, the warming cycle will begin automatically. An indicator light will illuminate.
5. **Completion:** The warmer will emit an audible and visual signal when the warming cycle is complete. The device will automatically shut off.
6. **Remove and Check:** Carefully remove the bottle/jar using the basket or appropriate tongs. Always shake the bottle gently and check the temperature of the contents on your wrist before feeding your baby.

Keeping Warm Function:

The warmer can maintain the temperature of the warmed meal for up to one hour after the cycle is complete. This feature is automatically activated after warming.

Consecutive Cycles:

The CHICCO Home Bottle Warmer is designed to perform consecutive heating cycles, making it ideal for families with multiple children or for preparing multiple meals.

7. Maintenance and Cleaning

Regular cleaning ensures optimal performance and hygiene.

Daily Cleaning:

1. Unplug the warmer and allow it to cool completely.
2. Empty any remaining water from the heating chamber.
3. Wipe the interior and exterior of the warmer with a damp cloth. Do not use abrasive cleaners or scourers.
4. Wash the removable basket with warm soapy water, rinse thoroughly, and dry.

Descaling:

Over time, mineral deposits (limescale) may build up in the heating chamber, especially in areas with hard water. Descaling is recommended every 2-4 weeks, or more frequently if you notice slower heating times or white residue.

1. Unplug the warmer and ensure it is cool.
2. Mix 50ml of white vinegar with 100ml of cold water.
3. Pour the solution into the heating chamber.
4. Allow the solution to soak for 30 minutes to 1 hour, or until the limescale dissolves. Do not turn on the warmer during this process.
5. Empty the solution and rinse the heating chamber thoroughly with clean water several times to remove any vinegar residue.
6. Wipe dry with a clean cloth.

8. Troubleshooting

If you encounter any issues with your CHICCO Home Bottle Warmer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Warmer does not turn on.	Not plugged in; Power outlet issue; Damaged cord/plug.	Ensure the warmer is securely plugged into a working outlet. Check the power cord for damage.
Warming takes too long.	Insufficient water; Limescale buildup; Incorrect mode selected.	Ensure adequate water level. Perform descaling if necessary. Verify the correct warming mode is selected.
Food/milk is not warm enough.	Too much water; Bottle/jar too large for selected mode.	Adjust water level according to instructions. Ensure bottle/jar size is compatible with the selected mode.
Warmer shuts off prematurely.	Automatic shut-off activated; Overheating.	This is a safety feature. Allow the unit to cool down before attempting another cycle. Ensure proper water levels.
Audible/visual signal not working.	Malfunction.	If other functions work, this may indicate a minor fault. Contact customer support if persistent.

If the problem persists after trying these solutions, please contact CHICCO Customer Support.

9. Specifications

Feature	Detail
Model Number	00007388100000

Feature	Detail
Gender	Unisex
Number of items in package	1
Style	Plastic
Battery(ies) / Cell(s) required	No
Manufacturer	Artsana SPA
Product Dimensions (L x W x H)	14 x 14 x 17.5 cm
Weight	481 grams
ASIN	B092S9L6N8
Date first available on Amazon.com.be	April 20, 2022
Average Customer Review	4.1 out of 5 stars (2,819 ratings)
Amazon Best Sellers Rank	#1540 in Baby Products; #12 in Bottle Warmers & Sterilizers

10. Warranty and Support

Warranty Information:

This CHICCO product is covered by a manufacturer's warranty against defects in materials and workmanship. The specific terms and duration of the warranty may vary by region. Please retain your proof of purchase for warranty claims.

Customer Support:

For technical assistance, troubleshooting, or warranty inquiries, please contact CHICCO Customer Support. Refer to the CHICCO official website or product packaging for the most up-to-date contact information in your region.
You may also visit the product page on Amazon.com.be for additional support resources:
https://www.amazon.com.be/dp/B092S9L6N8

© 2024 CHICCO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question