Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Joyroom JR-K12

JR-K12 Zhen Miao Series Automatic Dual-Mode Capacitive Pen

User Manual

Overview Contents Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Product Overview

The Joyroom JR-K12 Zhen Miao Series Automatic Dual-Mode Capacitive Pen is a versatile stylus designed for seamless interaction with various touch-enabled devices, including tablets and smartphones. Its compact design and high utility make it an essential tool for digital note-taking, drawing, and precise navigation.





Figure 1: The Joyroom JR-K12 Zhen Miao Series Automatic Dual-Mode Capacitive Pen, showcasing its sleek white design.

2. Package Contents

Please check the package for the following items:

- 1 x JR-K12 Zhen Miao Series Capacitive Pen
- 1 x USB Charging Cable
- 1 x User Manual (this document)

3. Setup and First Use

1. **Initial Charge:** Before first use, fully charge the JR-K12 pen. Connect the charging cable to the pen's charging port and a compatible USB power source. The indicator light will typically show charging status and turn off or change color when fully charged.

2. **Power On:** To turn on the pen, simply touch the tip to the screen of a compatible device. The pen is designed for automatic dual-mode operation, meaning it should function immediately upon contact with a supported screen.
3. **Compatibility:** This capacitive pen is compatible with most tablets and smartphones that support touch input. For optimal performance, ensure your device's screen is clean and free of debris.



Figure 2: The JR-K12 pen can be conveniently attached to the side of compatible tablets for storage or charging (if magnetic charging is supported by the device).

4. Operating Instructions

The JR-K12 pen offers a straightforward user experience:

- **Writing and Drawing:** Simply touch the pen tip to your device's screen to begin writing, drawing, or navigating. The pen's precise tip allows for accurate input.
- **Automatic Dual-Mode:** The pen automatically adapts to the device's touch input, providing a smooth and responsive experience without requiring manual pairing or complex settings.
- **Power Saving:** The pen is designed to enter a low-power standby mode after a period of inactivity to conserve battery life. To reactivate, simply touch it to the screen again.



Figure 3: Demonstrating the use of the JR-K12 pen for creative tasks and precise input on a tablet.

5. Care and Maintenance

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the pen's body. For the tip, gently wipe with a slightly damp cloth if necessary, ensuring no moisture enters the pen.
- **Storage:** Store the pen in a cool, dry place away from direct sunlight and extreme temperatures. Avoid placing heavy objects on the pen.
- **Battery Care:** To prolong battery life, avoid fully discharging the pen frequently. Charge it regularly, even if not in constant use.
- **Tip Replacement:** If the pen tip becomes worn or damaged, it may affect performance. Refer to Joyroom's official support for information on replacement tips.

6. Troubleshooting

If you encounter issues with your JR-K12 pen, please refer to the following table:

Problem	Possible Cause	Solution
Pen not responding	Low battery; Device screen issue; Pen not powered on.	Charge the pen fully. Ensure your device screen is clean and responsive to finger touch. Re-touch the pen to the screen to activate.
Inaccurate writing/drawing	Worn tip; Screen protector interference; Device calibration issue.	Check the pen tip for wear and replace if necessary. Ensure screen protector is properly applied. Restart your device.

Problem	Possible Cause	Solution
Pen disconnects frequently	Low battery; Interference from other devices; Device software issue.	Charge the pen. Move away from strong electromagnetic fields. Update your device's operating system.

7. Product Specifications

Feature	Detail
Model Number	JR-K12
Brand	Joyroom
Color	White
Material	Mixed Material
Product Dimensions	10 x 5 x 1.27 cm
Item Weight	140 g (0.14 Kilograms)
Average Battery Standby Life	12 Hours
Batteries Included	No (refers to user-replaceable batteries, internal rechargeable battery is present)
Compatible Devices	Tablet, Smartphone
GTIN (Global Trade Identification Number)	06941237119377

8. Warranty and Support

For warranty information, technical support, or to purchase replacement parts, please contact Joyroom customer service or visit their official website. Keep your purchase receipt as proof of purchase.
You can find more information and contact details on theJoyroom Store on Amazon.

© 2024 Joyroom. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B092TLVTGY

More documents and user manuals: **https://manuals.plus/**